Average CT marks calculations

```
clc; %Clears previous data from command window
clear all; %Removes all variables from the current workspace
cd('F:\Study material\Lab\3-2\Power System I'); %Changes file directory
x = xlsread('Exp01') %Imports data from excel file
fprintf('\n Roll No
                                                        CT3
                                                                           CT4
                                \tCTI
                                                CT2
           CT6\n') %Display the text
disp(x) %Display the data inside variable
n=length(x); %Determines the number of columns
y = x(:,2:n); %Isolates the data to be averaged from the roll
fprintf('Marks:\n') %Display the text
disp(y) %Display the data inside variable
w = sort(y, 2, 'descend'); %Rearranging the columns in descending order. 2 is for
descending rawwise
fprintf('\nSorting descending order rawwise: \n') %Display the text
disp(w) %display the data inside variable
z = w(:,1:3) %Takes the first three columns containing highest three marks
fprintf('\nBest three marks: \n') %Display the text
disp(z) %Display the data inside variable
m = mean(z, 2) %Calculates mean of the highest three marks. 2 is for doing the action
fprintf('\nAverage marks: \n') %Display the text
disp(m) %Display the data inside variable
Output = round(m) %Round the calculated data
fprintf('Rounding the average marks: \n') %Display the text
disp(Output) %display the value inside variable
Roll=x(:,1) %Taking the column of Roll
Y=[Roll Output] %Forming a matrix of column Roll and Attained data as marks
fprintf(' Roll No Attained Marks \n') %Display the text
disp(Y) %Display the marks inside variable
    Ascending and descending
clc; %Clears previous data from command window
clear all; %Removes all variables from the current workspace
cd('F:\Study material\Lab\3-2\Power System I'); %Changes file directory
Matrix=xlsread('Exp01p02'); %Reads from excel file
fprintf('Matrix:'); %Prints the data
disp (Matrices) % Shows the output
n=length(Matrix); %Determines the number of elements
%Ascending
for j=1:n %Campare first elements
    for k=j+1:n %Campare second elements
        if Matrix(j)>=Matrix(k) %Compare greater or not
            m=Matrix(j); %Store the greater number in a variable
            Matrix(j)=Matrix(k); %Replace the greater number by the smaller one
           Matrix(k)=m; %Replace the smaller number with greater number
       end
    end
end
fprintf('Ascending: '); %Print the data in desired order
```

```
%Descending
disp (Matrix) %Show the output
Output=xlsread('Exp01p02'); %Read from excel file
n=length(Output); %Read the number of elements
for j=1:n %Campare first elements
    for k=j+1:n %Campare second elements
        if Output(j) <=Output(k) %Compare samller or not</pre>
           m=Output(j);%Store the smaller number in a variable
           Output(j) = Output(k); Replace the smaller number by the smaller one
           Output(k)=m; %Replace the greater number with smaller number
        end
    end
end
fprintf('Descending: '); %Printing the data
disp (Output) %Show the output
     Generate Y-bus matrix
clc; %Clears previous data from command window
clear all; %Removes all variables from the current workspace
cd('F:\Study material\Lab\3-2\Power System I'); %change the file directory
A = xlsread('Exp02'); %Read the excel file
n = length(A); %Determine the length of the excel file
% Applying symmetric condition
for w=1:n
Z(A(w,1),A(w,2)) = A(w,3)+i*A(w,4);
Z(A(w,2),A(w,1)) = A(w,3)+i*A(w,4);
end
m = length(Z) %Determine the length of the new matrix
for j=1:m
for k=1:m
    if Z(j,k) == 0
       Z(j,k) = inf;
    end
end
fprintf(' Z matrix is \n') %Display the text
disp(Z) %Display the output
y = 1./Z %Taking inverse impedance matrix
p = sum(y,2) %Taking symmetric summation
%Apply looping condition to determine value of the matrix element
for u=1:m
for x=1:m
    if u~=x
       Y(u,x) = -y(u,x); %For diagonal element
    else
       Y(u,x) = p(u); %For non-diagonal element
    end
end
end
fprintf(' Y- bus matrix is \n') %Display the text
disp(Y) %Display the output

    Reduced Y-bus

   clc; %Clears previous data from command window
   clear all; %Removes all variables from the current workspace
   cd('F:\Study material\Lab\3-2\Power System I'); %change the file directory
   A = xlsread('Exp02'); %Read the excel file
```

```
n = length(A); %Determine the length of the excel file
  % Applying symmetric condition
  for w=1:n
  Z(A(w,1),A(w,2)) = A(w,3)+i*A(w,4);
  Z(A(w,2),A(w,1)) = A(w,3)+i*A(w,4);
  m = length(Z) %Determine the length of the new matrix
  for j=1:m
  for k=1:m
      if Z(j,k) == 0
          Z(j,k) = inf;
      end
  end
  fprintf(' Z matrix is \n') %Display the text
  disp(Z) %Display the output
  y = 1./Z %Taking inverse impedance matrix
  p = sum(y,2) %Taking symmetric summation
  %Apply looping condition to determine value of the matrix element
  for u=1:m
  for x=1:m
       if u~=x
          Y(u,x) = -y(u,x); %For diagonal element
          Y(u,x) = p(u); %For non-diagonal element
      end
  end
  end
  fprintf(' Y- bus matrix is \n') %Display the text
  disp(Y) %Display the output
  d = length(Y);
  f = input('Total no. of buses: ');
  g = input('No. of reduction: ');
  for h=1:g %No. of reduction
      F = zeros(d-1); %Define a new matrix
      for t=1:(d-1) %Access all Y matrix element
           for r=1:(d-1) %
           F(t,r) = Y(t,r) - ((Y(t,d)*Y(d,r))/Y(d,d));
           end
      end
      Y = F;
     d = d-1;
  end
  fprintf(' Z matrix is \n') %Display the text
  disp(Y)
    Gaus-Seidal
clc; %Clears previous data from command window
clear all; %Removes all variables from the current workspace
cd('F:\Study material\Lab\3-2\Power System I'); %change the file directory
A = xlsread('EXp02p02'); %Read the excel file
n = length(A); %Determine the length of the excel file
% Applying symmetric condition
for w=1:n
    Z(A(w,1),A(w,2)) = A(w,3)+i*A(w,4);
```

```
Z(A(w,2),A(w,1)) = A(w,3)+i*A(w,4);
end
m = length(Z); %Determine the length of the new matrix
for j=1:m
    for k=1:m
         if Z(i,k) == 0
             Z(j,k) = inf;
         end
    end
end
fprintf(' Z matrix is \n') %Display the text
disp(Z) %Display the output
y = 1./Z %Taking inverse impedance matrix
p = sum(y,2) %Taking symmetric summation
%Apply looping condition to determine value of the matrix element
for u=1:m
    for x=1:m
         if u~=x
             Y(u,x) = -y(u,x); %For diagonal element
             Y(u,x) = p(x); %For non-diagonal element
         end
    end
end
fprintf(' Y- bus matrix is \n') %Display the text
disp(Y) %Display the output
cd('F:\Study material\Lab\3-2\Power System I'); %change the file directory
B = xlsread('Exp05'); %Read the excel file
j = 3;
V = B(:,2);
V0=B(:,2);
%to get the value of real power
P=B(:,3)-B(:,5);
%to get the value of reactive power
Q=B(:,4)-B(:,6);
%to get the angle
ang=B(:,7);
V1=V;
% to get the value of generator bus
Pg=B(:,3);
for w=1:100
    z=V;
    for k=2:j
        vv1=0;
        yv2=0;
         for h=1:j
             yv2=yv2+Y(k,h)*V(h); %to find the product of Y bus and voltages
                 yv1=yv1+Y(k,h)*V(h); %to find the product of Y bus and voltages
             end
         end
         if Pg(k) \sim = 0
             g(k) = imag(V(k) * (conj(yv2))); %to get the imaginary value
            S(k)=P(k)+1i*g(k); %to calculate the apparent power
         else S(k)=P(k)+1i*Q(k);
```

```
end
        V(k)=(1/Y(k,k))*((conj(S(k))/conj(V(k)))-yv1); %to get the value of node
voltages
        ang1(k) = angle(V(k));
                                %to get the angles
        ang2(k)=rad2deg(ang1(k)); %to convert the radian values to degrees
         if Pg(k) \sim = 0
             V(k) = V0(k) * exp(1i*ang1(k));
         end
    end
        V1=abs(V);
          ang2=rad2deg(ang1);
    E=abs((V-z)/V);
    if E<=10e-4
        break:
                  %to break the for loop
    end
    Vlt 1(w) = V1(1);
    Vlt 2(w) = V1(2);
    Vlt 3(w) = V1(3);
    ang 1(w) = ang2(1);
    ang 2(w) = ang 2(2);
    ang 3(w) = ang2(3);
end
% to show the value column wise
Vlt 1=Vlt 1';
ang 1=ang 1';
Vlt 2=Vlt 2';
ang_2=ang_2';
Vlt 3=Vlt 3';
ang 3=ang 3';
iteration=(1:w-1)';
% to show the values in a table
table(iteration, Vlt 1, ang 1, Vlt 2, ang 2, Vlt 3, ang 3)
      Zero-positive-negative sequence
clc; %Clears previous data from command window
clear all; %Removes all variables from the current workspace
% magnitude and phase of unbalanced voltage V1
M1 = input('Enter magnitude of V1:');
P1 = input('Enter phase of V1:');
V1 = M1.*exp(j*deg2rad(P1))
% magnitude and phase of unbalanced voltage V2
M2 = input('Enter magnitude of V2:');
P2 = input('Enter phase of V2:');
V2 = M2.*exp(j*deg2rad(P2))
% magnitude and phase of unbalanced voltage V3
M3 = input('Enter magnitude of V3:');
P3 = input('Enter phase of V3:');
V3 = M3.*exp(j*deg2rad(P3))
% calculate a
a = 1.*exp(j*2*pi/3);
anew = a.*a;
% finding zero sequence
Va0 = (1/3) * (V1+V2+V3);
Vb0 = Va0;
Vc0 = Va0;
% finding positive sequence
Va1 = (1/3) * (V1+a*V2+anew*V3);
```

```
1801171
```

```
Vb1 = anew*Va1;
Vc1 = a*Va1;
% finding negative sequence
Va2 = (1/3) * (V1+anew*V2+a*V3);
Vb2 = a*Va2;
Vc2 = anew*Va2;
% finding original sequence
Va = (Va0+Va1+Va2); Vb = (Vb0+Vb1+Vb2); Vc = (Vc0+Vc1+Vc2);
% plotting unbalanced sequence
subplot(2,3,1); compass([V1,V2,V3]); title('Unbalanced Sequence');
% plotting zero sequence
subplot(2,3,2); compass([Va0,Vb0,Vc0]); title('Zero Sequence');
% finding positive sequence
subplot(2,3,3); compass([Va1,Vb1,Vc1]); title('Positive Sequence');
% finding negative sequence
subplot(2,3,4); compass([Va2,Vb2,Vc2]); title('Negative Sequence');
% finding original sequence
subplot(2,3,6); compass([Va,Vb,Vc]); title('Original Sequence');
     Transient response analysis
clc; %Clears previous data from command window
clear all; %Removes all variables from the current workspace
% Declaring function
syms i(t)
% Assigning values to the variable
R = 50;
             % Resistance
a = pi/3;
            % Phase angle
L = 300e-3; % Inductance
f = 100;
            % Frequency
w = 2*pi*f;
Vm = 100;
           % Voltage
% Formula
p = dsolve(L*diff(i)+i/R==Vm*sin(w*t+a),i(0)==0)
% Plotting function
ezplot(p)
grid on
% Labeling plot
xlabel('Time(sec)')
ylabel('Current(amp)')
title('Transient response')
```