
# **PA Amplifier**

# Front Panel connections - Ahuja SSA-250M



### 1. MIC-1 Input Jack Socket

For accepting unbalanced signal from a low impedance microphone.

- 2. MIC-2 Input Jack Socket
- 3. MIC-3 Input Jack Socket
- 4. MIC-4 Input Jack Socket
- 5. MIC-5/AUX-1 Selector Switch
- 6. MIC-5 Input Jack Socket
- 7. MIC-6/AUX-2 Selector Switch
- 8. MIC-6 Input Jack Socket
- 9. BOX SPEAKER / DRIVER UNIT Selector Switch

### 10. BASS Control

For attenuating or boosting the signal level of low frequencies.

### 11. TREBLE Control

For attenuating or boosting the signal level of high frequencies.

## 12. POWER Switch

#### 13. POWER LED

This LED glows when the amplifier is switched ON.

#### 14. OVERLOAD LED

This LED glows when the circuit protector trips.

#### 15. RESET button

This button pops out when the circuit protector trips. Rectify the cause and press the RESET button for resetting normal operation of the amplifier.

# 16. LED Array

This indicates the output level of the amplifier.

# 17. MASTER Volume Control

For adjustment of the overall volume level from the amplifier.

- 18. MIC-6/AUX-2 Volume Control
- 19. MIC-5/AUX-1 Volume Control
- 20. MIC-4 Volume Control
- 21. MIC-3 Volume Control
- 22. MIC-2 Volume Control
- 23. MIC-1 Volume Control