
ISS Camera - Troubleshooting

Troubleshooting Tree



- 1. The connection between IP camera and router cannot be established. Check Ethernet cable/IP address setting
- 2. The IP camera's IP address is repeatedly displayed as "DHCP mode". Set Static IP address to the cam.
- 3. Continuously seeing gray image. Network Congestion.
- 4. Having ghost image. Insufficient network bandwidth.
- 5. The image is very blocky. Set video resolution to lower one.
- 6. & 7. A warning message saying "Your video quality is too high for your internet bandwidth" popped up. Insufficent network bandwidth
- 8. The video is not real-time. Check video buffer setting.