Part 1 Recap

```
In [ ]: #/ default_exp part_1_recap
```

Please fill up the questionnaire at: https://esami.unipi.it

Jupyter and Python

Installing Anaconda and dependencies to run the notebooks

- Install Anaconda: Anaconda Download Page
- Refer to the Anaconda documentation for more information here
- Open a terminal window:
 - Windows: From the Start menu, search for and open "Anaconda Prompt"
 - MacOS/Linux: Click the terminal icon.
- Once in a terminal,
 - create an environment: conda create --name env-automatic-control python=3.9
 - activate it: conda activate env-automatic-control
- Install everything that is needed
 - Jupyter notebook:

```
conda install -c conda-forge notebook
```

Standard engineering libraries:

```
python -m pip install matplotlib numpy pandas
conda install numpy scipy matplotlib # if not yet installed
conda install -c conda-forge control
conda install -c anaconda sympy
```

You are set up!

Going back to work (opening your Jupyter notebooks)

- Open a terminal window:
 - Windows: From the Start menu, search for and open "Anaconda Prompt"
 - MacOS/Linux: Click the terminal icon.
- Move to yur project folder (e.g. cd /Users/<USERNAME>/MyProject/)
 (if you need to find out how to find your folder path in Windows read below: "Note: To find out where is your folder in Windows")
- Activate your conda environment: conda activate env-automatic-control
- Run: jupyter notebook

A new tab in your browser should open up automatically showing the jupyter home folder (your current folder). If it does not open, open your favourite brower and type: localhost:8888 in the browser address bar. Sometime jupyter requires a token - this is automatically created when jupyter is started. Look back to your terminal window right after the command jupyter notebook there should be a line similar to:


To access the notebook, open this file in a browser:
 file:///Users/<YOUR_USERNAME>/Library/Jupyter/runtime/nbserver-73848open.html
Or copy and paste one of these URLs:
 http://localhost:8888/?
token=66781622f3ed474ccf1f0f61e5708b035acfcf4e41cc7c8a
or http://127.0.0.1:8888/?
token=66781622f3ed474ccf1f0f61e5708b035acfcf4e41cc7c8a

Copy and paste one of the last two addresses in your browser to start your jupyter session.

You are ready to start coding!

Note: To find out where is your folder in Windows:

- Open Windows Explorer and go inside the folder you need
- Right click on the address path and right-click
- Select "copy address as text" (see picture below)
- Go back to your Anaconda prompt and paste it (remember to type cd first!)



References

- Installing Jupyter Software
- Python Control Library

The Control Problem

- Systems and control systems
- Three problems:
 - system identification problem
 - simulation problem
 - control Problem
- Why do we need feedback control

LTI systems

- Homogeneity
- Superposition (Additivity)
- Time Invariance
- Impulse Response

LTI systems can be characterised by their response to an impulse function (the output of the system when presented with a brief input signal)

Transfer Functions

Laplace domain representation of a system

Definition: Transfer function is the Laplace transform of the impulse response of a linear, time-invariant system with a single input and single output when you set the initial conditions to zero.

- State space vs Transfer functions
- Laplace Transform

The Laplace transform is important because it is a tool for solving differential equations: it transforms linear differential equations into algebraic equations, and convolution into multiplication!

• Derivatives and integrals become algebric operations

From a system perspective, the Transfer function expresses the relation between the Laplace Transform of the input and that of the output:

$$Y(s) = \mathbf{c}^T (s\mathbf{I} - \mathbf{A})^{-1} \mathbf{b} U(s)$$

- Properties of the Laplace Transform (relationships between time and frequency)
 - $lacksquare rac{df}{dt}(t)
 ightarrow sF(s)$
 - lack af(t) + bg(t)
 ightarrow aF(s) + bG(s)
- Laplace transforms of known functions:
 - ullet $\delta(t)
 ightarrow 1$

 - $\begin{array}{c} \bullet \quad 1(t) \rightarrow \frac{1}{s} \\ \bullet \quad e^{-at} \rightarrow \frac{1}{s+a} \end{array}$

Stability and other properties

- System G(s) is asymptotically stable if all its poles have Re < 0
- System G(s) is stable if all its poles have G(s) $Re \leq 0$ and if those with Re = 0 have multiplicity one.
- System G(s) is unstable if it has at least one pole with Re>0 or with Re=0 and multiplicity ≥ 2 .
- BIBO stability:
 - A system is BIBO stable (Bounded Input, Bounded Output) if for each limited input, there is a limited output
 - ullet For linear systems: BIBO stability if and only if poles of the transfer functions have Re < 0
- Stability of a system in a state space representation
- Controllability (Reachability)
- Observability

Block diagrams

- Standard representation of interconnected systems and subsystems using Transfer Functions
- Block diagram algebra (serie, parallel, feedback) and equivalent block diagrams
- Zero-poles cancellations
- Impact on stability and other properties

System Response

- Dominant pole approximation
- First-order and second-order systems
 - First-order systems: step response and performance
 - time constant (τ) Characterises completely the response of a first order system
 - settling time: $t_s = au ln(0.05)$ (time to get to 95% of steady state)
 - Second order systems: step response and performance
 - More parameters to define performance: max overshoot, time of max overshoot, settling time, oscillation period

Frequency response

- Assuming that the system is asymptotically stable,
- If we input a sinusoid $Asin(\omega t)$
- ullet The output of the system converges $y(t)=A|G(j\omega)|sin(\omega t+ \angle G(j\omega))$
- $G(j\omega)$ is the frequency response
- If we know magnitude and phase of $G(j\omega)$ (for varying ω) then we know how the system behaves for all sinusoidal inputs with different driving frequencies.

Bode plots

- Frequency Response and Bode Plots
 - analysing the gain and the phase shift across the full frequency spectrum
 - gain diagram and phase diagram
- Leverages the properties of transfer functions and of logarithms:
 - lacktriangle The transfer function of linear systems are polynomial fractions in s
 - It is always possible to factor polynomials in terms of their roots (zeros and poles)
 - Each polynomial is the product of first-order or second-order (potentially with multiplicity > 1)
 - To build the frequency response of the system is useful to have simple rules to represent each term
 - The logarithm of a product is equal to a sum of logarithms
 - \circ remember to convert gain to dB: $|G(j\omega)|_{dB}=20log_{10}|G(j\omega)|$
- Sketching Bode Plots
 - ullet Given a transfer function G(s) we can obtain the (steady state) frequency response setting $s=j\omega o G(j\omega)$
 - $G(j\omega) = \text{real} + \text{imag}j$
 - $lacksquare \operatorname{\mathsf{Gain:}} \sqrt{\operatorname{real}^2 + \operatorname{img}^2} = |G(j\omega)|$
 - lacksquare Phase: $atan2(\mathrm{img,real}) = arg(G(j\omega)) = \angle G(j\omega)$
 - Our building blocks:
 - o constant gain
 - integrator
 - o simple pole
 - complex poles
 - specular behaviour for the zeros (properties of the logarithms)
 - Transform the trasnfer function to the Bode form before drawing the Bode plots!

Final value theorem and steady state error

- Meaning of final value
- ullet Theorem: for an asymptotically stable LTI system: $\lim_{t o\infty}x(t)=\lim_{s o0}sX(s)$
- System type: number of poles at the origin
- Analysis of the final value for different system types and different inputs
- For a feedback system: the final value of the error is a much better indicator of the performance of our controller

Diving deeper into the feedback loop

- Included load disturbances and measurement noise in the feedback loop
- Sensitivity function (feedback and disturbances / low frequency specifications)
- Complementary sensitivity function (feedback and measurements / high frequency specifications)
- Design requirements on the loop gain function |R(s)G(s)|

Routh-Hurwitz Criterion

- Necessary and sufficient condition to analyse the stability of the systems without solving for the roots explicitely
- Usage can be extended to beyond stability
 - Gain margins
 - Deal with requirement on the speed of the response (time to half)

Coming up next

- Polar plots and the Nyquist plot
- Stability margins
- Root locus
- PID controllers
- Lead-lag/lad-lead compensators