

Publication # 1.0 Revision: 1027

Issue Date: October 2021

#### Disclaimer

The information presented in this document is for informational purposes only and may contain technical inaccuracies, omissions, and typographical errors. The information contained herein is subject to change and may be rendered inaccurate for many reasons, including but not limited to product and roadmap changes, component and motherboard versionchanges, new model and/or product releases, product differences between differing manufacturers, software changes, BIOS flashes, firmware upgrades, or the like. Any computer system has risks of security vulnerabilities that cannot be completely prevented or mitigated. AMD assumes no obligation to update or otherwise correct or revise this information. However, AMD reserves the right to revise this information and to make changes from time to time to the content hereof without obligation of AMD to notify any person of such revisions or changes. THIS INFORMATION IS PROVIDED 'AS IS." AMD MAKES NO REPRESENTATIONS OR WARRANTIES WITH RESPECT TO THE CONTENTS HEREOF AND ASSUMES NO RESPONSIBILITY FOR ANY INACCURACIES, ERRORS, OR OMISSIONS THAT MAY APPEAR IN THIS INFORMATION. AMD SPECIFICALLY DISCLAIMS ANY IMPLIED WARRANTIES OF NON-INFRINGEMENT, MERCHANTABILITY, OR FITNESS FOR ANY PARTICULAR PURPOSE. IN NO EVENT WILL AMD BE LIABLE TO ANY PERSON FOR ANY RELIANCE, DIRECT, INDIRECT, SPECIAL, OR OTHER CONSEQUENTIAL DAMAGES ARISING FROM THE USE OF ANY INFORMATION CONTAINED HEREIN, EVEN IF AMD IS EXPRESSLY ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.AMD, the AMD Arrow logo, insert all other AMD trademarks used in the material here perAMD Trademarks and combinations thereof are trademarks of Advanced Micro Devices, Inc.Other product names used in this publication are for identification purposes only and may be trademarks of their respective companies. [Insert any third party trademark attribution here per AMD's Third Party Trademark List.]©[Insert year written\*]Advanced Micro Devices, Inc.All rights reserved.

#### **Third-party Disclaimer**

Third-party content is licensed to you directly by the third party that owns the content and is not licensed to you by AMD. ALL LINKED THIRD-PARTY CONTENT IS PROVIDED "AS IS" WITHOUT A WARRANTY OF ANY KIND. USE OF SUCH THIRD-PARTY CONTENT IS DONE AT YOUR SOLE DISCRETION AND UNDER NO CIRCUMSTANCES WILL AMD BE LIABLE TO YOU FOR ANY THIRD-PARTY CONTENT. YOU ASSUME ALL RISK AND ARE SOLELY RESPONSIBLE FOR ANY DAMAGES THAT MAY ARISE FROM YOUR USE OF THIRD-PARTY CONTENT.

1.0 Rev. 1027 October 2021

AMD ROCm<sup>TM</sup> Compiler Reference Guide

[This page left blank intentionally]

# **Table of Contents**

Table of Con	tents	. 4
Chapter 1	Overview of ROCmCC Compiler	. 6
Chapter 2	Command Options	. 6
2.1 Tarş	get Selection	. 6
2.2 Cod	le Generation	. 7
2.3 AM	D Optimizations for AMD Zen Architectures	. 8
2.3.1	-famd-opt	. 8
2.3.2	-fstruct-layout=[1,2,3,4,5,6,7]	. 8
2.3.3	-fitodcalls	. 9
2.3.4	-fitodcallsbyclone	. 9
2.3.5	-fremap-arrays	10
2.3.6	-finline-aggressive	10
2.3.7	-fnt-store (non-temporal store)	10
2.3.8	-fnt-store=aggressive	10
2.4 Opt	imizations Through Driver -mllvm <options></options>	10
2.4.1	-enable-partial-unswitch.	10
2.4.2	-aggressive-loop-unswitch	10
2.4.3	-enable-strided-vectorization.	11
2.4.4	-enable-epilog-vectorization.	11
2.4.5	-enable-redundant-movs	11
2.4.6	-merge-constant	12
2.4.7	-function-specialize	12
2.4.8	-lv-function-specialization	12
2.4.9	-enable-vectorize-compares	12
2.4.10	-inline-recursion=[1,2,3,4]	12
2.4.11	-reduce-array-computations=[1,2,3]	12
2.4.12	-global-vectorize-slp={true,false}	13
2.4.13	-region-vectorize	13
2.4.14	-enable-X86-prefetching	13

1	0	Rev	1027	October	-2021

2.4.15	-suppress-fmas	.13
2.4.16	-enable-licm-vrp	.13
2.4.17	-loop-splitting	.13
2.4.18	-enable-ipo-loop-split	.13
2.4.19	-compute-interchange-order	
2.4.20	-convert-pow-exp-to-int={true,false}	
2.4.21	-do-block-reordering={none,normal,aggressive}	
2.4.22	-fuse-tile-inner-loop	
2.4.23	-Hz,1,0x1 [Fortran]	
	U Compilation	
Chapter 3	Appendix A	
•	~~	
3.1 Sup	ported Status of Other Clang Options	.16

# **Chapter 1 Overview of ROCmCC Compiler**

The ROCmCC Compiler is based on the Clang/LLVM compiler technology. It is optimized for high-performance computing on AMD GPUs and CPUs and supports various heterogenous programming models such as HIP, OpenMP, and OpenCL.

# **Chapter 2 Command Options**

The CPU compiler optimizations described in this chapter originate from the AMD AOCC compiler. They are available in ROCmCC after the rocm-llvm-alt package installation. AMD provides high performance compiler optimizations for Zen-based processors in *AMD Optimizing C/C++ Compiler* (AOCC).

For more information, refer to

https://developer.amd.com/amd-aocc/

# 2.1 Target Selection

Option	Description
-march= <cpu></cpu>	Use it to specify if Clang must generate code for a specific processor family member and later. For example, if you specify -march=i486, the compiler can generate instructions that are valid on i486 and later processors, but which may not exist on the earlier ones.
- march=znver1	Use this architecture flag for enabling the best code generation and tuning for AMD Zen based x86 architecture. All the x86 Zen ISA and associated intrinsic are supported.
- march=znver2	Use this architecture flag for enabling the best code generation and tuning for AMD Zen2 based x86 architecture. All x86 Zen2 ISA and associated intrinsic are supported.
- march=znver3	Use this architecture flag for enabling best code generation and tuning for AMD Zen3 based x86 architecture. All x86 Zen3 ISA and associated intrinsic are supported.

# 2.2 Code Generation

Use the following options to specify the optimization level:

Level	Description
-00	It means no optimization: this level compiles the fastest and generates the most debuggable code.
-01	Between levels -00 and -02.
-02	A moderate level of optimization, which enables most optimizations.
-03	It is similar to the level -02, except that it enables the optimizations, which take longer to perform or may generate larger code (in an attempt to make the program run faster).  This -03 level has more optimizations when compared to the base LLVM
	version on which it is based. These optimizations include improved handling of indirect calls, advanced vectorization, and so on.
-Ofast	It enables all the optimizations from -03 along with other aggressive optimizations that may violate strict compliance with language standards.  This -0fast level has more optimizations when compared to the base LLVM version on which it is based. These optimizations include partial unswitching, improvements to inlining, unrolling, and so on.
-0s	It is similar to the level -02, but with extra optimizations to reduce the code size.
-0z	It is similar to the level -0s (and thus, -02), but reduces the code size further.
-0	It is equivalent to the level 02.
-04 and higher	It is equivalent to the level 03.

# 2.3 AMD Optimizations for AMD Zen Architectures

#### 2.3.1 -famd-opt

Enables a default set of AMD proprietary optimizations for the AMD Zen CPU architectures.

-fno-amd-opt disables the AMD proprietary optimizations.

The -famd-opt flag is useful when a user wants to build with the proprietary optimization compiler and not have to depend on setting any of the other proprietary optimization flags. Note, -famd-opt can be used in addition to other proprietary CPU optimization flags.

The table of optimizations below will implicitly enable the invocation of the AMD proprietary optimizations compiler. Whereas the -famd-opt flag explicitly requires such.

#### 2.3.2 -fstruct-layout=[1,2,3,4,5,6,7]

Analyzes the whole program to determine if the structures in the code can be peeled and if the pointer or integer fields in the structure can be compressed. If feasible, this optimization transforms the code to enable these improvements. This transformation is likely to improve cache utilization and memory bandwidth. It is expected to improve the scalability of programs executed on multiple cores.

This is effective only under flto as the whole program analysis is required to perform this optimization. You can choose different levels of aggressiveness with which this optimization can be applied to your application; with 1 being the least aggressive and 7 being the most aggressive level.

- o **fstruct-layout=1** enables structure peeling.
- o **fstruct-layout=2** enables structure peeling and selectively compresses self-referential pointers in these structures to 32-bit pointers, wherever safe.
- o **fstruct-layout=3** enables structure peeling and selectively compresses self-referential pointers in these structures to 16-bit pointers, wherever safe.
- o **fstruct-layout=4** enables structure peeling, pointer compression as in level 2 and further enables compression of structure fields, which are of integer type. This is performed under a strict safety check.
- o **fstruct-layout=5** enables structure peeling, pointer compression as in level 3 and further enables compression of structure fields which are of integer type. This is performed under a strict safety check.
- o **fstruct-layout=6** enables structure peeling, pointer compression as in level 2 and further enables compression of structure fields, which are of type 64-bit **signed int** or **unsigned int**. You must ensure that the values assigned to 64-bit **signed int** fields are in range -(2^31 1) to +(2^31 1) and 64-bit **unsigned int** fields are in the range 0 to +(2^31 1). Else, incorrect results may be obtained. This

#### AMD ROCm™ Compiler Reference Guide

- compression is performed without considering any safety analysis. So, you must ensure the safety based on the program compiled.
- o **fstruct-layout=7** enables structure peeling, pointer compression as in level 3 and further enables compression of structure fields, which are of type 64-bit **signed int** or **unsigned int**. You must ensure that the values assigned to 64-bit **signed int** fields are in range -(2^31 1) to + (2^31 1) and 64-bit **unsigned int** fields are in the range 0 to + (2^31 1). Else, incorrect results may be obtained. This compression is performed without considering any safety analysis. So, must ensure the safety based on the program compiled.

#### NOTE:

fstruct-layout=4 and fstruct-layout=5 are derived from fstruct-layout=2 and fstruct-layout=3 respectively, with the added feature of safe compression of integer fields in structures. Going from fstruct-layout=4 to fstruct-layout=5 may result in higher performance if the pointer values are such that the pointers can be compressed to 16-bits.

fstruct-layout=6 and fstruct-layout=7 are derived from fstruct-layout=2 and fstruct-layout=3 respectively, with the added feature of compression of the integer fields in structures. These are similar to fstruct-layout=4 and fstruct-layout=5, but here, the integer fields of the structures are always compressed from 64-bits to 32-bits, without any safety guarantee.

#### 2.3.3 -fitodcalls

It promotes indirect to direct calls by placing conditional calls. Application or benchmarks that have small and deterministic set of target functions for function pointers that are passed as call parameters benefit from this optimization. Indirect-to-direct call promotion transforms the code to use all possible determined targets under runtime checks and falls back to the original code for all the other cases. Runtime checks are introduced by the compiler for each of these possible function pointer targets followed by direct calls to the targets.

This is a link time optimization, which is invoked as -flto -fitodcalls.

### 2.3.4 -fitodcallsbyclone

Performs value specialization for functions with function pointers passed as an argument. It does this specialization by generating a clone of the function. The cloning of the function happens in the call chain as needed to allow conversion of indirect function call to direct call. This complements -fitodcalls optimization and is also a link time optimization, which is invoked as -flto -fitodcallsbyclone.

#### 2.3.5 -fremap-arrays

Transforms the data layout of a single dimensional array to provide better cache locality. This optimization is effective only under *flto* as the whole program analysis is required to perform this optimization, which can be invoked as *-flto -fremap-arrays*.

#### 2.3.6 -finline-aggressive

Enables improved inlining capability through better heuristics. This optimization is more effective when using with *flto* as the whole program analysis is required to perform this optimization, which can be invoked as *-flto -finline-aggressive*.

#### **2.3.7** -fnt-store (non-temporal store)

Generates a non-temporal store instruction for array accesses in a loop with a large trip count.

#### 2.3.8 -fnt-store=aggressive

This is an experimental option to generate non-temporal store instruction for array accesses in a loop, whose iteration count cannot be determined at compile time. In this case, compiler assumes the iteration count is huge.

# 2.4 Optimizations Through Driver -mllvm <options>

The following optimization options must be invoked through driver -mllvm <options>:

#### 2.4.1 -enable-partial-unswitch

Enables partial loop un-switching, which is an enhancement to the existing loop unswitching optimization in LLVM. Partial loop un-switching hoists a condition inside a loop from a path for which the execution condition remains invariant, whereas the original loop un-switching works for a condition that is completely loop invariant. The condition inside the loop gets hoisted out from the invariant path and original loop is retained for the path where condition is variant.

# 2.4.2 -aggressive-loop-unswitch

Experimental option which enables aggressive loop unswitching heuristic (including -enable-partial-unswitch) based on the usage of the branch conditional values. Loop unswitching leads to code-bloat. Code-bloat can be minimized if the hoisted condition is executed more often. This heuristic prioritizes the conditions based on the number of times they are used within the loop. The heuristic can be controlled with the following options:

-unswitch-identical-branches-min-count=<n>

#### AMD ROCm™ Compiler Reference Guide

Enables unswitching of a loop with respect to a branch conditional value (B), where B appears in at least <n> compares in the loop. This option is enabled with -aggressive-loop-unswitch. The default value is 3.

Usage: -mllvm -aggressive-loop-unswitch -mllvm -unswitch-identicalbranches-min-count=<n>

Where,  $\mathbf{n}$  is a positive integer and lower value of  $\langle \mathbf{n} \rangle$  facilitates more unswitching.

#### o -unswitch-identical-branches-max-count=<n>

Enables unswitching of a loop with respect to a branch conditional value (B), where B appears in at most  $\langle n \rangle$  compares in the loop. This option is enabled with -aggressive-loop-unswitch. The default value is 6.

Usage: -mllvm -aggressive-loop-unswitch -mllvm -unswitch-identicalbranches-max-count=<n>

Where,  $\mathbf{n}$  is a positive integer and higher value of  $\langle \mathbf{n} \rangle$  facilitates more unswitching.

**NOTE:** These options may facilitate more unswitching in some of the workloads. Since, loop-unswitching inherently leads to code-bloat, facilitating more unswitching may significantly increase the code size. Hence, it may also lead to longer compilation times.

#### 2.4.3 -enable-strided-vectorization

Enables strided memory vectorization as an enhancement to the interleaved vectorization framework present in LLVM. It enables the effective use of gather and scatter kind of instruction patterns. This flag must be used along with the interleave vectorization flag.

#### 2.4.4 -enable-epilog-vectorization

Enables vectorization of epilog-iterations as an enhancement to existing vectorization framework. This enables generation of an additional epilog vector loop version for the remainder iterations of the original vector loop. The vector size or factor of the original loop should be large enough to allow an effective epilog vectorization of the remaining iterations. This optimization takes place only when the original vector loop is vectorized with a vector width or factor of sixteen. This vectorization width of sixteen may be overwritten by -min-width-epilog-vectorization command line option.

#### 2.4.5 -enable-redundant-movs

Removes any redundant mov operations including redundant loads from memory and stores to memory. This can be invoked using -Wl,-plugin-opt=-enable-redundant-movs.

#### 2.4.6 -merge-constant

Attempts to promote frequently occurring constants to registers. The aim is to reduce the size of the instruction encoding for instructions using constants and obtain a performance improvement.

#### **2.4.7** -function-specialize

Optimizes the functions with compile time constant formal arguments.

#### 2.4.8 -lv-function-specialization

Generates specialized function versions when the loops inside function are vectorizable and the arguments are not aliased with each other.

#### 2.4.9 -enable-vectorize-compares

Enables vectorization on certain loops with conditional breaks assuming the memory access are safely bound within the page boundary.

#### **2.4.10** -inline-recursion=[1,2,3,4]

Enables inlining for recursive functions based on heuristics with level 4 being most aggressive. The default level will be 2. Higher levels may lead to code-bloat due to expansion of recursive functions at call sites.

- o For level 1-2: Enables inlining for recursive functions using heuristics with inline depth 1. Level 2 uses more aggressive heuristics.
- o For level 3: Enables inlining for all recursive functions with inline depth 1.
- o For level 4: Enables inlining for all recursive function with inline depth 10.

This is more effective with flto as the whole program analysis is required to perform this optimization, which can be invoked as -flto -inline-recursion=[1,2,3,4].

#### 2.4.11 -reduce-array-computations=[1,2,3]

Performs array dataflow analysis and optimizes the unused array computations.

- o **reduce-array-computations=1**: Eliminates the computations on unused array elements.
- o **reduce-array-computations=2**: Eliminates the computations on zero valued array elements.
- o **reduce-array-computations=3**: Eliminates the computations on unused and zero valued array elements (combination of 1 and 2).

1.0 Rev. 1027 October 2021

AMD ROCm™ Compiler Reference Guide

This optimization is effective with flto as the whole program analysis is required to perform this optimization, which can be invoked as -flto -reduce-array-computations=[1,2,3].

#### 2.4.12 -global-vectorize-slp={true,false}

Vectorizes the straight-line code inside a basic block with data reordering vector operations. This option is set to **true** by default.

#### 2.4.13 -region-vectorize

Experimental flag for enabling vectorization on certain loops with complex control flow which the normal vectorizer cannot handle.

This optimization is effective with *flto* as the whole program analysis is required to perform this optimization, which can be invoked as -flto -region-vectorize.

#### 2.4.14 -enable-X86-prefetching

Enables the generation of x86 prefetch instruction for the memory references inside a loop/inside an inner most loop of a loop nest to prefetch the second dimension of multidimensional array/memory references in the inner most of a loop nest. This is an experimental pass; its profitability is being improved.

#### 2.4.15 -suppress-fmas

Identifies the reduction patterns on FMA and suppresses the FMA generation as it is not profitable on the reduction patterns.

#### 2.4.16 -enable-licm-vrp

Enables estimation of the virtual register pressure before performing loop invariant code motion. This estimation is used to control the number of loop invariants that will be hoisted during the loop invariant code motion.

#### 2.4.17 -loop-splitting

Enables splitting of loops into multiple loops to eliminate the branches, which compare the loop induction with an invariant or constant expression. This option is enabled under -03 by default. To disable this optimization, use -loop-splitting=false.

### 2.4.18 -enable-ipo-loop-split

Enables splitting of loops into multiple loops to eliminate the branches, which compares the loop induction with a constant expression. This constant expression can be derived through inter-

procedural analysis. This option is enabled under -03 by default. To disable this optimization, use -enable-ipo-loop-split=false.

#### 2.4.19 -compute-interchange-order

Enables heuristic for finding the best possible interchange order for a loop nest. To enable this option, use -enable-loopinterchange. This option is set to **false** by default.

 ${f Usage:}$  -mllvm -enable-loopinterchange -mllvm -compute-interchange-order

#### **2.4.20** -convert-pow-exp-to-int={true,false}

Converts the call to floating point exponent version of pow to its integer exponent version if the floating-point exponent can be converted to integer. This option is set to **true** by default.

#### **2.4.21** -do-block-reordering={none,normal,aggressive}

Reorders the control predicates in increasing order of complexity from outer predicate to inner when it is safe. The **normal** mode reorders simple expressions while the **aggressive** mode will reorder predicates involving function calls if it can determine that they have no side-effects. This option is set to **normal** by default.

#### 2.4.22 -fuse-tile-inner-loop

Enables fusion of adjacent tiled loops as a part of loop tiling transformation. This option is set to **false** by default.

### **2.4.23** -Hz,1,0x1 [Fortran]

[Fortran] Helps to preserve array index information for array access expressions which get linearized in the compiler frontend. The preserved information is used by the compiler optimization phase in performing optimizations such as loop transformations. It is recommended that any user who is using optimizations such as loop transformations and other optimizations requiring de-linearized index expressions should use the Hz option. This option has no impact on any other aspects of the Flang frontend.

# 2.5 **GPU Compilation**

This table provides the most commonly-used compiler options for GPU code.

-x hip	Compiles the source file as a HIP program
-fopenmp	Enables the OpenMP support
-fopenmp-targets= <gpu></gpu>	Enables the OpenMP target offload support of the specified GPU architecture
gpu-max-threads-per-block= <value></value>	Set default launch bounds for kernels
-munsafe-fp-atomics	Enable unsafe floating point atomic instructions (AMDGPU only)
-ffast-math	Allow aggressive, lossy floating-point optimizations
-mwavefrontsize64/-mno-wavefrontsize64	Set wavefront size to be 64 or 32 on Navi architectures
-mcumode	Switch between CU and WGP modes on Navi architectures
offload-arch= <gpu></gpu>	HIP offloading target ID in the form of a device architecture followed by target ID features delimited by a colon. Each target ID feature is a pre-defined string followed by a plus or minus sign (e.g. gfx908:xnack+:sramecc-). May be specified more than once.
-g	Generate source-level debug information
-fgpu-rdc/-fno-gpu-rdc	Generate relocatable device code, also known as separate compilation mode

# Chapter 3 Appendix A

# 3.1 Supported Status of Other Clang Options

Option	Support	Description
-###	Supported	Print (but do not run) the commands to run for this compilation
analyzer-output <value></value>	Supported	Static analyzer report output format (html\ plist\ plist-multi-file\ plist-html\ sarif\ text).
analyze	Supported	Run the static analyzer
-arcmt-migrate-emit- errors	Unsupported	Emit ARC errors even if the migrator can fix them
-arcmt-migrate-report- output <value></value>	Unsupported	Output path for the plist report
-byteswapio	Supported	Swap byte-order for unformatted input/output
-B <dir></dir>	Supported	Add <dir> to search path for binaries and object files used implicitly</dir>
-CC	Supported	Include comments from within macros in preprocessed output
-cl-denorms-are-zero	Supported	OpenCL only. Allow denormals to be flushed to zero.
-cl-fast-relaxed-math	Supported	OpenCL only. Sets -cl-finite-math-only and -cl-unsafe-math-optimizations, and defines _FAST_RELAXED_MATH
-cl-finite-math-only	Supported	OpenCL only. Allow floating-point optimizations that assume arguments and results are not NaNs or +-Inf.
-cl-fp32-correctly- rounded-divide-sqrt	Supported	OpenCL only. Specify that single-precision floating- point divide and sqrt used in the program source are correctly rounded.
-cl-kernel-arg-info	Supported	OpenCL only. Generate kernel argument metadata.
-cl-mad-enable	Supported	OpenCL only. Allow use of less precise MAD computations in the generated binary.
-cl-no-signed-zeros	Supported	OpenCL only. Allow use of less precise no signed zeros computations in the generated binary.
-cl-opt-disable	Supported	OpenCL only. This option disables all optimizations. By default optimizations are enabled.
-cl-single-precision- constant	Supported	OpenCL only. Treat double-precision floating-point constant as single precision constant.
-cl-std= <value></value>	Supported	OpenCL language standard to compile for.
-cl-strict-aliasing	Supported	OpenCL only. This option is added for compatibility with OpenCL 1.0.
-cl-uniform-work-group- size	Supported	OpenCL only. Defines that the global work-size be a multiple of the work-group size specified to clEnqueueNDRangeKernel

Option	Support	Description
-cl-unsafe-math-	Supported	OpenCL only. Allow unsafe floating-point optimizations.
optimizations		Also implies -cl-no-signed-zeros and -cl-mad-enable.
config <value></value>	Supported	Specifies configuration file
cuda-compile-host-device	Supported	Compile CUDA code for both host and device (default).
•		Has no effect on non-CUDA compilations.
cuda-device-only	Supported	Compile CUDA code for device only
cuda-host-only	Supported	Compile CUDA code for host only. Has no effect on
·		non-CUDA compilations.
cuda-include-	Unsupported	Include PTX for the following GPU architecture (e.g.
ptx= <value></value>	**	sm 35) or 'all'. May be specified more than once.
cuda-noopt-device-debug	Unsupported	Enable device-side debug info generation. Disables ptxas
		optimizations.
cuda-path-ignore-env	Unsupported	Ignore environment variables to detect CUDA
	**	installation
cuda-path= <value></value>	Unsupported	CUDA installation path
-cxx-isystem <directory></directory>	Supported	Add a directory to the C++ SYSTEM include search path
-C	Supported	Include comments in preprocessed output
-c	Supported	Only run preprocess, compile, and assemble steps
-dD	Supported	Print macro definitions in -E mode in addition to normal
		output
-dependency-dot <value></value>	Supported	Filename to write DOT-formatted header dependencies
1		to
-dependency-file <value></value>	Supported	Filename (or -) to write dependency output to
-dI	Supported	Print include directives in -E mode in addition to normal
	11	output
-dM	Supported	Print macro definitions in -E mode instead of normal
		output
-dsym-dir <dir></dir>	Unsupported	Directory to output dSYM's (if any) to
-D <macro></macro>	Supported	= <value> Define <macro> to <value> (or 1 if <value></value></value></macro></value>
		omitted)
-emit-ast	Supported	Emit Clang AST files for source inputs
-emit-interface-stubs	Supported	Generate Interface Stub Files.
-emit-llvm	Supported	Use the LLVM representation for assembler and object
		files
-emit-merged-ifs	Supported	Generate Interface Stub Files, emit merged text not
		binary.
emit-static-lib	Supported	Enable linker job to emit a static library.
-enable-trivial-auto-var-	Supported	Trivial automatic variable initialization to zero is only
init-zero-knowing-it-will-		here for benchmarks, it'll eventually be removed, and I'm
be-removed-from-clang		OK with that because I'm only using it to benchmark
-E	Supported	Only run the preprocessor
-fAAPCSBitfieldLoad	Unsupported	Follows the AAPCS standard that all volatile bit-field
		write generates at least one load. (ARM only).
-faddrsig	Supported	Emit an address-significance table
-faligned-allocation	Supported	Enable C++17 aligned allocation functions

Option	Support	Description
-fallow-editor-placeholders	Supported	Treat editor placeholders as valid source code
-fallow-fortran-gnu-ext	Supported	Allow Fortran GNU extensions
-fansi-escape-codes	Supported	Use ANSI escape codes for diagnostics
-fapple-kext	Unsupported	Use Apple's kernel extensions ABI
-fapple-link-rtlib	Unsupported	Force linking the clang builtins runtime library
-fapple-pragma-pack	Unsupported	Enable Apple gcc-compatible #pragma pack handling
-fapplication-extension	Unsupported	Restrict code to those available for App Extensions
-fbackslash	Supported	Treat backslash as C-style escape character
-fbasic-block-	Supported	Place each function's basic blocks in unique sections
sections= <value></value>		(ELF Only) : all \  labels \  none \  list= <file></file>
-fblocks	Supported	Enable the 'blocks' language feature
-fborland-extensions	Unsupported	Accept non-standard constructs supported by the Borland compiler
-fbuild-session-file= <file></file>	Supported	Use the last modification time of <file> as the build session timestamp</file>
-fbuild-session-	Supported	Time when the current build session started
timestamp= <time since<="" th=""><th></th><th></th></time>		
Epoch in seconds>		
-fbuiltin-module-map	Unsupported	Load the clang builtins module map file.
-fcall-saved-x10	Unsupported	Make the x10 register call-saved (AArch64 only)
-fcall-saved-x11	Unsupported	Make the x11 register call-saved (AArch64 only)
-fcall-saved-x12	Unsupported	Make the x12 register call-saved (AArch64 only)
-fcall-saved-x13	Unsupported	Make the x13 register call-saved (AArch64 only)
-fcall-saved-x14	Unsupported	Make the x14 register call-saved (AArch64 only)
-fcall-saved-x15	Unsupported	Make the x15 register call-saved (AArch64 only)
-fcall-saved-x18	Unsupported	Make the x18 register call-saved (AArch64 only)
-fcall-saved-x8	Unsupported	Make the x8 register call-saved (AArch64 only)
-fcall-saved-x9	Unsupported	Make the x9 register call-saved (AArch64 only)
-fcf-protection= <value></value>	Unsupported	Instrument control-flow architecture protection. Options: return, branch, full, none.
-fcf-protection	Unsupported	Enable cf-protection in 'full' mode
-fchar8_t	Supported	Enable C++ builtin type char8_t
-fclang-abi-	Supported	Attempt to match the ABI of Clang <version></version>
compat= <version></version>		
-fcolor-diagnostics	Supported	Enable colors in diagnostics
-fcomment-block-	Supported	Treat each comma separated argument in <arg> as a</arg>
commands= <arg></arg>		documentation comment block command
-fcommon	Supported	Place uninitialized global variables in a common block
-fcomplete-member-	Supported	Require member pointer base types to be complete if they
pointers		would be significant under the Microsoft ABI
-fconvergent-functions	Supported	Assume functions may be convergent
-fcoroutines-ts	Supported	Enable support for the C++ Coroutines TS
-fcoverage-mapping	Unsupported	Generate coverage mapping to enable code coverage analysis

1.0 Rev. 1027 October 2021

Option	Support	Description
-fcs-profile-	Unsupported	Generate instrumented code to collect context sensitive
generate= <directory></directory>	**	execution counts into <directory>/default.profraw</directory>
		(overridden by LLVM_PROFILE_FILE env var)
-fcs-profile-generate	Unsupported	Generate instrumented code to collect context-sensitive
		execution counts into default.profraw (overridden by
		LLVM_PROFILE_FILE env var)
-fcuda-approx-	Unsupported	Use approximate transcendental functions
transcendentals		
-fcuda-flush-denormals-to-	Supported	Flush denormal floating-point values to zero in CUDA
zero		device mode.
-fcuda-short-ptr	Unsupported	Use 32-bit pointers for accessing const/local/shared
		address spaces
-fcxx-exceptions	Supported	Enable C++ exceptions
-fdata-sections	Supported	Place each data in its section
-fdebug-compilation-dir	Supported	The compilation directory to embed in the debug info.
<value></value>		
-fdebug-default-	Supported	Default DWARF version to use, if a -g option caused
version= <value></value>		DWARF debug info to be produced
-fdebug-info-for-profiling	Supported	Emit extra debug info to make the sample profile more
		accurate
-fdebug-macro	Supported	Emit macro debug information
-fdebug-prefix-	Supported	remap file source paths in debug info
map= <value></value>	-	
-fdebug-ranges-base-	Supported	Use DWARF base address selection entries in
address	~	.debug_ranges
-fdebug-types-section	Supported	Place debug types in their section (ELF Only)
-fdeclspec	Supported	Allowdeclspec as a keyword
-fdelayed-template-parsing	Supported	Parse templated function definitions at the end of the
	G 1	translation unit
-fdelete-null-pointer-	Supported	Treat usage of null pointers as undefined behavior
checks	G 1	(default)
-fdiagnostics-absolute-	Supported	Print absolute paths in diagnostics
paths  fdiagnostics between	I In group a set a 1	Prevent optimization remarks from being output if they
-fdiagnostics-hotness- threshold= <number></number>	Unsupported	do not have at least this profile count
	Cupported	•
-fdiagnostics-parseable- fixits	Supported	Print fix-its in machine parseable form
-fdiagnostics-print-source-	Supported	Print source range spans in numeric form
range-info	Supported	1 This source range spans in numeric form
-fdiagnostics-show-hotness	Unsupported	Enable profile hotness information in diagnostic line
-fdiagnostics-show-note-	Supported	Display include stacks for diagnostic notes
include-stack	Supported	Display metade stacks for diagnostic notes
-fdiagnostics-show-option	Supported	Print option name with mappable diagnostics
-fdiagnostics-show-	Supported	Print a template comparison tree for differing templates
template-tree	Supported	1 This a complace comparison tree for differing templates
tempiate-tree		

Option	Support	Description
-fdigraphs	Supported	Enable alternative token representations '<:', ':>', '<%',
		'%>', '%:', '%:%:' (default)
-fdiscard-value-names	Supported	Discard value names in LLVM IR
-fdollars-in-identifiers	Supported	Allow '\$' in identifiers
-fdouble-square-bracket-	Supported	Enable '[[]]' attributes in all C and C++ language modes
attributes		
-fdwarf-exceptions	Unsupported	Use DWARF style exceptions
-feliminate-unused-debug-	Supported	Do not emit debug info for defined but unused types
types		
-fembed-bitcode-marker	Supported	Embed placeholder LLVM IR data as a marker
-fembed-bitcode= <option></option>	Supported	Embed LLVM bitcode (option: off, all, bitcode, marker)
-fembed-bitcode	Supported	Embed LLVM IR bitcode as data
-femit-all-decls	Supported	Emit all declarations, even if unused
-femulated-tls	Supported	Use emutls functions to access thread_local variables
-fenable-matrix	Supported	Enable matrix data type and related builtin functions
-fexceptions	Supported	Enable support for exception handling
-fexperimental-new-	Supported	Enable the experimental new constant interpreter
constant-interpreter		
-fexperimental-new-pass-	Supported	Enables an experimental new pass manager in LLVM.
manager		
-fexperimental-relative-	Supported	Use the experimental C++ class ABI for classes with
c++-abi-vtables		virtual tables
-fexperimental-strict-	Supported	Enables experimental strict floating point in LLVM.
floating-point	0 1	A11
-ffast-math	Supported	Allow aggressive, lossy floating-point optimizations
-ffile-prefix-map= <value></value>	Supported	remap file source paths in debug info and predefined
ffine queined hitfield	Commonte d	preprocessor macros
-ffine-grained-bitfield- accesses	Supported	Use separate accesses for consecutive bitfield runs with
-ffixed-form	Cumported	legal widths and alignments.  Enable fixed-form format for Fortran
-ffixed-point	Supported Supported	Enable fixed point types
-ffixed-r19	Unsupported	Reserve register r19 (Hexagon only)
-ffixed-r9	Unsupported	Reserve the r9 register (ARM only)
-ffixed-x10	Unsupported	Reserve the x10 register (AArch64/RISC-V only)
-ffixed-x11	Unsupported	Reserve the x11 register (AArch64/RISC-V only)
-ffixed-x12	Unsupported	Reserve the x12 register (AArch64/RISC-V only)
-ffixed-x13	Unsupported	Reserve the x13 register (AArch64/RISC-V only)
-ffixed-x14	Unsupported	Reserve the x14 register (AArch64/RISC-V only)
-ffixed-x15	Unsupported	Reserve the x15 register (AArch64/RISC-V only)
-ffixed-x16	Unsupported	Reserve the x16 register (AArch64/RISC-V only)
-ffixed-x17	Unsupported	Reserve the x17 register (AArch64/RISC-V only)
-ffixed-x18	Unsupported	Reserve the x18 register (AArch64/RISC-V only)
-ffixed-x19	Unsupported	Reserve the x19 register (AArch64/RISC-V only)
-ffixed-x1	Unsupported	Reserve the x1 register (AArch64/RISC-V only)
-ffixed-x20	Unsupported	Reserve the x20 register (AArch64/RISC-V only)
	2 appoited	, (In the first voing)

OptionSupportDescription-ffixed-x21UnsupportedReserve the x21 register (AArch64/RISC-V only)-ffixed-x22UnsupportedReserve the x22 register (AArch64/RISC-V only)-ffixed-x23UnsupportedReserve the x23 register (AArch64/RISC-V only)-ffixed-x24UnsupportedReserve the x24 register (AArch64/RISC-V only)-ffixed-x25UnsupportedReserve the x25 register (AArch64/RISC-V only)-ffixed-x26UnsupportedReserve the x26 register (AArch64/RISC-V only)-ffixed-x27UnsupportedReserve the x27 register (AArch64/RISC-V only)-ffixed-x28UnsupportedReserve the x28 register (AArch64/RISC-V only)-ffixed-x29UnsupportedReserve the x29 register (AArch64/RISC-V only)-ffixed-x2UnsupportedReserve the x2 register (AArch64/RISC-V only)-ffixed-x30UnsupportedReserve the x30 register (AArch64/RISC-V only)-ffixed-x31UnsupportedReserve the x31 register (AArch64/RISC-V only)
-ffixed-x22UnsupportedReserve the x22 register (AArch64/RISC-V only)-ffixed-x23UnsupportedReserve the x23 register (AArch64/RISC-V only)-ffixed-x24UnsupportedReserve the x24 register (AArch64/RISC-V only)-ffixed-x25UnsupportedReserve the x25 register (AArch64/RISC-V only)-ffixed-x26UnsupportedReserve the x26 register (AArch64/RISC-V only)-ffixed-x27UnsupportedReserve the x27 register (AArch64/RISC-V only)-ffixed-x28UnsupportedReserve the x28 register (AArch64/RISC-V only)-ffixed-x29UnsupportedReserve the x29 register (AArch64/RISC-V only)-ffixed-x2UnsupportedReserve the x2 register (AArch64/RISC-V only)-ffixed-x30UnsupportedReserve the x30 register (AArch64/RISC-V only)
-ffixed-x23UnsupportedReserve the x23 register (AArch64/RISC-V only)-ffixed-x24UnsupportedReserve the x24 register (AArch64/RISC-V only)-ffixed-x25UnsupportedReserve the x25 register (AArch64/RISC-V only)-ffixed-x26UnsupportedReserve the x26 register (AArch64/RISC-V only)-ffixed-x27UnsupportedReserve the x27 register (AArch64/RISC-V only)-ffixed-x28UnsupportedReserve the x28 register (AArch64/RISC-V only)-ffixed-x29UnsupportedReserve the x29 register (AArch64/RISC-V only)-ffixed-x2UnsupportedReserve the x2 register (AArch64/RISC-V only)-ffixed-x30UnsupportedReserve the x30 register (AArch64/RISC-V only)
-ffixed-x24UnsupportedReserve the x24 register (AArch64/RISC-V only)-ffixed-x25UnsupportedReserve the x25 register (AArch64/RISC-V only)-ffixed-x26UnsupportedReserve the x26 register (AArch64/RISC-V only)-ffixed-x27UnsupportedReserve the x27 register (AArch64/RISC-V only)-ffixed-x28UnsupportedReserve the x28 register (AArch64/RISC-V only)-ffixed-x29UnsupportedReserve the x29 register (AArch64/RISC-V only)-ffixed-x2UnsupportedReserve the x2 register (AArch64/RISC-V only)-ffixed-x30UnsupportedReserve the x30 register (AArch64/RISC-V only)
-ffixed-x25UnsupportedReserve the x25 register (AArch64/RISC-V only)-ffixed-x26UnsupportedReserve the x26 register (AArch64/RISC-V only)-ffixed-x27UnsupportedReserve the x27 register (AArch64/RISC-V only)-ffixed-x28UnsupportedReserve the x28 register (AArch64/RISC-V only)-ffixed-x29UnsupportedReserve the x29 register (AArch64/RISC-V only)-ffixed-x2UnsupportedReserve the x2 register (AArch64/RISC-V only)-ffixed-x30UnsupportedReserve the x30 register (AArch64/RISC-V only)
-ffixed-x26UnsupportedReserve the x26 register (AArch64/RISC-V only)-ffixed-x27UnsupportedReserve the x27 register (AArch64/RISC-V only)-ffixed-x28UnsupportedReserve the x28 register (AArch64/RISC-V only)-ffixed-x29UnsupportedReserve the x29 register (AArch64/RISC-V only)-ffixed-x2UnsupportedReserve the x2 register (AArch64/RISC-V only)-ffixed-x30UnsupportedReserve the x30 register (AArch64/RISC-V only)
-ffixed-x27UnsupportedReserve the x27 register (AArch64/RISC-V only)-ffixed-x28UnsupportedReserve the x28 register (AArch64/RISC-V only)-ffixed-x29UnsupportedReserve the x29 register (AArch64/RISC-V only)-ffixed-x2UnsupportedReserve the x2 register (AArch64/RISC-V only)-ffixed-x30UnsupportedReserve the x30 register (AArch64/RISC-V only)
-ffixed-x28UnsupportedReserve the x28 register (AArch64/RISC-V only)-ffixed-x29UnsupportedReserve the x29 register (AArch64/RISC-V only)-ffixed-x2UnsupportedReserve the x2 register (AArch64/RISC-V only)-ffixed-x30UnsupportedReserve the x30 register (AArch64/RISC-V only)
-ffixed-x29UnsupportedReserve the x29 register (AArch64/RISC-V only)-ffixed-x2UnsupportedReserve the x2 register (AArch64/RISC-V only)-ffixed-x30UnsupportedReserve the x30 register (AArch64/RISC-V only)
-ffixed-x2UnsupportedReserve the x2 register (AArch64/RISC-V only)-ffixed-x30UnsupportedReserve the x30 register (AArch64/RISC-V only)
-ffixed-x30 Unsupported Reserve the x30 register (AArch64/RISC-V only)
-ffixed-x5 Unsupported Reserve the x5 register (AArch64/RISC-V only)
-ffixed-x6 Unsupported Reserve the x6 register (AArch64/RISC-V only)
-ffixed-x7 Unsupported Reserve the x7 register (AArch64/RISC-V only)
-ffixed-x8 Unsupported Reserve the x8 register (AArch64/RISC-V only)
-ffixed-x9 Unsupported Reserve the x9 register (AArch64/RISC-V only)
-fforce-dwarf-frame Supported Always emit a debug frame section
-fforce-emit-vtables Supported Emits more virtual tables to improve devirtualization
-fforce-enable-int128 Supported Enable support for int128_t type
-ffp-contract= <value> Supported Form fused FP ops (e.g. FMAs): fast (everywhere) \  on</value>
(according to FP_CONTRACT pragma) \  off (never
fuse). Default is 'fast' for CUDA/HIP and 'on' otherwise
-ffp-exception- Supported Specifies the exception behavior of floating-point
behavior= <value> operations.</value>
-ffp-model= <value> Supported Controls the semantics of floating-point calculations.</value>
-ffree-form Supported Enable free-form format for Fortran
-ffreestanding Supported Assert that the compilation takes place in a freestanding environment
<b>-ffunc-args-alias</b> Supported Function argument may alias (equivalent to ansi alias)
-ffunction-sections Supported Place each function in its section
-fglobal-isel Supported Enables the global instruction selector
-fgnu-keywords Supported Allow GNU-extension keywords regardless of a
language standard
<b>-fgnu-runtime</b> Unsupported Generate output compatible with the standard GNU Objective-C runtime
<b>-fgnu89-inline</b> Unsupported Use the gnu89 inline semantics
-fgnuc-version= <value> Supported Sets various macros to claim compatibility with the give</value>
GCC version (default is 4.2.1)
-fgpu-allow-device-init Supported Allow device-side init function in HIP
<b>-fgpu-rdc</b> Supported Generate relocatable device code, also known as separa
compilation mode
-fhip-new-launch-api Supported Use new kernel launching API for HIP

Option	Support	Description
-fignore-exceptions	Supported	Enable support for ignoring exception handling
	11	constructs
-fimplicit-module-maps	Unsupported	Implicitly search the file system for module map files.
-finline-functions	Supported	Inline suitable functions
-finline-hint-functions	Supported	Inline functions that are (explicitly or implicitly) marked
		inline
-finstrument-function-	Unsupported	Instrument function entry only, after inlining, without
entry-bare		arguments to the instrumentation call
-finstrument-functions-	Unsupported	Like -finstrument-functions, but insert the calls after
after-inlining		inlining
-finstrument-functions	Unsupported	Generate calls to instrument function entry and exit
-fintegrated-as	Supported	Enable the integrated assembler
-fintegrated-cc1	Supported	Run cc1 in-process
-fjump-tables	Supported	Use jump tables for lowering switches
-fkeep-static-consts	Supported	Keep static const variables if unused
-flax-vector-	Supported	Enable implicit vector bit-casts
conversions= <value></value>		
-flto-jobs= <value></value>	Unsupported	Controls the backend parallelism of -flto=thin (default of
		0 means the number of threads will be derived from the
		number of CPUs detected)
-flto= <value></value>	Unsupported	Set LTO mode to either 'full' or 'thin'
-flto	Unsupported	Enable LTO in 'full' mode
-fmacro-prefix-	Supported	remap file source paths in predefined preprocessor
map= <value></value>		macros
-fmath-errno	Supported	Require math functions to indicate errors by setting errno
-fmax-tokens= <value></value>	Supported	Max total number of preprocessed tokens for -Wmax-
	~ 1	tokens.
-fmax-type-align= <value></value>	Supported	Specify the maximum alignment to enforce on pointers
a m	G . 1	lacking an explicit alignment
-fmemory-profile	Supported	Enable heap memory profiling
-fmerge-all-constants	Supported	Allow merging of constants
-fmessage-length= <value></value>	Supported	Format message diagnostics so that they fit within N
£	TT	columns
-fmodule-	Unsupported	Specify the mapping of module name to precompiled
file=[ <name>=]<file></file></name>	TT	module file, or load a module file if name is omitted.
-fmodule-map-file= <file></file>	Unsupported	Load this module map file
-fmodule-name= <name></name>	Unsupported	Specify the name of the module to build
-fmodules-cache-	Unsupported	Specify the module cache path
path= <directory></directory>	I In on a set of	Deguing dealeration of modules used within a module
-fmodules-decluse	Unsupported	Require declaration of modules used within a module
-fmodules-disable-	Unsupported	Disable validation of the diagnostic options when loading
diagnostic-validation	Ungunnantad	the module  Ignore the definition of the given macro when building
-fmodules-ignore-	Unsupported	and loading modules
macro= <value></value>		and loading modules

1.0 Rev. 1027 October 2021

Option	Support	Description
-fmodules-prune-	Unsupported	Specify the interval (in seconds) after which a module
after= <seconds></seconds>		file will be considered unused
-fmodules-prune-	Unsupported	Specify the interval (in seconds) between attempts to
interval= <seconds></seconds>		prune the module cache
-fmodules-search-all	Unsupported	Search even non-imported modules to resolve references
-fmodules-strict-decluse	Unsupported	Like -fmodules-decluse but requires all headers to be in
		modules
-fmodules-ts	Unsupported	Enable support for the C++ Modules TS
-fmodules-user-build-path	Unsupported	Specify the module user build path
<pre><directory></directory></pre>	C	W.1: 1.4. DCM :t Cl 1 tt 'Ct'
-fmodules-validate-input- files-content	Supported	Validate PCM input files based on content if mtime differs
-fmodules-validate-once-	Unsupported	Don't verify input files for the modules if the module has
per-build-session	Offsupported	been successfully validated or loaded during this build
per bunu-session		session
-fmodules-validate-system-	Supported	Validate the system headers that a module depends on
headers		when loading the module
-fmodules	Unsupported	Enable the 'modules' language feature
-fms-compatibility-	Supported	Dot-separated value representing the Microsoft compiler
version= <value></value>		version number to report in _MSC_VER (0 = don't
		define it (default))
-fms-compatibility	Supported	Enable full Microsoft Visual C++ compatibility
-fms-extensions	Supported	Accept some non-standard constructs supported by the
		Microsoft compiler
-fmsc-version= <value></value>	Supported	Microsoft compiler version number to report in
e l'	C 1	MSC_VER (0 = don't define it (default))
-fnew-alignment= <align></align>	Supported	Specifies the largest alignment guaranteed by '::operator
-fno-addrsig	Supported	new(size_t)'  Don't emit an address-significance table
-fno-allow-fortran-gnu-ext	Supported	Allow Fortran GNU extensions
-fno-assume-sane-	Supported	Don't assume that C++'s global operator new can't alias
operator-new	Supported	any pointer
-fno-autolink	Supported	Disable generation of linker directives for automatic
	Tr	library linking
-fno-backslash	Supported	Treat backslash like any other character in character
		strings
-fno-builtin- <value></value>	Supported	Disable implicit builtin knowledge of a specific function
-fno-builtin	Supported	Disable implicit builtin knowledge of functions
-fno-c++-static-destructors	Supported	Disable C++ static destructor registration
-fno-char8_t	Supported	Disable C++ builtin type char8_t
-fno-color-diagnostics	Supported	Disable colors in diagnostics
-fno-common	Supported	Compile common globals like normal definitions
-fno-complete-member-	Supported	Do not require member pointer base types to be complete
pointers	G 1	if they would be significant under the Microsoft ABI
-fno-constant-cfstrings	Supported	Disable creation of CodeFoundation-type constant strings
-fno-coverage-mapping	Supported	Disable code coverage analysis

Option	Support	Description
-fno-crash-diagnostics	Supported	Disable auto-generation of preprocessed source files and
8	11	a script for reproduction during a clang crash
-fno-cuda-approx-	Unsupported	Don't use approximate transcendental functions
transcendentals	**	**
-fno-debug-macro	Supported	Do not emit macro debug information
-fno-declspec	Unsupported	Disallow declspec as a keyword
-fno-delayed-template-	Supported	Disable delayed template parsing
parsing		
-fno-delete-null-pointer-	Supported	Do not treat usage of null pointers as undefined behavior
checks		
-fno-diagnostics-fixit-info	Supported	Do not include fixit information in diagnostics
-fno-digraphs	Supported	Disallow alternative token representations '<:', ':>', '<%',
		1%>', '%:', '%:%:'
-fno-discard-value-names	Supported	Do not discard value names in LLVM IR
-fno-dollars-in-identifiers	Supported	Disallow '\$' in identifiers
-fno-double-square-	Supported	Disable '[[]]' attributes in all C and C++ language modes
bracket-attributes	C 1	D: 11 C
-fno-elide-constructors	Supported	Disable C++ copy constructor elision
-fno-elide-type	Supported	Do not elide types when printing diagnostics
-fno-eliminate-unused-	Supported	Emit debug info for defined but unused types
debug-types	C	Distallar manuscrat for a consention to a 11' as
-fno-exceptions	Supported	Disable support for exception handling
-fno-experimental-new- pass-manager	Supported	Disables an experimental new pass manager in LLVM.
-fno-experimental-relative-	Supported	Do not use the experimental C++ class ABI for classes
c++-abi-vtables	Supported	with virtual tables
-fno-fine-grained-bitfield-	Supported	Use large-integer access for consecutive bitfield runs.
accesses	Supported	ose large integer access for consecutive ordinera rans.
-fno-fixed-form	Supported	Disable fixed-form format for Fortran
-fno-fixed-point	Supported	Disable fixed point types
-fno-force-enable-int128	Supported	Disable support for int128 t type
-fno-fortran-main	Supported	Don't link in Fortran main
-fno-free-form	Supported	Disable free-form format for Fortran
-fno-func-args-alias	Supported	Function argument may alias (equivalent to ansi alias)
-fno-global-isel	Supported	Disables the global instruction selector
-fno-gnu-inline-asm	Supported	Disable GNU style inline asm
-fno-gpu-allow-device-init	Supported	Don't allow device-side init function in HIP
-fno-hip-new-launch-api	Supported	Don't use new kernel launching API for HIP
-fno-integrated-as	Supported	Disable the integrated assembler
-fno-integrated-cc1	Supported	Spawn a separate process for each cc1
-fno-jump-tables	Supported	Do not use jump tables for lowering switches
-fno-keep-static-consts	Supported	Don't keep static const variables if unused
-fno-lto	Supported	Disable LTO mode (default)
-fno-memory-profile	Supported	Disable heap memory profiling
-fno-merge-all-constants	Supported	Disallow merging of constants

Option	Support	Description
-fno-no-access-control	Supported	Disable C++ access control
-fno-objc-infer-related-	Supported	do not infer Objective-C related result type based on
result-type		method family
-fno-operator-names	Supported	Do not treat C++ operator name keywords as synonyms
		for operators
-fno-pch-codegen	Supported	Do not generate code for uses of this PCH that assumes
		an explicit object file will be built for the PCH
-fno-pch-debuginfo	Supported	Do not generate debug info for types in an object file
		built from this PCH and do not generate them elsewhere
-fno-plt	Supported	Use GOT indirection instead of PLT to make external
	-	function calls (x86 only)
-fno-preserve-as-comments	Supported	Do not preserve comments in inline assembly
-fno-profile-generate	Supported	Disable generation of profile instrumentation.
-fno-profile-instr-generate	Supported	Disable generation of profile instrumentation.
-fno-profile-instr-use	Supported	Disable using instrumentation data for profile-guided
	C 1	optimization 1111
-fno-register-global-dtors- with-atexit	Supported	Don't use atexit orcxa_atexit to register global destructors
	Commonte d	
-fno-rtlib-add-rpath	Supported	Do not add -rpath with architecture-specific resource directory to the linker flags
-fno-rtti-data	Supported	Disable generation of RTTI data
-fno-rtti	Supported	Disable generation of rtti information
-fno-sanitize-address-	Supported on	Disable poisoning array cookies when using custom
poison-custom-array-	Host only	operator new[] in AddressSanitizer
cookie	110st Offiy	operator new[] in AddressSamuzer
-fno-sanitize-address-use-	Supported on	Disable use-after-scope detection in AddressSanitizer
after-scope	Host only	Disable use after scope actection in readless samules
-fno-sanitize-address-use-	Supported on	Disable ODR indicator globals
odr-indicator	Host only	2 Isaacia a 2 It marraner graams
-fno-sanitize-blacklist	Supported on	Don't use blacklist file for sanitizers
	Host only	
-fno-sanitize-cfi-canonical-	Supported on	Do not make the jump table addresses canonical in the
jump-tables	Host only	symbol table
-fno-sanitize-cfi-cross-dso	Supported on	Disable control flow integrity (CFI) checks for cross-
	Host only	DSO calls.
-fno-sanitize-	Supported on	Disable specified features of coverage instrumentation
coverage= <value></value>	Host only	for Sanitizers
-fno-sanitize-memory-	Supported on	Disable origins tracking in MemorySanitizer
track-origins	Host only	D: 11
-fno-sanitize-memory-use-	Supported on	Disable use-after-destroy detection in MemorySanitizer
after-dtor	Host only	Disable manager for the life
-fno-sanitize-	Supported on	Disable recovery for specified sanitizers
recover= <value></value>	Host only	Disable conitizer statistics authoring
-fno-sanitize-stats	Supported on	Disable sanitizer statistics gathering.
	Host only	

Option	Support	Description
-fno-sanitize-thread-	Supported on	Disable atomic operations instrumentation in
atomics	Host only	ThreadSanitizer
-fno-sanitize-thread-func-	Supported on	Disable function entry/exit instrumentation in
entry-exit	Host only	ThreadSanitizer
-fno-sanitize-thread-	Supported on	Disable memory access instrumentation in
memory-access	Host only	ThreadSanitizer
-fno-sanitize-trap= <value></value>	Supported on Host only	Disable trapping for specified sanitizers
-fno-sanitize-trap	Supported on Host only	Disable trapping for all sanitizers
-fno-short-wchar	Supported	Force wchar t to be an unsigned int
-fno-show-column	Supported	Do not include column number on diagnostics
-fno-show-source-location	Supported	Do not include source location information with
	11	diagnostics
-fno-signed-char	Supported	char is unsigned
-fno-signed-zeros	Supported	Allow optimizations that ignore the sign of floating point zeros
-fno-spell-checking	Supported	Disable spell-checking
-fno-split-machine-	Supported	Disable late function splitting using profile information
functions		(x86 ELF)
-fno-stack-clash-protection	Supported	Disable stack clash protection
-fno-stack-protector	Supported	Disable the use of stack protectors
-fno-standalone-debug	Supported	Limit debug information produced to reduce size of debug binary
-fno-strict-float-cast- overflow	Supported	Relax language rules and try to match the behavior of the target's native float-to-int conversion instructions
-fno-strict-return	Supported	Don't treat control flow paths that fall off the end of a non-void function as unreachable
-fno-sycl	Unsupported	Disable SYCL kernels compilation for device
-fno-temp-file	Supported	Directly create compilation output files. This may lead to
_		incorrect incremental builds if the compiler crashes
-fno-threadsafe-statics	Supported	Do not emit code to make initialization of local statics thread safe
-fno-trigraphs	Supported	Do not process trigraph sequences
-fno-unique-section-names	Supported	Don't use unique names for text and data sections
-fno-unroll-loops	Supported	Turn off loop unroller
-fno-use-cxa-atexit	Supported	Don't usecxa_atexit for calling destructors
-fno-use-flang-math-libs	Supported	Use Flang internal runtime math library instead of
fno uso init armay	Supported	LLVM math intrinsics.
-fno-use-init-array -fno-visibility-inlines-	Supported Supported	Use .ctors/.dtors instead of .init_array/.fini_array  Disables fvisibility inlines hidden static local var (this
hidden-static-local-var	Supported	Disables -fvisibility-inlines-hidden-static-local-var (this is the default on non-darwin targets)
-fno-xray-function-index	Unsupported	Omit function index section at the expense of single-
-1110-x1 ay-1uncuon-mucx	Onsupported	function patching performance
-fno-zero-initialized-in-bss	Supported	Don't place zero initialized data in BSS
		F

1.0 Rev. 1027 October 2021

Option	Support	Description
-fobjc-arc-exceptions	Unsupported	Use EH-safe code when synthesizing retains and releases
		in -fobjc-arc
-fobjc-arc	Unsupported	Synthesize retain and release calls for Objective-C
		pointers
-fobjc-exceptions	Unsupported	Enable Objective-C exceptions
-fobjc-runtime= <value></value>	Unsupported	Specify the target Objective-C runtime kind and version
-fobjc-weak	Unsupported	Enable ARC-style weak references in Objective-C
-fopenmp-simd	Unsupported	Emit OpenMP code only for SIMD-based constructs.
-fopenmp-targets= <value></value>	Unsupported	Specify a comma-separated list of triples OpenMP
		offloading targets to be supported
-fopenmp	Unsupported	Parse OpenMP pragmas and generate parallel code.
-foptimization-record-	Supported	Specify the output name of the file containing the
file= <file></file>		optimization remarks. Implies -fsave-optimization-
		record. On Darwin platforms, this cannot be used with
fortiningtion wood	Carrage and a d	multiple -arch <arch> options.</arch>
-foptimization-record-	Supported	Only include passes that match a specified regular expression in the generated optimization record (by
passes= <regex></regex>		default, include all passes)
-forder-file-	Supported	Generate instrumented code to collect order file into
instrumentation	Supported	default.profraw file (overridden by '=' form of option or
instrumentation		LLVM PROFILE FILE env var)
-fpack-struct= <value></value>	Unsupported	Specify the default maximum struct packing alignment
-fpascal-strings	Supported	Recognize and construct Pascal-style string literals
-fpass-plugin= <dsopath></dsopath>	Supported	Load pass plugin from a dynamic shared object file (only
-Fund broden marking		with new pass manager).
-fpatchable-function-	Supported	Generate M NOPs before function entry and N-M NOPs
entry= <n,m></n,m>		after function entry
-fpcc-struct-return	Unsupported	Override the default ABI to return all structs on the stack
-fpch-codegen	Supported	Generate code for uses of this PCH that assumes an
		explicit object file will be built for the PCH
-fpch-debuginfo	Supported	Generate debug info for types in an object file built from
		this PCH and do not generate them elsewhere
-fpch-instantiate-templates	Supported	Instantiate templates already while building a PCH
-fpch-validate-input-files-	Supported	Validate PCH input files based on content if mtime
content	G 1	differs
-fplugin= <dsopath></dsopath>	Supported	Load the named plugin (dynamic shared object)
-fprebuilt-module-	Unsupported	Specify the prebuilt module path
path= <directory></directory>	TT	T
-fprofile-exclude- files= <value></value>	Unsupported	Instrument only functions from files where names don't
	I Ingrangata 1	match all the regexes separated by a semi-colon
-fprofile-filter- files= <value></value>	Unsupported	Instrument only functions from files where names match any regex separated by a semi-colon
-fprofile-	Unsupported	Generate instrumented code to collect execution counts
generate= <directory></directory>	Offsupported	into <directory>/default.profraw (overridden by</directory>
generate— suit ector y		LLVM PROFILE FILE env var)
		DD VIVI_I ROT IDD_I IDD CIIV VaI)

Option Support Description  -fprofile-generate Unsupported Generate instrumented code to collect execution con into default.profraw (overridden by LLVM PROFILE FILE env var)	ınte
	amo
LIVM PROFILE FILE env var)	
<b>-fprofile-instr-</b> Unsupported Generate instrumented code to collect execution cou	ınts
generate= <file> into <file> (overridden by LLVM_PROFILE_FILE</file></file>	env
var)	
-fprofile-instr-generate Unsupported Generate instrumented code to collect execution cou	
into default.profraw file (overridden by '=' form of o	option
or LLVM_PROFILE_FILE env var)	
-fprofile-instr-use= <value> Unsupported Use instrumentation data for profile-guided optimiz</value>	
<b>-fprofile-remapping-</b> Unsupported Use the remappings described in <file> to match the</file>	e
file= <file> profile data against names in the program</file>	
-fprofile-sample-accurate Unsupported Specifies that the sample profile is accurate	
-fprofile-sample- use= <value>  Unsupported Enable sample-based profile guided optimizations</value>	
	atio
<b>-fprofile-use=<pathname></pathname></b> Unsupported Use instrumentation data for profile-guided optimiz If pathname is a directory, it reads from	auon.
spathname s a directory, it reads from spathname s a directory it reads from spathname s a directo	om
file <pre>patimame&gt;.</pre>	OIII
-freciprocal-math Supported Allow division operations to be reassociated	
-freg-struct-return  Unsupported  Override the default ABI to return small structs in	
registers	
<b>-fregister-global-dtors-</b> Supported Use atexit or exa atexit to register global destruc	tors
with-atexit	
<b>-frelaxed-template-</b> Supported Enable C++17 relaxed template argument matching	
template-args	
-freroll-loops Supported Turn on loop reroller	
-fropi Unsupported Generate read-only position independent code (ARI	M
only)	
-frtlib-add-rpath Supported Add -rpath with architecture-specific resource direct	tory
to the linker flags	
<b>-frwpi</b> Unsupported Generate read-write position independent code (AR	M
only)	
-fsanitize-address-field- Supported on Level of field padding for AddressSanitizer	
padding= <value> Host only</value>	
-fsanitize-address-globals- Supported on Enable linker dead stripping of globals in	
dead-stripping Host only Address Sanitizer  frankla poisoning array gookies when using quetom	
-fsanitize-address-poison- custom-array-cookie  Supported on Enable poisoning array cookies when using custom operator new[] in AddressSanitizer	
-fsanitize-address-use- Supported on Enable use-after-scope detection in AddressSanitize	r
after-scope  Host only	/1
-fsanitize-address-use-odr- Supported on Enable ODR indicator globals to avoid false ODR	
indicator  Host only  Violation reports in partially sanitized programs at the same state of the same	ne
cost of an increase in binary size	-
<b>-fsanitize-</b> Supported on Path to blacklist file for sanitizers	
blacklist= <value> Host only</value>	

Option	Support	Description
-fsanitize-cfi-canonical-	Supported on	Make the jump table addresses canonical in the symbol
jump-tables	Host only	table
-fsanitize-cfi-cross-dso	Supported on Host only	Enable control flow integrity (CFI) checks for cross-DSO calls.
-fsanitize-cfi-icall- generalize-pointers	Supported on Host only	Generalize pointers in CFI indirect call type signature checks
-fsanitize-coverage- allowlist= <value></value>	Supported on Host only	Restrict sanitizer coverage instrumentation exclusively to modules and functions that match the provided special case list, except the blocked ones
-fsanitize-coverage- blacklist= <value></value>	Supported on Host only	Deprecated, use -fsanitize-coverage-blocklist= instead
-fsanitize-coverage- blocklist= <value></value>	Supported on Host only	Disable sanitizer coverage instrumentation for modules and functions that match the provided special case list, even the allowed ones
-fsanitize-coverage- whitelist= <value></value>	Supported on Host only	Deprecated, use -fsanitize-coverage-allowlist= instead
-fsanitize- coverage= <value></value>	Supported on Host only	Specify the type of coverage instrumentation for Sanitizers
-fsanitize-hwaddress- abi= <value></value>	Supported on Host only	Select the HWAddressSanitizer ABI to target (interceptor or platform, default interceptor). This option is currently unused.
-fsanitize-memory-track- origins= <value></value>	Supported on Host only	Enable origins tracking in MemorySanitizer
-fsanitize-memory-track- origins	Supported on Host only	Enable origins tracking in MemorySanitizer
-fsanitize-memory-use- after-dtor	Supported on Host only	Enable use-after-destroy detection in MemorySanitizer
-fsanitize-recover= <value></value>	Supported on Host only	Enable recovery for specified sanitizers
-fsanitize-stats	Supported on Host only	Enable sanitizer statistics gathering.
-fsanitize-system- blacklist= <value></value>	Supported on Host only	Path to system blacklist file for sanitizers
-fsanitize-thread-atomics	Supported on Host only	Enable atomic operations instrumentation in ThreadSanitizer (default)
-fsanitize-thread-func- entry-exit	Supported on Host only	Enable function entry/exit instrumentation in ThreadSanitizer (default)
-fsanitize-thread-memory- access	Supported on Host only	Enable memory access instrumentation in ThreadSanitizer (default)
-fsanitize-trap= <value></value>	Supported on Host only	Enable trapping for specified sanitizers
-fsanitize-trap	Supported on Host only	Enable trapping for all sanitizers
-fsanitize-undefined-strip- path- components= <number></number>	Supported on Host only	Strip (or keep only, if negative) a given number of path components when emitting check metadata.

Option	Support	Description
-fsanitize= <check></check>	Supported on	Turn on runtime checks for various forms of undefined or
	Host only	suspicious behavior. See user manual for available
		checks
-fsave-optimization-	Supported	Generate an optimization record file in a specific format
record= <format></format>		
-fsave-optimization-record	Supported	Generate a YAML optimization record file
-fseh-exceptions	Supported	Use SEH style exceptions
-fshort-enums	Supported	Allocate to an enum type only as many bytes as it needs
		for the declared range of possible values
-fshort-wchar	Unsupported	Force wchar_t to be a short unsigned int
-fshow-overloads= <value></value>	Supported	Which overload candidates to show when overload
	~ .	resolution fails: best\ all; defaults to all
-fsigned-char	Supported	char is signed
-fsized-deallocation	Supported	Enable C++14 sized global deallocation functions
-fsjlj-exceptions	Supported	Use SjLj style exceptions
-fslp-vectorize	Supported	Enable the superword-level parallelism vectorization
6 10, 1 6, 10	TT . 1	passes
-fsplit-dwarf-inlining	Unsupported	Provide minimal debug info in the object/executable to
		facilitate online symbolication/stack traces in the absence
familia 140	I I	of .dwo/.dwp files when using Split DWARF
-fsplit-lto-unit	Unsupported	Enables splitting of the LTO unit
-fsplit-machine-functions	Supported	Enable late function splitting using profile information (x86 ELF)
-fstack-clash-protection	Supported	Enable stack clash protection
-fstack-protector-all	Unsupported	Enable stack crash protection  Enable stack protectors for all functions
-fstack-protector-strong	Unsupported	Enable stack protectors for some functions vulnerable to
-istack-protector-strong	Chsupported	stack smashing. Compared to -fstack-protector, this uses
		a stronger heuristic that includes functions containing
		arrays of any size (and any type), as well as any calls to
		alloca or the taking of an address from a local variable
-fstack-protector	Unsupported	Enable stack protectors for some functions vulnerable to
*	11	stack smashing. This uses a loose heuristic that considers
		functions vulnerable if they contain a char (or 8bit
		integer) array or constant sized calls to alloca, which are
		of greater size than ssp-buffer-size (default: 8 bytes). All
		variable sized calls to alloca are considered vulnerable. A
		function with a stack protector has a guard value added to
		the stack frame that is checked on function exit. The
		guard value must be positioned in the stack frame such
		that a buffer overflow from a vulnerable variable will
		overwrite the guard value before overwriting the
		function's return address. The reference stack guard value is stored in a global variable.
-fstack-size-section	Supported	Emit section containing metadata on function stack sizes
-fstandalone-debug	Supported	Emit full debug info for all types used by the program
istanuaione-uebug	Supported	Emiliarian acoug milo for an types used by the program

Option	Support	Description
-fstrict-enums	Supported	Enable optimizations based on the strict definition of an
	**	enum's value range
-fstrict-float-cast-overflow	Supported	Assume that overflowing float-to-int casts are undefined (default)
-fstrict-vtable-pointers	Supported	Enable optimizations based on the strict rules for
<b>P</b>	11	overwriting polymorphic C++ objects
-fsycl	Unsupported	Enable SYCL kernels compilation for device
-fsystem-module	u	Build this module as a system module. Only used with -
·		emit-module
-fthin-link-	Supported	Write minimized bitcode to <file> for the ThinLTO thin</file>
bitcode= <value></value>	11	link only
-fthinlto-index= <value></value>	Unsupported	Perform ThinLTO importing using the provided function summary index
-ftime-trace-	Supported	Minimum time granularity (in microseconds) traced by
granularity= <value></value>		time profiler
-ftime-trace	Supported	Turn on time profiler. Generates JSON file based on output filename.
-ftrap-function= <value></value>	Unsupported	Issue call to specified function rather than a trap
_		instruction
-ftrapv-handler= <function< th=""><th>Unsupported</th><th>Specify the function to be called on overflow</th></function<>	Unsupported	Specify the function to be called on overflow
name>		
-ftrapv	Unsupported	Trap on integer overflow
-ftrigraphs	Supported	Process trigraph sequences
-ftrivial-auto-var-init-stop-	Supported	Stop initializing trivial automatic stack variables after the
after= <value></value>		specified number of instances
-ftrivial-auto-var-	Supported	Initialize trivial automatic stack variables: uninitialized
init= <value></value>		(default) \  pattern
-funique-basic-block-	Supported	Use unique names for basic block sections (ELF Only)
section-names		
-funique-internal-linkage- names	Supported	Uniqueify Internal Linkage Symbol Names by appending the MD5 hash of the module path
-funroll-loops	Supported	Turn on loop unroller
-fuse-flang-math-libs	Supported	Use Flang internal runtime math library instead of
		LLVM math intrinsics.
-fuse-line-directives	Supported	Use #line in preprocessed output
-fvalidate-ast-input-files-	Supported	Compute and store the hash of input files used to build an
content		AST. Files with mismatching mtime's are considered
		valid if both contents is identical
-fveclib= <value></value>	Unsupported	Use the given vector functions library
-fvectorize	Unsupported	Enable the loop vectorization passes
-fverbose-asm	Supported	Generate verbose assembly output
-fvirtual-function-	Supported	Enables dead virtual function elimination optimization.
elimination		Requires -flto=full
-fvisibility-global-new-	Supported	Give global C++ operator new and delete declarations
delete-hidden		hidden visibility

Option	Support	Description
-fvisibility-inlines-hidden-	Supported	When -fvisibility-inlines-hidden is enabled, static
static-local-var		variables in inline C++ member functions will also be
		given hidden visibility by default
-fvisibility-inlines-hidden	Supported	Give inline C++ member functions hidden visibility by
		default
-fvisibility-ms-compat	Supported	Give global types 'default' visibility and global functions
•		and variables 'hidden' visibility by default
-fvisibility= <value></value>	Supported	Set the default symbol visibility for all global
_		declarations
-fwasm-exceptions	Unsupported	Use WebAssembly style exceptions
-fwhole-program-vtables	Unsupported	Enables whole-program vtable optimization. Requires -
		flto
-fwrapv	Supported	Treat signed integer overflow as two's complement
-fwritable-strings	Supported	Store string literals as writable data
-fxray-always-emit-	Unsupported	Always emit xray customevent() calls even if the
customevents	**	containing function is not always instrumented
-fxray-always-emit-	Unsupported	Always emit xray typedevent() calls even if the
typedevents		containing function is not always instrumented
-fxray-always-instrument=	Unsupported	DEPRECATED: Filename defining the whitelist for
<value></value>		imbuing the 'always instrument' XRay attribute.
-fxray-attr-list= <value></value>	Unsupported	Filename defining the list of functions/types for imbuing
		XRay attributes.
-fxray-ignore-loops	Unsupported	Don't instrument functions with loops unless they also
		meet the minimum function size
-fxray-instruction-	Unsupported	Sets the minimum function size to instrument with XRay
threshold= <value></value>		
-fxray-instrumentation-	Unsupported	Select which XRay instrumentation points to emit.
bundle= <value></value>		Options: all, none, function-entry, function-exit, function,
		custom. Default is 'all'. 'function' includes both 'function-
		entry' and 'function-exit'.
-fxray-instrument	Unsupported	Generate XRay instrumentation sleds on function entry
		and exit
-fxray-link-deps	Unsupported	Tells clang to add the link dependencies for XRay.
-fxray-modes= <value></value>	Unsupported	List of modes to link in by default into XRay
_		instrumented binaries.
-fxray-never-instrument=	Unsupported	DEPRECATED: Filename defining the whitelist for
<value></value>		imbuing the 'never instrument' XRay attribute.
-fzvector	Supported	Enable System z vector language extension
-F <value></value>	Unsupported	Add directory to framework include search path
gcc-toolchain= <value></value>	Supported	Use the gcc toolchain at the given directory
-gcodeview-ghash	Supported	Emit type record hashes in a .debug\$H section
-gcodeview	Supported	Generate CodeView debug information
-gdwarf-2	Supported	Generate source-level debug information with dwarf
		version 2
-gdwarf-3	Supported	Generate source-level debug information with dwarf
		version 3

Option	Support	Description
-gdwarf-4	Supported	Generate source-level debug information with dwarf version 4
-gdwarf-5	Supported	Generate source-level debug information with dwarf version 5
-gdwarf	Supported	Generate source-level debug information with the default dwarf version
-gembed-source	Supported	Embed source text in DWARF debug sections
-gline-directives-only	Supported	Emit debug line info directives only
-gline-tables-only	Supported	Emit debug line number tables only
-gmodules	Supported	Generate debug info with external references to clang modules or precompiled headers
-gno-embed-source	Supported	Restore the default behavior of not embedding source text in DWARF debug sections
-gno-inline-line-tables	Supported	Don't emit inline line tables
gpu-max-threads-per- block= <value></value>	Supported	Default max threads per block for kernel launch bounds for HIP
-gsplit-dwarf= <value></value>	Supported	Set DWARF fission mode to either 'split' or 'single'
-gz= <value></value>	Supported	DWARF debug sections compression type
-gz	Supported	DWARF debug sections compression type
-G <size></size>	Unsupported	Put objects of at most <size> bytes into small data section (MIPS / Hexagon)</size>
-g	Supported	Generate source-level debug information
help-hidden	Supported	Display help for hidden options
-help	Supported	Display available options
hip-device-lib= <value></value>	Supported	HIP device library
hip-link	Supported	Link clang-offload-bundler bundles for HIP
hip-version= <value></value>	Supported	HIP version in the format of major.minor.patch
-Н	Supported	Show header includes and nesting depth
-I-	Supported	Restrict all prior -I flags to double-quoted inclusion and remove the current directory from include path
-ibuiltinine	Supported	Enable builtin #include directories even when -nostdinc is used before or after -ibuiltininc. Using -nobuiltininc after the option disables it
-idirafter <value></value>	Supported	Add directory to AFTER include search path
-iframeworkwithsysroot	Unsupported	Add directory to SYSTEM framework search path,
<directory></directory>		absolute paths are relative to -isysroot
-iframework <value></value>	Unsupported	Add directory to SYSTEM framework search path
-imacros <file></file>	Supported	Include macros from file before parsing
-include-pch <file></file>	Supported	Include precompiled header file
-include <file></file>	Supported	Include file before parsing
-index-header-map	Supported	Make the next included directory (-I or -F) an indexer header map
-iprefix <dir></dir>	Supported	Set the -iwithprefix/-iwithprefixbefore prefix
-iquote <directory></directory>	Supported	Add directory to QUOTE include search path
-isysroot <dir></dir>	Supported	Set the system root directory (usually /)

Option	Support	Description
-isystem-after <directory></directory>	Supported	Add directory to end of the SYSTEM include search path
-isystem <directory></directory>	Supported	Add directory to SYSTEM include search path
-ivfsoverlay <value></value>	Supported	Overlay the virtual filesystem described by file over the real file system
-iwithprefixbefore <dir></dir>	Supported	Set directory to include search path with prefix
-iwithprefix <dir></dir>	Supported	Set directory to SYSTEM include search path with prefix
-iwithsysroot <directory></directory>	Supported	Add directory to SYSTEM include search path, absolute paths are relative to -isysroot
-I <dir></dir>	Supported	Add directory to include search path. If there are multiple -I options, these directories are searched in the order they are given before the standard system directories are searched. If the same directory is in the SYSTEM include search paths, for example, if also specified with -isystem, the -I option will be ignored
libomptarget-nvptx-	Unsupported	Path to libomptarget-nvptx libraries
path= <value></value>	a . 1	
-L <dir></dir>	Supported	Add directory to library search path
-mabicalls	Unsupported	Enable SVR4-style position-independent code (Mips only)
-maix-struct-return	Unsupported	Return all structs in memory (PPC32 only)
-malign-branch- boundary= <value></value>	Supported	Specify the boundary's size to align branches
-malign-branch= <value></value>	Supported	Specify types of branches to align
-malign-double	Supported	Align doubles to two words in structs (x86 only)
-Mallocatable= <value></value>	Unsupported	Select semantics for assignments to allocatables (F03 or F95)
-mbackchain	Unsupported	Link stack frames through backchain on System Z
-mbranch- protection= <value></value>	Unsupported	Enforce targets of indirect branches and function returns
-mbranches-within-32B- boundaries	Supported	Align selected branches (fused, jcc, jmp) within 32-byte boundary
-mcmodel=medany	Unsupported	Equivalent to -mcmodel=medium, compatible with RISC-V gcc.
-mcmodel=medlow	Unsupported	Equivalent to -mcmodel=small, compatible with RISC-V gcc.
-mcmse	Unsupported	Allow use of CMSE (Armv8-M Security Extensions)
-mcode-object-v3	Supported	Legacy option to specify code object ABI V2 (-mnocode-object-v3) or V3 (-mcode-object-v3) (AMDGPU only)
-mcode-object- version= <version></version>	Supported	Specify code object ABI version. Defaults to 4. (AMDGPU only)
-mcrc	Unsupported	Allow use of CRC instructions (ARM/Mips only)
-mcumode	Supported	Specify CU (-mcumode) or WGP (-mno-cumode) wavefront execution mode (AMDGPU only)
-mdouble= <value></value>	Supported	Force double to be 32 bits or 64 bits
-MD	Supported	Write a depfile containing user and system headers

1.0 Rev. 1027 October 2021

Option	Support	Description
-meabi <value></value>	Supported	Set EABI type, e.g. 4, 5 or gnu (default depends on
		triple)
-membedded-data	Unsupported	Place constants in the .rodata section instead of the .sdata
		section even if they meet the -G <size> threshold (MIPS)</size>
-menable-experimental-	Unsupported	Enable use of experimental RISC-V extensions.
extensions		*
-mexec-model= <value></value>	Unsupported	Execution model (WebAssembly only)
-mexecute-only	Unsupported	Disallow generation of data access to code sections
Ů		(ARM only)
-mextern-sdata	Unsupported	Assume that externally defined data is in the small data if
		it meets the -G <size> threshold (MIPS)</size>
-mfentry	Unsupported	Insert calls to fentry at function entry (x86/SystemZ
·		only)
-mfix-cortex-a53-835769	Unsupported	Workaround Cortex-A53 erratum 835769 (AArch64
	1	only)
-mfp32	Unsupported	Use 32-bit floating point registers (MIPS only)
-mfp64	Unsupported	Use 64-bit floating point registers (MIPS only)
-MF <file></file>	Supported	Write depfile output from -MMD, -MD, -MM, or -M to
		<file></file>
-mgeneral-regs-only	Unsupported	Generate code which only uses the general purpose
		registers (AArch64 only)
-mglobal-merge	Supported	Enable merging of globals
-mgpopt	Unsupported	Use GP relative accesses for symbols known to be in a
		small data section (MIPS)
-MG	Supported	Add missing headers to depfile
-mharden-sls= <value></value>	Unsupported	Select straight-line speculation hardening scope
-mhvx-length= <value></value>	Unsupported	Set Hexagon Vector Length
-mhvx= <value></value>	Unsupported	Enable Hexagon Vector eXtensions
-mhvx	Unsupported	Enable Hexagon Vector eXtensions
-miamcu	Unsupported	Use Intel MCU ABI
migrate	Unsupported	Run the migrator
-mincremental-linker-	Supported	(integrated-as) Emit an object file that can be used with
compatible		an incremental linker
-mindirect-jump= <value></value>	Unsupported	Change indirect jump instructions to inhibit speculation
-Minform= <value></value>	Supported	Set error level of messages to display
-mios-version-	Unsupported	Set iOS deployment target
min= <value></value>		
-MJ <value></value>	Unsupported	Write a compilation database entry per input
-mllvm <value></value>	Supported	Additional arguments to forward to LLVM's option
		processing
-mlocal-sdata	Unsupported	Extend the -G behavior to object local data (MIPS)
-mlong-calls	Supported	Generate branches with extended addressability, usually
		via indirect jumps.
-mlong-double-128	Supported on	Force long double to be 128 bits
	Host only	_
-mlong-double-128	* *	v 1

Option	Support	Description
-mlong-double-64	Supported	Force long double to be 64 bits
-mlong-double-80	Supported on	Force long double to be 80 bits, padded to 128 bits for
	Host only	storage
-mlvi-cfi	Supported on	Enable only control-flow mitigations for Load Value
	Host only	Injection (LVI)
-mlvi-hardening	Supported on	Enable all mitigations for Load Value Injection (LVI)
	Host only	
-mmacosx-version-	Unsupported	Set Mac OS X deployment target
min= <value></value>	~ .	
-mmadd4	Supported	Enable the generation of 4-operand madd.s, madd.d and related instructions.
-mmark-bti-property	Unsupported	Add .note.gnu.property with BTI to assembly files
		(AArch64 only)
-MMD	Supported	Write a depfile containing user headers
-mmemops	Supported	Enable generation of memop instructions
-mms-bitfields	Unsupported	Set the default structure layout to be compatible with the
	I In grown a set of	Microsoft compiler standard
-mmsa	Unsupported Unsupported	Enable MSA ASE (MIPS only)
-mmt		Enable MT ASE (MIPS only)  Like MMD but also implies. E and united to atdout by
-MM	Supported	Like -MMD, but also implies -E and writes to stdout by default
-mno-abicalls	Unsupported	Disable SVR4-style position-independent code (Mips
	T.I.,	only)
-mno-crc	Unsupported	Disallow use of CRC instructions (Mips only)
-mno-embedded-data	Unsupported	Do not place constants in the .rodata section instead of the .sdata if they meet the -G <size> threshold (MIPS)</size>
-mno-execute-only	Unsupported	Allow generation of data access to code sections (ARM only)
-mno-extern-sdata	Unsupported	Do not assume that externally defined data is in the small
mno fix coutox of 2	I In gramm ant a d	data if it meets the -G <size> threshold (MIPS)  Don't workaround Cortex-A53 erratum 835769</size>
-mno-fix-cortex-a53- 835769	Unsupported	(AArch64 only)
-mno-global-merge	Supported	Disable merging of globals
-mno-grobal-mer ge	Unsupported	Do not use GP relative accesses for symbols known to be
mno Shoht	Silsapported	in a small data section (MIPS)
-mno-hvx	Unsupported	Disable Hexagon Vector eXtensions
-mno-implicit-float	Supported	Don't generate implicit floating point instructions
-mno-incremental-linker-	Supported	(integrated-as) Emit an object file which cannot be used
compatible		with an incremental linker
-mno-local-sdata	Unsupported	Do not extend the -G behaviour to object local data (MIPS)
-mno-long-calls	Supported	Restore the default behaviour of not generating long calls
-mno-lvi-cfi	Supported on	Disable control-flow mitigations for Load Value
	Host only	Injection (LVI)
-mno-lvi-hardening	Supported on Host only	Disable mitigations for Load Value Injection (LVI)

1.0 Rev. 1027 October 2021

-mno-madd4         Supported         Disable the generation of 4-operand madd.s, madd.d and related instructions.           -mno-moremops         Supported         Disable generation of memop instructions           -mno-moremops         Supported         Disable generation of memop instructions           -mno-ms biffields         Supported         Disable we of movt/movw pairs (ARM only)           -mno-ms         Unsupported         Disable MSA ASE (MIPS only)           -mno-more-immediates         Supported         Disable we converting instructions with negative immediates to their negation or inversion.           -mno-ny         Supported         Disable generation of new-value stores           -mno-value         Disable generation of instruction with negative immediates to their negation or inversion.           -mno-restrict-it         Unsupported         Disable generation of new-value stores           -mno-restrict-it         Unsupported         Disable generation of instruction packets           -mno-save-restore         Unsupported         Disable using library calls for save and restore           -mno-stack-arg-probe <th< th=""><th>Option</th><th>Support</th><th>Description</th></th<>	Option	Support	Description
-mno-momomomomomomomomomomomomomomomomom	-		
-mno-ms-bitfields Supported Supported With the Microsoft compiler standard branch with the Microsoft compiler standard with the Microsoft compiler with			related instructions.
-mno-msa         Unsupported with the Microsoft compiler standard           -mno-mt         Unsupported           -mno-mt         Unsupported           -mno-mt         Unsupported           -mno-mt         Unsupported           -mno-me-g-immediates         Supported           -mno-nvj         Supported         Disable MT ASE (MIPS only)           -mno-nvs         Supported         Disable generation of new-value jumps           -mno-nvs         Supported         Disable generation of new-value jumps           -mno-nutine         Unsupported         Disable generation of new-value jumps           -mno-nvalume         Unsupported         Disable function outlining (AArch64 only)           -mno-mno-manuline         Unsupported         Disable generation of instruction packets           -mno-relax         Supported         Disable function outlining (AArch64 only)           -mno-relax         Supported         Disable function of prevalue stores           -mno-relax         Supported         Disable function of prevalue stores           -mno-restrict-it         Unsupported         Disable stack probable stack probable stack probable stack probable stack stack probable stack	-mno-memops	Supported	Disable generation of memop instructions
mno-msa Unsupported Disable MSA ASE (MIPS only)  -mno-mt Unsupported Disable MT ASE (MIPS only)  -mno-neg-immediates Supported Disable MT ASE (MIPS only)  -mno-neg-immediates Supported Disable MT ASE (MIPS only)  -mno-ny Supported Disable MT ASE (MIPS only)  -mno-ny Supported Disable generation of inversion.  -mno-ny Supported Disable generation of new-value jumps  -mno-ny Supported Disable function outlining (AArch64 only)  -mno-packets Supported Disable linker relaxation  -mno-restrict-it Unsupported Disable linker relaxation  -mno-save-restore Unsupported Disable using library calls for save and restore  -mno-save-restore Unsupported Disable stack probes which are enabled by default mon-tls-direct-seg-refs Supported Disable direct TLS access through segment registers  -mno-unaligned-access Unsupported Specify wavefront size 32 mode (AMDGPU only)  -mno-wavefrontsize64 Supported Specify wavefront size 32 mode (AMDGPU only)  -mno-mcount Supported Generate mcount/ fentry_calls as nops. To activate they need to be patched in.  -mnvj Supported Enable generation of new-value jumps  -mnvs Supported Enable generation of new-value into supported Directory to dump module dependencies to  -module-file-info Unsupported Unsupported Directory to dump module dependencies to  -mpacked-stack Unsupported Specify maximum number of prefixes to use for padding size='value'  -mpacked-stack Supported Specify maximum number of prefixes to use for padding size='value'  -mpacked-stack Supported Unsupported Specify maximum number of prefixes to use for padding size='value'  -mpie-copy-relocations Supported Use copy relocations support for PIE builds  -mprefer-vector-  width= <a for="" href="value" maximum="" number="" of="" padding="" prefixes="" size="value" specify="" sup<="" supported="" th="" to="" unsupported="" use=""><th>-mno-movt</th><th></th><th></th></a>	-mno-movt		
-mno-mt         Unsupported         Disable MSA ASE (MIPS only)           -mno-mt         Unsupported         Disable MT ASE (MIPS only)           -mno-neg-immediates         Supported         Disable workerting instructions with negative immediates to their negation or inversion.           -mno-nvj         Supported         Disable generation of new-value jumps           -mno-nvs         Supported         Disable generation of finew-value stores           -mno-packets         Supported         Disable generation of instruction packets           -mno-relax         Supported         Disable linker relaxation           -mno-restric-it         Unsupported         Disable linker relaxation           -mno-save-restore         Unsupported         Disable speculative and restore           -mno-seses         Unsupported         Disable speculative execution side effect suppression (SESES)           -mno-stack-arg-probe         Supported         Disable stack probes which are enabled by default           -mno-tls-direct-seg-refs         Supported         Disable direct TLS access through segment registers           -mno-wavefrontsize64         Supported         Supported (Arch32/AArch64 only)           -mnore         Supported         Supported (Arch32/AArch64 only)           -mnv         Supported         Supported (Arch32/Aarch64 only)           -	-mno-ms-bitfields	Supported	
-mno-mt         Unsupported         Disable MT ASE (MIPS only)           -mno-neg-immediates         Supported         Disablow converting instructions with negative immediates to their negation or inversion.           -mno-nvj         Supported         Disable generation of new-value jumps           -mno-nvs         Supported         Disable generation of new-value stores           -mno-packets         Supported         Disable generation of instruction packets           -mno-relax         Supported         Disable lunction outlining (AArch64 only)           -mno-restrict-it         Unsupported         Disable lunction outlining (AArch64 only)           -mno-restrict-it         Unsupported         Disable lunction outlining (AArch64 only)           -mno-save-restore         Unsupported         Disable lunction outlining (AArch64 only)           -mno-save-restore         Unsupported         Disable stack probes which are enabled by default for ARMv8. It is off by default for ARMv8. Thumb mode           -mno-save-restore         Unsupported         Disable stack probes which are enabled by default           -mno-stack-arg-probe         Supported         Disable stack probes which are enabled by default           -mno-ts-direct-seg-refs         Supported         Disable stack probes which are enabled by default           -mno-wavefrontsize64         Supported         Supported         Specify maximum f			-
-mno-neg-immediates         Supported immediates to their negation or inversion.           -mno-nvj         Supported Disable generation of new-value jumps           -mno-nvs         Supported Disable generation of new-value stores           -mno-outline         Unsupported Disable function outlining (AArch64 only)           -mno-relax         Supported Disable function outlining (AArch64 only)           -mno-restrict-it         Unsupported Disable function outlining (AArch64 only)           -mno-restrict-it         Unsupported Unsupported Disable function outlining (AArch64 only)           -mno-save-restore         Unsupported Unsupported Disable suck probes which are enabled by default is off by default for ARMv8 Thumb mode (SESES)           -mno-stack-arg-probe         Supported Disable stack probes which are enabled by default Disable stack probes which are enabled by default Disable direct TLS access through segment registers           -mno-unaligned-acces         Unsupported Unsupported Disable stack probes which are enabled by default Disable direct TLS access through segment registers           -mno-wavefrontsize64         Supported Supp		* *	
-mno-nvj         Supported         Disable generation of new-value jumps           -mno-nvs         Supported         Disable generation of new-value stores           -mno-nutine         Unsupported         Disable function outlining (AArch64 only)           -mno-packets         Supported         Disable function outlining (AArch64 only)           -mno-relax         Supported         Disable linker relaxation           -mno-restrictit         Unsupported         Allow generation of deprecated IT blocks for ARMv8. It is off by default for ARMv8 Thumb mode           -mno-save-restore         Unsupported         Disable using library calls for save and restore           -mno-stack-arg-probe         Supported         Disable speculative execution side effect suppression (SESES)           -mno-ts-direct-seg-refs         Supported         Disable stack probes which are enabled by default           -mno-ts-direct-seg-refs         Supported         Disable direct TLS access through segment registers           -mno-unaligned-access         Unsupported         Specify wavefront size 32 mode (AMDGPU only)           -mno-wavefrontsize64         Supported         Specify wavefront size 32 mode (AMDGPU only)           -mno-more         Unsupported         Generate mcount/ fentry calls as nops. To activate they need to be patched in.           -mnvj         Supported         Enable generation of new-value stores </th <th></th> <th>**</th> <th>` ,</th>		**	` ,
-mno-nvs         Supported         Disable generation of new-value stores           -mno-outline         Unsupported         Disable function outlining (AArch64 only)           -mno-packets         Supported         Disable function outlining (AArch64 only)           -mno-relax         Supported         Disable function outlining (AArch64 only)           -mno-relax         Supported         Disable speciation of instruction packets           -mno-relax         Unsupported         Allow generation of deprecated IT blocks for ARMv8. It is off by default for ARMv8 Thumb mode           -mno-save-restore         Unsupported         Disable speculative execution side effect suppression (SESES)           -mno-stack-arg-probe         Supported         Disable speculative execution side effect suppression (SESES)           -mno-stack-arg-probe         Supported         Disable speculative execution side effect suppression (SESES)           -mno-stack-arg-probe         Supported         Disable speculative execution side effect suppression (SESES)           -mno-stack-arg-probe         Supported         Disable speculative execution side effect suppression (SESES)           -mno-tls-direct-seg-refs         Supported         Disable speculative execution side effect suppression (SESES)           -mno-tls-direct-seg-refs         Supported         Disable speculative execution side effect suppression (SESES)           -mno-todu-file-info </th <th>-mno-neg-immediates</th> <th>Supported</th> <th></th>	-mno-neg-immediates	Supported	
-mno-nvs         Supported         Disable generation of new-value stores           -mno-packets         Supported         Disable function outlining (AArch64 only)           -mno-packets         Supported         Disable generation of instruction packets           -mno-relax         Supported         Disable linker relaxation           -mno-restrict-it         Unsupported         Allow generation of deprecated IT blocks for ARMv8. It is off by default for ARMv8 Thumb mode           -mno-save-restore         Unsupported         Disable using library calls for save and restore           -mno-stack-arg-probe         Supported         Disable speculative execution side effect suppression (SESES)           -mno-tls-direct-seg-refs         Supported         Disable stack probes which are enabled by default           -mno-tls-direct-seg-refs         Supported         Disable stack probes which are enabled by default           -mno-tls-direct-seg-refs         Supported         Disable stack probes which are enabled by default           -mno-maligned-access         Unsupported         Force all memory accesses to be aligned (AArch32/AArch64 only)           -mno-mover         Unsupported         Specify wavefront size 32 mode (AMDGPU only)           -mnore         Unsupported         Generate mcount/ fentry_calls as nops. To activate they need to be patched in.           -mnvj         Supported         Enable generati		G 1	
-mno-outlineUnsupportedDisable function outlining (AArch64 only)-mno-packetsSupportedDisable generation of instruction packets-mno-relaxSupportedDisable linker relaxation-mno-restrict-itUnsupportedAllow generation of deprecated IT blocks for ARMv8. It is off by default for ARMv8 Thumb mode-mno-save-restoreUnsupportedDisable using library calls for save and restore-mno-sesesUnsupportedDisable speculative execution side effect suppression (SESES)-mno-tls-direct-seg-refsSupportedDisable stack probes which are enabled by default-mno-unaligned-accessUnsupportedDisable direct TLS access through segment registers-mno-unaligned-accessUnsupportedForce all memory accesses to be aligned (AArch32/AArch64 only)-mno-wavefrontsize64SupportedSpecify wavefront size 32 mode (AMDGPU only)-mnoreUnsupportedDisallow use of CRC instructions (ARM only)-mnop-mcountSupportedGenerate mcount/_fentry_calls as nops. To activate they need to be patched inmnvjSupportedEnable generation of new-value jumps-mnvsSupportedDirectory to dump module dependencies to-moutle-dependency-dirUnsupportedDirectory to dump module dependencies to-value>UnsupportedOmit frame pointer setup for leaf functions-moutlineUnsupportedUnsupported information about a particular module file-mpacketsSupportedSpecify maximum number of prefixes to use for padding-mpacketsSupportedSpecify maximum number o			
-mno-packets         Supported         Disable generation of instruction packets           -mno-relax         Supported         Disable linker relaxation           -mno-restrict-it         Unsupported         Allow generation of deprecated IT blocks for ARMv8. It is off by default for ARMv8 Thumb mode           -mno-save-restore         Unsupported         Disable using library calls for save and restore           -mno-seses         Unsupported         Disable speculative execution side effect suppression (SESES)           -mno-tack-arg-probe         Supported         Disable direct TLS access through segment registers           -mno-unaligned-access         Unsupported         Force all memory accesses to be aligned (AArch32/AArch64 only)           -mno-wavefrontsize64         Supported         Specify wavefront size 32 mode (AMDGPU only)           -mnoer         Unsupported         Disallow use of CRC instructions (ARM only)           -mnop-mcount         Supported         Enable generation of new-value jumps           -mnvs         Supported         Enable generation of new-value stores           -moutle-dependency-dir         Unsupported         Enable generation of new-value stores           -module-file-info         Unsupported         Unsupported         Unsupported information about a particular module file           -momit-leaf-frame-pointer         Unsupported         Enable function outlin			
-mno-relaxSupportedDisable linker relaxation-mno-restrict-itUnsupportedAllow generation of deprecated IT blocks for ARMv8. It is off by default for ARMv8 Thumb mode-mno-save-restoreUnsupportedDisable using library calls for save and restore-mno-seesUnsupportedDisable speculative execution side effect suppression (SESES)-mno-tls-direct-seg-refsSupportedDisable stack probes which are enabled by default-mno-unaligned-accessUnsupportedForce all memory accesses to be aligned (AArch32/AArch64 only)-mno-wavefrontsize64SupportedSpecify wavefront size 32 mode (AMDGPU only)-mnop-mcountSupportedDisallow use of CRC instructions (ARM only)-mnop-mcountSupportedGenerate mcount/_fentry_calls as nops. To activate they need to be patched inmnvjSupportedEnable generation of new-value jumps-mnvsSupportedEnable generation of new-value stores-module-dependency-dirValue>-walueUnsupportedProvide information about a particular module file-momit-leaf-frame-pointerSupportedOmit frame pointer setup for leaf functions-mpaded-stackUnsupportedUse packed stack layout (SystemZ only)mpad-max-prefix-size=value>SupportedUse copy relocations support for PIE builds-mpie-copy-relocationsSupportedUse copy relocations support for PIE builds-mpie-copy-relocationsSupportedUse copy relocations support for PIE builds-mpie-copy-relocationsSupportedUse copy relocations support for PIE builds </th <th></th> <th></th> <th></th>			
-mno-restrict-it         Unsupported         Allow generation of deprecated IT blocks for ARMv8. It is off by default for ARMv8 Thumb mode           -mno-save-restore         Unsupported         Disable using library calls for save and restore           -mno-seses         Unsupported         Disable using library calls for save and restore           -mno-stack-arg-probe         Supported         Disable stack probes which are enabled by default           -mno-tls-direct-seg-refs         Supported         Disable direct TLS access through segment registers           -mno-unaligned-access         Unsupported         Force all memory accesses to be aligned (AArch32/AArch64 only)           -mno-wavefrontsize64         Supported         Specify wavefront size 32 mode (AMDGPU only)           -mnop-mcount         Supported         Generate mcount/_fentry_ calls as nops. To activate they need to be patched in.           -mnvj         Supported         Enable generation of new-value jumps           -module-dependency-dir         Unsupported         Directory to dump module dependencies to           -walue>         Unsupported         Provide information about a particular module file           -moutline         Unsupported         Omit frame pointer setup for leaf functions           -mpacked-stack         Unsupported         Enable generation of instruction packets           -mpackets         Supported         Enable			1
is off by default for ARMv8 Thumb mode  -mno-save-restore Unsupported Disable using library calls for save and restore  -mno-sess Unsupported Disable speculative execution side effect suppression (SESES)  -mno-stack-arg-probe Supported Disable stack probes which are enabled by default  -mno-tls-direct-seg-refs Supported Disable direct TLS access through segment registers  -mno-unaligned-access Unsupported Force all memory accesses to be aligned (AArch32/AArch64 only)  -mno-wavefrontsize64 Supported Specify wavefront size 32 mode (AMDGPU only)  -mnop-mcount Supported Generate mcount/_fentrycalls as nops. To activate they need to be patched in.  -mnvj Supported Enable generation of new-value jumps  -module-dependency-dir <value>  -module-file-info Unsupported Disable stack probes which are enabled by default  -monutine Unsupported Disable stack probes which are enabled by default  -moutine Unsupported Disable stack probes which are enabled by default  -moutine Unsupported Disable stack probes which are enabled by default  -moutine Unsupported Disable stack probes which are enabled by default  -moutine Unsupported Disable stack probes which are enabled by default  -moutine Unsupported Disable stack probes which are enabled by default  -moutine Unsupported Disable stack probes which are enabled by default  -moutine Unsupported Disable direct TLS access through segment registers  -moutine Unsupported Unsupported Disable direct TLS access through segment registers  -moutine Unsupported Disable direct TLS access through segment registers  -moutine Unsupported Disable direct TLS access through segment registers  -moutine Unsupported Disable direct TLS access through segment registers  -moutine Unsupported Unsupported Disable direct TLS access through segment registers  -moutine Unsupported Unsupported Disable direct TLS access through segment registers  -moutine Unsupported Unsupported One-value fall memory accesses to be aligned (AArch64 only)  -moutine Tustine Tustine fall memory accesses to be aligned (AArch64 onl</value>			
-mno-save-restore -mno-sesesUnsupported Unsupported Disable using library calls for save and restore-mno-stack-arg-probe -mno-tls-direct-seg-refs -mno-unaligned-accessSupported UnsupportedDisable stack probes which are enabled by default-mno-unaligned-accessUnsupported (AArch32/AArch64 only)Disable direct TLS access through segment registers-mno-unaligned-accessUnsupportedForce all memory accesses to be aligned (AArch32/AArch64 only)-mno-wavefrontsize64 -mnocrcSupportedSpecify wavefront size 32 mode (AMDGPU only)-mnop-mcountSupportedDisallow use of CRC instructions (ARM only)-mnop-mcountSupportedEnable generation of new-value jumps-mnvjSupportedEnable generation of new-value stores-module-dependency-dir <value>UnsupportedDirectory to dump module dependencies to-module-file-infoUnsupportedProvide information about a particular module file-momit-leaf-frame-pointerSupportedProvide information about a particular module file-moutlineUnsupportedProvide information about a particular module file-mpacked-stackUnsupportedUnsupportedEnable generation of instruction packets-mpacketsSupportedEnable generation of instruction packets-mpacketsSupportedSupportedSpecify maximum number of prefixes to use for padding-mpac-copy-relocationsSupportedUnsupportedUnsupported-mpie-copy-relocationsSupportedUnsupportedUnsupported-mpie-copy-relocations&lt;</value>	-mno-restrict-it	Unsupported	
-mno-stack-arg-probeSupportedDisable speculative execution side effect suppression (SESES)-mno-tls-direct-seg-refsSupportedDisable stack probes which are enabled by default-mno-unaligned-accessUnsupportedDisable direct TLS access through segment registers-mno-unaligned-accessUnsupportedForce all memory accesses to be aligned (AArch32/AArch64 only)-mno-wavefrontsize64SupportedSpecify wavefront size 32 mode (AMDGPU only)-mnop-mcountSupportedDisable wavefront size 32 mode (AMDGPU only)-mnop-mcountSupportedGenerate mount/_ fentry_ calls as nops. To activate they need to be patched inmnvjSupportedEnable generation of new-value jumps-movsSupportedEnable generation of new-value stores-module-dependency-dirUnsupportedDirectory to dump module dependencies to-value>Directory to dump module dependencies to-moutlineUnsupportedProvide information about a particular module file-moutlineUnsupportedOmit frame pointer setup for leaf functions-mpacked-stackUnsupportedEnable function outlining (AArch64 only)-mpacketsSupportedEnable generation of instruction packets-mpad-max-prefix-size= <ali>size=<ali>alue&gt;SupportedUse copy relocations support for PIE builds-mprefer-vector-width=<a>unipported</a>UnsupportedUse copy relocations support for auto-vectorization.-mprefer-vector-width=<a>unipported</a>UnsupportedCreate phony target for each dependency (other than main file)<th></th><th>TT . 1</th><th>•</th></ali></ali>		TT . 1	•
-mno-stack-arg-probe Supported Disable stack probes which are enabled by default -mno-tls-direct-seg-refs -mno-unaligned-access Unsupported (AArch32/AArch64 only) -mno-wavefrontsize64 Supported Disable direct TLS access through segment registers -mno-wavefrontsize64 Supported Specify wavefront size 32 mode (AMDGPU only) -mno-macount Supported Disable wavefront size 32 mode (AMDGPU only) -mnop-mcount Supported Generate mcount/_ fentry_ calls as nops. To activate they need to be patched inmnvj Supported Enable generation of new-value jumps -mnvs Supported Enable generation of new-value stores -module-dependency-dir <value> -module-file-info Unsupported Provide information about a particular module file -momit-leaf-frame-pointer Supported Unsupported Enable function outlining (AArch64 only) -mpacked-stack Unsupported Use packed stack layout (SystemZ only)mpackets Supported Enable generation of instruction packets -mpad-max-prefix- size=<value> -mpie-copy-relocations Supported Use copy relocations support for PIE builds -mprefer-vector- width=<value> -mpie-copy-relocations Supported Create phony target for each dependency (other than main file)</value></value></value>			
-mno-tls-direct-seg-refsSupportedDisable direct TLS access through segment registers-mno-unaligned-accessUnsupportedForce all memory accesses to be aligned (AArch32/AArch64 only)-mno-wavefrontsize64SupportedSpecify wavefront size 32 mode (AMDGPU only)-mnocrcUnsupportedDisallow use of CRC instructions (ARM only)-mnop-mcountSupportedGenerate mcount/_fentry calls as nops. To activate they need to be patched inmnvjSupportedEnable generation of new-value jumps-movsSupportedEnable generation of new-value stores-module-dependency-dirUnsupportedDirectory to dump module dependencies to-value>Directory to dump module dependencies to-moutle-file-infoUnsupportedProvide information about a particular module file-momit-leaf-frame-pointerSupportedOmit frame pointer setup for leaf functions-moutlineUnsupportedEnable function outlining (AArch64 only)-mpacked-stackUnsupportedUse packed stack layout (SystemZ only)mpacketsSupportedSupportedSpecify maximum number of prefixes to use for paddingsize= <value>SupportedUse copy relocations support for PIE builds-mpie-copy-relocationsSupportedUse copy relocations support for PIE builds-mprefer-vector- width=UnsupportedUse copy relocations support for each dependency (other than main file)</value>	-mno-seses	Unsupported	
-mno-unaligned-accessUnsupported (AArch32/AArch64 only)Force all memory accesses to be aligned (AArch32/AArch64 only)-mno-wavefrontsize64SupportedSpecify wavefront size 32 mode (AMDGPU only)-mnocrcUnsupportedDisallow use of CRC instructions (ARM only)-mnop-mcountSupportedGenerate mcount/_fentry calls as nops. To activate they need to be patched inmnvjSupportedEnable generation of new-value jumps-module-dependency-dirUnsupportedDirectory to dump module dependencies to-wodule-file-infoUnsupportedProvide information about a particular module file-moutlineUnsupportedOmit frame pointer setup for leaf functions-moutlineUnsupportedEnable function outlining (AArch64 only)-mpacked-stackUnsupportedUse packed stack layout (SystemZ only)mpacketsSupportedEnable generation of instruction packets-mpad-max-prefix- size= <value>SupportedSpecify maximum number of prefixes to use for padding-mpie-copy-relocationsSupportedUse copy relocations support for PIE builds-mprefer-vector- width=<value>UnsupportedUse copy referred vector width for auto-vectorizationMPSupportedCreate phony target for each dependency (other than main file)</value></value>	-mno-stack-arg-probe	Supported	Disable stack probes which are enabled by default
-mno-wavefrontsize64SupportedSpecify wavefront size 32 mode (AMDGPU only)-mnocrcUnsupportedDisallow use of CRC instructions (ARM only)-mnop-mcountSupportedGenerate mcount/_ fentry calls as nops. To activate they need to be patched inmnvjSupportedEnable generation of new-value jumps-module-dependency-dir UnsupportedDirectory to dump module dependencies to-walue>UnsupportedProvide information about a particular module file-module-file-infoUnsupportedOmit frame pointer setup for leaf functions-moutlineUnsupportedEnable function outlining (AArch64 only)-mpacked-stackUnsupportedUse packed stack layout (SystemZ only)mpacketsSupportedSpecify maximum number of prefixes to use for paddingsize= <value>Specify maximum number of prefixes to use for padding-mpie-copy-relocationsSupportedUse copy relocations support for PIE builds-mprefer-vector- width=<value>UnsupportedSpecifies preferred vector width for auto-vectorizationMPSupportedCreate phony target for each dependency (other than main file)</value></value>	-mno-tls-direct-seg-refs	Supported	
-mno-wavefrontsize64SupportedSpecify wavefront size 32 mode (AMDGPU only)-mnocrcUnsupportedDisallow use of CRC instructions (ARM only)-mnop-mcountSupportedGenerate mcount/_fentrycalls as nops. To activate they need to be patched inmnvjSupportedEnable generation of new-value jumps-mnvsSupportedEnable generation of new-value stores-module-dependency-dir UnsupportedDirectory to dump module dependencies to-value>Provide information about a particular module file-momit-leaf-frame-pointerSupportedOmit frame pointer setup for leaf functions-moutlineUnsupportedUse packed stack layout (SystemZ only)mpacked-stackUnsupportedUse packed stack layout (SystemZ only)mpad-max-prefix- size= <value>SupportedSpecify maximum number of prefixes to use for padding-mpie-copy-relocationsSupportedUse copy relocations support for PIE builds-mprefer-vector- width=<value>UnsupportedSpecifies preferred vector width for auto-vectorization. Defaults to 'none' which allows target specific decisionsMPSupportedCreate phony target for each dependency (other than main file)</value></value>	-mno-unaligned-access	Unsupported	
-mnocrcUnsupportedDisallow use of CRC instructions (ARM only)-mnop-mcountSupportedGenerate mcount/_fentry calls as nops. To activate they need to be patched inmnvjSupportedEnable generation of new-value jumps-mnvsSupportedEnable generation of new-value stores-module-dependency-dir UnsupportedDirectory to dump module dependencies to-module-file-infoUnsupportedProvide information about a particular module file-momit-leaf-frame-pointerSupportedOmit frame pointer setup for leaf functions-moutlineUnsupportedEnable function outlining (AArch64 only)-mpacked-stackUnsupportedUse packed stack layout (SystemZ only)mpad-max-prefix- size= <value>SupportedSpecify maximum number of prefixes to use for padding-mpie-copy-relocationsSupportedUse copy relocations support for PIE builds-mpie-copy-relocationsSupportedSpecifies preferred vector width for auto-vectorization. Defaults to 'none' which allows target specific decisionsMPSupportedCreate phony target for each dependency (other than main file)</value>	-mno-wavefrontsize64	Supported	
-mnop-mcountSupported they need to be patched in.Generate mcount/_fentry calls as nops. To activate they need to be patched inmnvjSupportedEnable generation of new-value jumps-module-dependency-dirUnsupportedDirectory to dump module dependencies to-walue>Directory to dump module dependencies to-module-file-infoUnsupportedProvide information about a particular module file-momit-leaf-frame-pointerSupportedOmit frame pointer setup for leaf functions-moutlineUnsupportedEnable function outlining (AArch64 only)-mpacked-stackUnsupportedUse packed stack layout (SystemZ only)mpacketsSupportedEnable generation of instruction packets-mpad-max-prefix- size= <value>SupportedSpecify maximum number of prefixes to use for padding-mpie-copy-relocationsSupportedUse copy relocations support for PIE builds-mprefer-vector- width=<value>UnsupportedSpecifies preferred vector width for auto-vectorization. Defaults to 'none' which allows target specific decisionsMPSupportedCreate phony target for each dependency (other than main file)</value></value>	-mnocrc		
-mnvjSupportedEnable generation of new-value jumps-module-dependency-dirUnsupportedEnable generation of new-value stores-module-file-infoUnsupportedDirectory to dump module dependencies to-momit-leaf-frame-pointerSupportedProvide information about a particular module file-moutlineUnsupportedOmit frame pointer setup for leaf functions-mpacked-stackUnsupportedEnable function outlining (AArch64 only)-mpacketsSupportedUse packed stack layout (SystemZ only)mpad-max-prefix- size= <value>SupportedSpecify maximum number of prefixes to use for padding-mpie-copy-relocationsSupportedUse copy relocations support for PIE builds-mprefer-vector- width=<value>UnsupportedSpecifies preferred vector width for auto-vectorizationMPSupportedCreate phony target for each dependency (other than main file)</value></value>	-mnop-mcount	Supported	
-mnvsSupportedEnable generation of new-value stores-module-dependency-dirUnsupportedDirectory to dump module dependencies to-walue>Provide information about a particular module file-module-file-infoUnsupportedOmit frame pointer setup for leaf functions-moutlineUnsupportedEnable function outlining (AArch64 only)-mpacked-stackUnsupportedUse packed stack layout (SystemZ only)mpacketsSupportedEnable generation of instruction packets-mpad-max-prefix- size= <value>SupportedSpecify maximum number of prefixes to use for padding-mpie-copy-relocationsSupportedUse copy relocations support for PIE builds-mprefer-vector- width=<value>UnsupportedSpecifies preferred vector width for auto-vectorizationMPSupportedCreate phony target for each dependency (other than main file)</value></value>	-mnvi	Supported	
-module-dependency-dir <value>UnsupportedDirectory to dump module dependencies to-module-file-infoUnsupportedProvide information about a particular module file-momit-leaf-frame-pointerSupportedOmit frame pointer setup for leaf functions-moutlineUnsupportedEnable function outlining (AArch64 only)-mpacked-stackUnsupportedUse packed stack layout (SystemZ only)mpacketsSupportedEnable generation of instruction packets-mpad-max-prefix- size=<value>SupportedSpecify maximum number of prefixes to use for padding-mpie-copy-relocationsSupportedUse copy relocations support for PIE builds-mprefer-vector- width=<value>UnsupportedSpecifies preferred vector width for auto-vectorization. Defaults to 'none' which allows target specific decisionsMPSupportedCreate phony target for each dependency (other than main file)</value></value></value>			
-module-file-infoUnsupportedProvide information about a particular module file-momit-leaf-frame-pointerSupportedOmit frame pointer setup for leaf functions-moutlineUnsupportedEnable function outlining (AArch64 only)-mpacked-stackUnsupportedUse packed stack layout (SystemZ only)mpacketsSupportedEnable generation of instruction packets-mpad-max-prefix- size= <value>SupportedSpecify maximum number of prefixes to use for padding-mpie-copy-relocationsSupportedUse copy relocations support for PIE builds-mprefer-vector- width=<value>UnsupportedSpecifies preferred vector width for auto-vectorization. Defaults to 'none' which allows target specific decisionsMPSupportedCreate phony target for each dependency (other than main file)</value></value>	-module-dependency-dir		
-momit-leaf-frame-pointerSupportedOmit frame pointer setup for leaf functions-moutlineUnsupportedEnable function outlining (AArch64 only)-mpacked-stackUnsupportedUse packed stack layout (SystemZ only)mpacketsSupportedEnable generation of instruction packets-mpad-max-prefix-size= <value>SupportedSpecify maximum number of prefixes to use for padding-mpie-copy-relocationsSupportedUse copy relocations support for PIE builds-mprefer-vector-width=UnsupportedSpecifies preferred vector width for auto-vectorizationMPSupportedCreate phony target for each dependency (other than main file)</value>		Unsupported	Provide information about a particular module file
-moutlineUnsupportedEnable function outlining (AArch64 only)-mpacked-stackUnsupportedUse packed stack layout (SystemZ only)mpacketsSupportedEnable generation of instruction packets-mpad-max-prefix- size= <value>SupportedSpecify maximum number of prefixes to use for padding-mpie-copy-relocationsSupportedUse copy relocations support for PIE builds-mprefer-vector- width=<value>UnsupportedSpecifies preferred vector width for auto-vectorization. Defaults to 'none' which allows target specific decisionsMPSupportedCreate phony target for each dependency (other than main file)</value></value>			•
-mpacked-stackUnsupportedUse packed stack layout (SystemZ only)mpacketsSupportedEnable generation of instruction packets-mpad-max-prefix- size= <value>SupportedSpecify maximum number of prefixes to use for padding-mpie-copy-relocationsSupportedUse copy relocations support for PIE builds-mprefer-vector- width=<value>UnsupportedSpecifies preferred vector width for auto-vectorization. Defaults to 'none' which allows target specific decisionsMPSupportedCreate phony target for each dependency (other than main file)</value></value>			• •
-mpacketsSupportedEnable generation of instruction packets-mpad-max-prefix- size= <value>SupportedSpecify maximum number of prefixes to use for padding-mpie-copy-relocationsSupportedUse copy relocations support for PIE builds-mprefer-vector- width=<value>UnsupportedSpecifies preferred vector width for auto-vectorization. Defaults to 'none' which allows target specific decisionsMPSupportedCreate phony target for each dependency (other than main file)</value></value>			<u> </u>
-mpad-max-prefix- size= <value>  -mpie-copy-relocations -mprefer-vector- width=<value>  Supported Use copy relocations support for PIE builds Unsupported Specifies preferred vector width for auto-vectorization. Defaults to 'none' which allows target specific decisions.  Create phony target for each dependency (other than main file)</value></value>			• • • • • • • • • • • • • • • • • • • •
-mpie-copy-relocations -mprefer-vector- width= <value>  Supported Use copy relocations support for PIE builds  Specifies preferred vector width for auto-vectorization. Defaults to 'none' which allows target specific decisions.  Create phony target for each dependency (other than main file)</value>			-
-mpie-copy-relocations       Supported       Use copy relocations support for PIE builds         -mprefer-vector-width= <value>       Unsupported       Specifies preferred vector width for auto-vectorization. Defaults to 'none' which allows target specific decisions.         -MP       Supported       Create phony target for each dependency (other than main file)</value>		113	1 , 12 First to the following
-mprefer-vector- width= <value> Defaults to 'none' which allows target specific decisions.  Create phony target for each dependency (other than main file)</value>		Supported	Use copy relocations support for PIE builds
width= <value> Defaults to 'none' which allows target specific decisions.  Create phony target for each dependency (other than main file)</value>		***	
main file)	width= <value></value>		Defaults to 'none' which allows target specific decisions.
· · · · · · · · · · · · · · · · · · ·	-MP	Supported	
migraph compate Chappered   Diacie included quape duck ward compatibility	-mqdsp6-compat	Unsupported	Enable hexagon-qdsp6 backward compatibility

Option	Support	Description
-MQ <value></value>	Supported	Specify name of main file output to quote in depfile
-mrecord-mcount	Supported	Generate amcount_loc section entry for eachfentry call.
-mrelax-all	Supported	(integrated-as) Relax all machine instructions
-mrelax	Supported	Enable linker relaxation
-mrestrict-it	Unsupported	Disallow generation of deprecated IT blocks for ARMv8. It is on by default for ARMv8 Thumb mode.
-mrtd	Unsupported	Make StdCall calling convention the default
-msave-restore	Unsupported	Enable using library calls for save and restore
-mseses	Unsupported	Enable speculative execution side effect suppression (SESES). Includes LVI control flow integrity mitigations
-msign-return-	Unsupported	Select return address signing scope
address= <value></value>		
-msmall-data-	Supported	Put global and static data smaller than the limit into a
limit= <value></value>	0 1	special section
-msoft-float	Supported	Use software floating point
-msram-ecc	Supported	Legacy option to specify SRAM ECC mode (AMDGPU only). Should useoffload-arch with :sramecc+ instead
-mstack-	Unsupported	Set the stack alignment
alignment= <value></value>	***	
-mstack-arg-probe	Unsupported	Enable stack probes
-mstack-probe-	Unsupported	Set the stack probe size
size= <value></value>	I I	Fana malian the stark at automate arrang for ation
-mstackrealign -msve-vector-bits= <value></value>	Unsupported Unsupported	Force realign the stack at entry to every function  Specify the size in bits of an SVE vector register.
-msve-vector-bits-value	Onsupported	Defaults to the vector length agnostic value of "scalable". (AArch64 only)
-msvr4-struct-return	Unsupported	Return small structs in registers (PPC32 only)
-mthread-model <value></value>	Supported	The thread model to use, e.g. posix, single (posix by default)
-mtls-direct-seg-refs	Supported	Enable direct TLS access through segment registers (default)
-mtls-size= <value></value>	Unsupported	Specify bit size of immediate TLS offsets (AArch64 ELF only): 12 (for 4KB) \  24 (for 16MB, default) \  32 (for 4GB) \  48 (for 256TB, needs -mcmodel=large)
-mtp= <value></value>	Unsupported	Thread pointer access method (AArch32/AArch64 only)
-mtune= <value></value>	Supported on Host only	Only supported on X86. Otherwise accepted for compatibility with GCC.
-MT <value></value>	Unsupported	Specify name of main file output in depfile
-munaligned-access	Unsupported	Allow memory accesses to be unaligned
		(AArch32/AArch64 only)
-MV	Supported	Use NMake/Jom format for the depfile
-mwavefrontsize64	Supported	Specify wavefront size 64 mode (AMDGPU only)
-mxnack	Supported	Legacy option to specify XNACK mode (AMDGPU only). Should useoffload-arch with :xnack+ instead

Option	Support	Description
-M	Supported	Like -MD, but also implies -E and writes to stdout by default
no-cuda-include- ptx= <value></value>	Supported	Do not include PTX for the following GPU architecture (e.g. sm_35) or 'all'. May be specified more than once.
no-cuda-version-check	Supported	Don't error out if the detected version of the CUDA install is too low for the requested CUDA gpu architecture.
-no-flang-libs	Supported	Do not link against Flang libraries
no-offload-arch= <value></value>	Supported	Remove CUDA/HIP offloading device architecture (e.g. sm_35, gfx906) from the list of devices to compile for. 'all' resets the list to its default value.
no-system-header- prefix= <pre>prefix&gt;</pre>	Supported	Treat all #include paths starting with <pre>prefix&gt;</pre> as not including a system header.
-nobuiltininc	Supported	Disable builtin #include directories
-nogpuinc	Supported	Do not add CUDA/HIP include paths and include default CUDA/HIP wrapper header files
-nogpulib	Supported	Do not link device library for CUDA/HIP device compilation
-nostdinc++	Unsupported	Disable standard #include directories for the C++ standard library
-ObjC++	Unsupported	Treat source input files as Objective-C++ inputs
-objcmt-atomic-property	Unsupported	Make migration to 'atomic' properties
-objcmt-migrate-all	Unsupported	Enable migration to modern ObjC
-objcmt-migrate- annotation	Unsupported	Enable migration to property and method annotations
-objcmt-migrate- designated-init	Unsupported	Enable migration to infer NS_DESIGNATED_INITIALIZER for initializer methods
-objcmt-migrate- instancetype	Unsupported	Enable migration to infer instancetype for method result type
-objcmt-migrate-literals	Unsupported	Enable migration to modern ObjC literals
-objcmt-migrate-ns- macros	Unsupported	Enable migration to NS_ENUM/NS_OPTIONS macros
-objcmt-migrate-property- dot-syntax	Unsupported	Enable migration of setter/getter messages to property-dot syntax
-objcmt-migrate-property	Unsupported	Enable migration to modern ObjC property
-objcmt-migrate-protocol- conformance	Unsupported	Enable migration to add protocol conformance on classes
-objcmt-migrate-readonly- property	Unsupported	Enable migration to modern ObjC readonly property
-objcmt-migrate- readwrite-property	Unsupported	Enable migration to modern ObjC readwrite property
-objcmt-migrate- subscripting	Unsupported	Enable migration to modern ObjC subscripting
-objemt-ns-nonatomic- iosonly	Unsupported	Enable migration to use NS_NONATOMIC_IOSONLY macro for setting property's 'atomic' attribute

Option	Support	Description
-objcmt-returns-	Unsupported	Enable migration to annotate property with
innerpointer-property		NS_RETURNS_INNER_POINTER
-objcmt-whitelist-dir-	Unsupported	Only modify files with a filename contained in the
path= <value></value>		provided directory path
-ObjC	Unsupported	Treat source input files as Objective-C inputs
offload-arch= <value></value>	Supported	CUDA offloading device architecture (e.g. sm_35), or HIP offloading target ID in the form of a device architecture followed by target ID features delimited by a colon. Each target ID feature is a pre-defined string followed by a plus or minus sign (e.g. gfx908:xnack+:sramecc-). May be specified more than once.
-o <file></file>	Supported	Write output to <file></file>
-parallel-jobs= <value></value>	Supported	Number of parallel jobs
-pg	Supported	Enable moount instrumentation
-pipe	Supported	Use pipes between commands, when possible
precompile	Supported	Only precompile the input
-print-effective-triple	Supported	Print the effective target triple
-print-file-name= <file></file>	Supported	Print the full library path of <file></file>
-print-ivar-layout	Unsupported	Enable Objective-C Ivar layout bitmap print trace
-print-libgcc-file-name	Supported	Print the library path for the currently used compiler runtime library ("libgcc.a" or "libclang_rt.builtins.*.a")
-print-prog-name= <name></name>	Supported	Print the full program path of <name></name>
-print-resource-dir	Supported	Print the resource directory pathname
-print-search-dirs	Supported	Print the paths used for finding libraries and programs
-print-supported-cpus	Supported	Print supported cpu models for the given target (if target is not specified, it will print the supported cpus for the default target)
-print-target-triple	Supported	Print the normalized target triple
-print-targets	Supported	Print the registered targets
-pthread	Supported	Support POSIX threads in generated code
ptxas-path= <value></value>	Unsupported	Path to ptxas (used for compiling CUDA code)
-P	Supported	Disable linemarker output in -E mode
-Qn	Supported	Do not emit metadata containing compiler name and version
-Qunused-arguments	Supported	Don't emit warning for unused driver arguments
-Qy	Supported	Emit metadata containing compiler name and version
-relocatable-pch	Supported	Whether to build a relocatable precompiled header
-rewrite-legacy-objc	Unsupported	Rewrite Legacy Objective-C source to C++
-rewrite-objc	Unsupported	Rewrite Objective-C source to C++
rocm-device-lib- path= <value></value>	Supported	ROCm device library path. Alternative to rocm-path.
rocm-path= <value></value>	Supported	ROCm installation path, used for finding and automatically linking required bitcode libraries.

1.0 Rev. 1027 October 2021

-Rpass-analysis= <value> Supported Report transformation analysis from optimization pass whose name matches the given POSIX regular expression  -Rpass-missed=<value> Supported Report missed transformations by optimization passes whose name matches the given POSIX regular expression  -Rpass=<value> Supported Report transformations performed by optimization pass whose name matches the given POSIX regular expression  -rtlib=<value> Unsupported Compiler runtime library to use -R<remark> Unsupported Save llvm statisticssave-stats -save-stats -save-temps -save-temps Supported Save intermediate compilation resultssave-temps -serialize-diagnostics -save-diagnostics -save-diagnostics -save-diagnostics -shared-libsan Unsupported Unsupported Supported Supported -static-flang-libs -static-libsan Unsupported Statically link the sanitizer runtime Statically link the sanitizer runtime Statically link the sanitizer runtime</remark></value></value></value></value>
-Rpass-missed= <value> Supported Report missed transformations by optimization passes whose name matches the given POSIX regular expression  -Rpass=<value> Supported Report transformations performed by optimization pass whose name matches the given POSIX regular expression  -rtlib=<value> Unsupported Compiler runtime library to use -R<remark> Unsupported Enable the specified remark -save-stats=<value> Supported Save llvm statisticssave-temps=<value> Supported Save intermediate compilation resultssave-temps Supported Save intermediate compilation results -serialize-diagnostics -serialize-diagnostics -save-temps -shared-libsan Unsupported Dynamically link the sanitizer runtime -static-flang-libs Supported Link using static Flang libraries</value></value></remark></value></value></value>
-Rpass-missed= <value> Supported Report missed transformations by optimization passes whose name matches the given POSIX regular expression  Report transformations performed by optimization pass whose name matches the given POSIX regular expression  -rtlib=<value> Unsupported Compiler runtime library to use -R<remark> Unsupported Save llvm statisticssave-stats Supported Save llvm statisticssave-temps=<value> Supported Save intermediate compilation results -save-temps Supported Save intermediate compilation results -serialize-diagnostics Supported Serialize compiler diagnostics to a file -shared-libsan Unsupported Link using static Flang libraries</value></remark></value></value>
whose name matches the given POSIX regular expression  -Rpass= <value> Supported Report transformations performed by optimization pass whose name matches the given POSIX regular expression  -rtlib=<value> Unsupported Compiler runtime library to use -R<remark> Unsupported Supported Save llvm statisticssave-stats Supported Save llvm statisticssave-temps=<value> Supported Save intermediate compilation resultssave-temps Supported Save intermediate compilation results -serialize-diagnostics Supported Serialize compiler diagnostics to a file -shared-libsan Unsupported Dynamically link the sanitizer runtime -static-flang-libs Supported Link using static Flang libraries</value></remark></value></value>
-Rpass= <value> Supported Report transformations performed by optimization pass whose name matches the given POSIX regular expression  -rtlib=<value> Unsupported Compiler runtime library to use -R<remark> Unsupported Enable the specified remark -save-stats=<value> Supported Save llvm statisticssave-temps=<value> Supported Save intermediate compilation resultssave-temps Supported Save intermediate compilation results -serialize-diagnostics -save-diagnostics -save-temps -save-te</value></value></remark></value></value>
-rtlib= <value> Unsupported Compiler runtime library to use -R<remark> Unsupported Enable the specified remark -save-stats=<value> Supported Save llvm statisticssave-temps=<value> Supported Save intermediate compilation resultssave-temps -save-temps Supported Save intermediate compilation results -save-temps -save-temps Unsupported Save intermediate compilation results -save-temps Supported Save intermediate compilation results -save-temps -serialize-diagnostics -save-diagnostics -save-libsan Unsupported Dynamically link the sanitizer runtime -static-flang-libs -supported Link using static Flang libraries</value></value></remark></value>
whose name matches the given POSIX regular expression  -rtlib= <value> Unsupported Compiler runtime library to use -R<remark> Unsupported Enable the specified remark -save-stats=<value> Supported Save llvm statisticssave-temps=<value> Supported Save intermediate compilation resultssave-temps Supported Save intermediate compilation results -save-temps Supported Save intermediate compilation results -serialize-diagnostics -serialize-diagnostics -save-temps Unsupported Serialize compiler diagnostics to a file -shared-libsan Unsupported Dynamically link the sanitizer runtime -static-flang-libs Supported Link using static Flang libraries</value></value></remark></value>
expression  -rtlib= <value> Unsupported Compiler runtime library to use -R<remark> Unsupported Enable the specified remark -save-stats=<value> Supported Save llvm statisticssave-temps=<value> Supported Save intermediate compilation resultssave-temps Supported Save intermediate compilation results -save-temps Supported Save intermediate compilation results -serialize-diagnostics Supported Serialize compiler diagnostics to a file  -shared-libsan Unsupported Dynamically link the sanitizer runtime -static-flang-libs Supported Link using static Flang libraries</value></value></remark></value>
-rtlib= <value>UnsupportedCompiler runtime library to use-R<remark>UnsupportedEnable the specified remark-save-stats=<value>SupportedSave llvm statisticssave-temps=<value>SupportedSave intermediate compilation resultssave-tempsSupportedSave intermediate compilation results-serialize-diagnosticsSupportedSerialize compiler diagnostics to a file<value>SupportedDynamically link the sanitizer runtime-static-flang-libsSupportedLink using static Flang libraries</value></value></value></remark></value>
-R <remark> -save-stats=<value> Supported Save llvm statisticssave-stats Supported Save llvm statisticssave-temps=<value> Supported Save intermediate compilation resultssave-temps Supported Save intermediate compilation resultssave-temps Supported Save intermediate compilation results -serialize-diagnostics Supported Serialize compiler diagnostics to a file <value> -shared-libsan Unsupported Dynamically link the sanitizer runtime -static-flang-libs Supported Link using static Flang libraries</value></value></value></remark>
-save-stats
-save-statsSupportedSave llvm statisticssave-temps= <value>SupportedSave intermediate compilation resultssave-tempsSupportedSave intermediate compilation results-serialize-diagnosticsSupportedSerialize compiler diagnostics to a file<value>UnsupportedDynamically link the sanitizer runtime-static-flang-libsSupportedLink using static Flang libraries</value></value>
-save-temps Supported Save intermediate compilation resultssave-temps Supported Save intermediate compilation results -serialize-diagnostics Supported Serialize compiler diagnostics to a file <value> -shared-libsan Unsupported Dynamically link the sanitizer runtime -static-flang-libs Supported Link using static Flang libraries</value>
-save-temps Supported Save intermediate compilation results -serialize-diagnostics Supported Serialize compiler diagnostics to a file <value> -shared-libsan Unsupported Dynamically link the sanitizer runtime -static-flang-libs Supported Link using static Flang libraries</value>
-serialize-diagnostics <value> Supported Serialize compiler diagnostics to a file  -shared-libsan Unsupported Dynamically link the sanitizer runtime -static-flang-libs Supported Link using static Flang libraries</value>
<value>UnsupportedDynamically link the sanitizer runtime-static-flang-libsSupportedLink using static Flang libraries</value>
-static-flang-libs Supported Link using static Flang libraries
-static-libsan Unsupported Statically link the sanitizer runtime
<b>-static-openmp</b> Supported Use the static host OpenMP runtime while linking.
-std= <value> Supported Language standard to compile for</value>
-stdlib++-isystem Supported Use directory as the C++ standard library include path
<directory></directory>
-stdlib= <value> Supported C++ standard library to use</value>
-sycl-std= <value> Unsupported SYCL language standard to compile for.</value>
system-header- Supported Treat all #include paths starting with <pre>prefix&gt;</pre> as
<b>prefix=<pre>prefix&gt;</pre></b> including a system header.
-S Supported Only run preprocess and compilation steps
target= <value> Supported Generate code for the given target</value>
-Tbss <addr> Supported Set starting address of BSS to <addr></addr></addr>
-Tdata <addr> Supported Set starting address of DATA to <addr></addr></addr>
-time Supported Time individual commands
<b>-traditional-cpp</b> Unsupported Enable some traditional CPP emulation
-trigraphs Supported Process trigraph sequences
-Ttext <addr> Supported Set starting address of TEXT to <addr></addr></addr>
-T <script> Unsupported Specify <script> as linker script</th></tr><tr><th>-undef Supported undef all system defines</th></tr><tr><th>-unwindlib=<value> Supported Unwind library to use</th></tr><tr><th>-U <macro> Supported Undefine macro <macro></th></tr><tr><th><b>verify-debug-info</b> Supported Verify the binary representation of debug output</th></tr><tr><th>-verify-pch Unsupported Load and verify that a pre-compiled header file is not stale</th></tr><tr><th>version Supported Print version information</th></tr><tr><th>-v Supported Show commands to run and use verbose output</th></tr></tbody></table></script>

Option	Support	Description
-Wa, <arg></arg>	Supported	Pass the comma separated arguments in <arg> to the assembler</arg>
-Wdeprecated	Supported	Enable warnings for deprecated constructs and defineDEPRECATED
-Wl, <arg></arg>	Supported	Pass the comma separated arguments in <arg> to the linker</arg>
-working-directory <value></value>	Supported	Resolve file paths relative to the specified directory
-Wp, <arg></arg>	Supported	Pass the comma separated arguments in <arg> to the preprocessor</arg>
-W <warning></warning>	Supported	Enable the specified warning
-W	Supported	Suppress all warnings
-Xanalyzer <arg></arg>	Supported	Pass <arg> to the static analyzer</arg>
-Xarch_device <arg></arg>	Supported	Pass <arg> to the CUDA/HIP device compilation</arg>
-Xarch_host <arg></arg>	Supported	Pass <arg> to the CUDA/HIP host compilation</arg>
-Xassembler <arg></arg>	Supported	Pass <arg> to the assembler</arg>
-Xclang <arg></arg>	Supported	Pass <arg> to the clang compiler</arg>
-Xcuda-fatbinary <arg></arg>	Supported	Pass <arg> to fatbinary invocation</arg>
-Xcuda-ptxas <arg></arg>	Supported	Pass <arg> to the ptxas assembler</arg>
-Xlinker <arg></arg>	Supported	Pass <arg> to the linker</arg>
-Xopenmp-target= <triple></triple>	Supported	Pass <arg> to the target offloading toolchain identified</arg>
<arg></arg>		by <triple>.</triple>
-Xopenmp-target <arg></arg>	Supported	Pass <arg> to the target offloading toolchain.</arg>
-Xpreprocessor <arg></arg>	Supported	Pass <arg> to the preprocessor</arg>
-x <language></language>	Supported	Treat subsequent input files as having type <language></language>
-z <arg></arg>	Supported	Pass -z <arg> to the linker</arg>