Introduction to Scopesim for METIS

February 20, 2022

This notebook presents a basic description of the simulation procedure with scopesim and tries to give some useful hints how the behaviour of each step can be inspected and controlled. Once scopesim and the necessary instrument packages are installed, a simulation is basically a four-step process using the commands UserCommands, OpticalTrain, observe and readout. The cells in this notebook are not executable; the practical application to a variety of different source objects and instrument modes is presented in other notebooks.

1 Installation and prerequisites

The easiest way to install Scopesim is to use pip from the command line:

pip install scopesim

If you want to upgrade an existing installation, do

pip install -U scopesim

In your favourite python environment (e.g. ipython, jupyter notebook or a script), scopesim is loaded by

import scopesim

or

import scopesim as sim

Scopesim has a utility function sim.bug_report() which checks a number of other python packages required by scopesim and reports their version numbers. The output of this command should be included in any bug report or question submitted to the scopesim team.

Scopesim is a general simulation framework. In order to simulate observations with any particular instrument, you will have to load an instrument package, as well as packages describing the telescope and observatory location (the latter is important for the atmospheric conditions). In the case of METIS, the packages can be downloaded with

```
sim.download_package(['instruments/METIS', 'telescopes/ELT', 'locations/Armazones'])
```

This will install the packages in the directory inst_pkgs, which is a subdirectory to the current working directory. It is possible to install the packages elsewhere; however, keeping the instrument packages together with the input and output data of scopesim makes it easier to reconstruct the conditions under which a simulation was run.

The command sim.list_packages() lists all packages that are available for download, as well as those that are already installed.

2 Setting up the instrument

The instrument is configured using the sim.UserCommands() class. A basic setup for METIS could be

```
cmd = sim.UserCommands(use_instrument='METIS', set_modes=['img_lm'])
```

This creates a (nested dictionary) containing all parameters that are relevant for the description of the instrument and observational conditions, and the way that the simulation is to be run.

The modes are predefined in the instrument package (in the file METIS/default.yaml). The available modes for METIS are

- img_lm for imaging using the LM imager
- img_n for imaging using the N imager
- 1ss 1 for long-slit spectroscopy in the L band
- lss_m for long-slit spectroscopy in the M band
- lss_n for long-slit spectroscopy in the N band

The LMS modes lms and lms_extended are not yet functional.

The UserCommands dictionary is structured into a number of sections that can be accessed using a "bang string", starting with an exclamation mark. For instance, the list of "observation" parameters is obtained with cmd['!OBS']. Individual parameters are addressed as cmd['!OBS.filter_name'] etc. The !OBS class contains the parameters that users are most likely to want to change from one simulation to the next. The other sections are more static, and users should only change them with more caution. The following sections are available:

- !OBS: parameters that might be changed from one simulation to the other
- !SIM: parameters that set up file paths and simulation parameters for scopesim
- !ATMO: parameters that relate to the atmosphere and atmospheric conditions.
- !TEL: parameters related to the telescope. Of interest for METIS is the parameter !TEL.ter_curve, which defaults to TER_ELT_6_mirror_field_track.dat but could be changed to TER_ELT_6_mirror_pupil_track.dat. The files differ in that field tracking includes thermal emission from the telescope support spiders, which are assumed to be masked in pupil tracking.
- !INST: parameters related to the instrument
- !DET: parameters related to the detector

The parameters can be changed at this point, for instance to change the pupil transmission (this refers to undersizing of the aperture by inserting a cold stop):

```
cmd['!OBS.pupil transmission'] = 0.9
```

Individual parameters can be set immediately in the UserCommands by giving a properties dictionary. This gives the compact form

Some parameters can also be set later as will be demonstrated.

3 Building and modifying the instrument

The combination of atmosphere, telescope and instrument is represented in scopesim as an OpticalTrain object, which is instantiated as

```
metis = sim.OpticalTrain(cmd)
```

The optical train consists of a number of Effect objects, which can be listed as

```
metis.effects
```

The table has four columns of which name and included are important. An effect is addressed by its name; for example, metis['detector_linearity'] is the effect that describes the (non-)linearity of the detector. Each effect has a meta dictionary that contains parameters used to set it up, as well as meta data from configuration files. To resolve a parameter that contains a bang string, the function from_currsys has to be used. For instance, metis['dark_current'] returns !DET.dark_current, which is resolved by

```
sim.utils.from_currsys(metis['dark_current'])
```

into a number of electrons per second.

Some parameters support changing parameters, these are notably filter_wheel and slit_wheel. These have a number of predefined options that can be seen with

```
metis['filter_wheel'].filters
```

The current setting is found by metis['filter_wheel'].current_filter and can be changed by metis['filter_wheel'].change_filter('PAH_3.3')

4 Defining and observing the source

The observe() method of an OpticalTrain transmits a source object through the atmosphere, telescope and instrument into the detector plane but does not yet include the detector itself (with the exception of the quantum efficiency, which is treated as a transmission effect). The result is an ideal noise-free image in units of electrons per second (electrons because of the inclusion of QE).

The definition of Source objects is described in other notebooks. The observation is done by

```
src = sim.source.source_templates.star()
metis.observe(src)
```

The same optical train can be used to observe multiple sources in succession. In this case it is advisable (and should never harm) to include the parameter update=True:

```
metis.observe(src, update=True)
```

Sometimes one might have several optical trains to observe the same source, e.g metis_1 and metis_n for observation in the L and M bands, respectively. To switch from one to the other it is necessary to call the method set focus(), as in

```
metis_1.observe(src)
metis_n.set_focus()
metis_n.observe(src)
```

The noise-free image is an ImagePlane object, which can be accessed as

```
metis.image_planes[0]
```

In general, image_planes is a list, although METIS always produces a single ImagePlane. An ImagePlane is essentially a FITS HDU whose parts are accessed as

```
metis.image_planes[0].header
metis.image_planes[0].data
```

5 Creating detector images

The readout() method applies photon noise and detector noise to the image and creates detector images with a given exposure time. The result of readout() is a list of FITS HDULists (essentially FITS "files" in memory). For METIS only a single HDULIST is created, so a command like

```
result = metis.readout()[0]
```

is convenient. The detector image is in the first extension of result and one might want to look at

```
result[0].header
result[1].header
result[1].data
```

The second extension is not yet useful - in the future it will contain a table representation of the UserCommands structure.

By default, the exposure time is set by the UserCommands parameter !OBS.exptime. In many cases it is more convenient to set it as a parameter to the readout() method:

```
result = metis.readout(exptime=3600)[0]  # exposure time in seconds
```

The exposure time is automatically split into NDIT subexposures of length DIT, ensuring that the detector is not saturated during a subexposure (a warning is issued if a bright source saturates the detector even in the minimum possible DIT).

The METIS detectors each have two settings ("fast" and "slow" for the HAWAII detectors, "high_capacity" and "low_capacity" for the Geosnap). There is a default setting for each instrument mode, but an optimal readout mode can also be automatically determined by

```
result = metis.readout(detector_readout_mode='auto')
```

The result can be written to disk with

```
result.writeto("simulation_result.fits", overwrite=True) # careful with overwrite for analysis with external tools.
```