Rigging the Flaperons

Sub-Section "E" - Rigging the Flaperons

connect tubes, and adjust the control tube linkages to rig the flaperons. Objective: Install the Flaperon Control Horns. Install the flaperons on the wings, the

STEP (1): cardboard. Paste the Flaperon Clamping Fixture Template (Fig. W-E-1) onto a piece of

on the Flaperon centerline. STEP (2): Carefully cut around the outside border of the Template then cut the Template Flaperon. Trim the two Template parts along the outer line of the

lengthwise on the centerline. Clamp the two halves together, lay out your Template over the centerline and mark around the Template. (See Fig. W-E-3.) **STEP** (3): Find two pieces of 2" x 4" board each 12" to 14" long. Rip saw each piece

STEP (4): Use a bandsaw or jigsaw to cut out one Clamping Fixture for each Flaperon.


together. STEP (5): Drill a 1/4" hole through the Fixtures on each end so you can bolt the two halves Countersink the holes so the bolt head and nut fit below the surface of the fixture.

at mid-span and at the tips on pads or sandbags. **STEP** (6): flaperons on your work table with the Fixture flat on the table and support the Flaperons Clamp the flaperons near the inboard ends as shown in Fig. W-E-3. Lay the

200

....


		DENNET		THE S	COMPANY
MODEL 4	ASSEMBLY	REVISION	DATE	SECTION	PAGE
KITFO	KITFOX Sub-Section "E" - Rigging The Flaperons	1	6 Mar 92		W-E-1



the Bearing so it will not bind. each pair of bearings. Leave a gap of about 1/16" between the Hinge and the shoulder of each bearing to .4" from the flange. <u>STEP</u> (7): There are two #24003 Nylon Bearings on the ends of each Flaperon spar. Sand the ends so a #25019 Hinge rotates freely on Trim


expand and slip over the spar. STEP (8): Slide a bearing half onto the spar, then the Hinge, the other Bearing, and the #21001 Retention Ring as shown in Fig. W-E-2. Cut on side of the Retention Ring so it can

into the Shim. STEP (9): Slide the #21002 Shim into the end of the Flaperon spar and the #25009 Horn Sand the shim if necessary to fit inside the spar.



right one is different than the left. depicted in the diagram Fig. W-E-3 and clamp the Horns in place. Notice the angle of the (10): Adjust the angle of each Flaperon Horn to the axis of the Flaperon chord as

the Retention Ring, Spar, Shim and Horn Spar. Rivet with 1/8x3/16 SS Rivets. STEP (11): horn spar. Cleco as you go. Disassemble, deburr the rivet holes, assemble and rivet with 1/8" x 1/8" S.S. Rivets. Refer to Fig. W-E-2 and Plate W-21. Drill three #30 holes through Drill four #30 holes through each Rib Flance the Flaperon spar, Shim, and




Flaperon Horn Positions Fig. W-E-3

.

W-E-4	1.	6 Mar 92	1.0	Sub-Section "E" - Rigging The Flaperons	KITFOX
PAGE	SECTION	DATE	REVISION DATI	ASSEMBLY	MODEL 4
COMPANY	A-TAG	DENNEY ALTON	DENNEY		
D82001					

STEP (12): Attach the wings to the fuselage and level the fuselage as you did earlier.


in Fig. shown, STEP (13): Also Refer to Plate W-21. W.E.4. Remove the Clamping Fixtures and attach the Flaperons to the wings as shown 5-4. Use an AN960-10 Washer and an AN960-10L Washer on each bolt as



Flaperon Attachment Fig. W-E-4

					D62003
	,	DENNEY &	TARRESTA I	AL TOPE	COMPANY
MODEL 4	ASSEMBLY	REVISION	DATE	SECTION	PAGE
KITFOX	KITFOX Sub-Section "E" - Rigging The Flaperons		6 Mar 92		W-E-S

shown in Fig. W-E-5. other end of the straight edge to the front spar with a 2.82" wood block in between, as Fasten a 4' long straight board or level to the bottom of the Clamping Fixture. STEP (14): Clamp one Fixture just inboard of the center Flaperon Hinge of each Flaperon. Tape the



FLAPERON RIGGING

Neutral Flaperon Fig. W-E-5

the other door frame. easy way is to attach a strip of strapping tape to one door frame, around the stick and to STEP (15): Center the control stick (lateral function) and tape or clamp it securely. 2


this.) STEP (16): Adjust the flap push-pull tube so the angle between the belly of the aircraft and the #15049 Bellcrank is 11.4° as shown in Fig. W-E-6. (A "Smart Level" is invaluable for STEP (16):

on the rod ends. end and the #15061 Winged Bolt on the Flaperon Horn. the lengths of the #15056 Right and #15055 Left Connect Tubes and install them. Use an AN3-7A Bolt, AN960-10 Washer and an AN364-1032 Nylock Shear Nut on the lower rod STEP (17): When you have the Flaperons clamped in this "neutral" position you can adjust Tighten the AN316-4 Check Nuts

W-E-6	and the second	6 Mar 92	1	Sub-Section "E" - Rigging The Flaperons	× —
PAGE	SECTION	DATE	REVISION	ASSEMBLY	
COMPANY	CAPPED C	AFFE	DENNEY		
D82001					

KITFO)

-



STEP (18): Drill a #40 oil hole just aft of the weld attaching Hinge to the Bearing Housing. Drill through the Bearing Housing only. See Fig. W-E-7 and W-E-8.




Fig. W-E-7




Fig. W-E-8

W-E-8		6 Mar 92	-	Sub-Section "E" - Rigging The Flaperons	KITFOX
PAGE	SECTION	DATE	REVISION	ASSEMBLY	MODEL 4
COMPANY	ASSE		DENNEY ALL		
D62001					