BRAKING SYSTEM Sub-Section "B"

SINGLE BRAKE PEDALS



Toe Brake Pedals

STEP 1: INSTALL GEAR WELDMENTS


Install the assembled (Hub, Calipers, etc.) Landing Gear Weldments onto the fuselage.

STEP 2: TOE BRAKE PEDALS

Slide the P/N 35007 Toe Brake Pedals through the Rudder Pedals, with the tabs on the Brake Pedals pointing forward. Then slide the P/N 39006 Collars onto the ends of the Brake Pedals and drill a 3/32" hole through the Collar and Brake Pedal for the AN380-3-3 Cotter Pin. See Fig. LG-B-1.


STEP 3: FITTINGS ON BRAKE LINES

Install four 90° Elbow P/N 94024 Fittings in the P/N 39003 Master Cylinder Assembly. Finger tighten only at this point. Use thread lubricant.



Brake Pedal Assembly Details Fig. LG-B-1

4-1200	MODEL ASSEMBLY	
4-1200 Sub-Section "B" Braking System	ASSEMBLY	
	REVISION	SkyStar
Sept. 1, 1993 Landing	DATE	SkyStar Aircraft Corporation
Landing Gear	SECTION	poration
LG-B-1	PAGE	© 1992



Master Cylinder installation


INSTALL MASTER CYLINDER

STEP 4: ATTACH MASTER CYLINDERS

The Master Cylinders go in between the Rudder Pedal Brackets and Brake Pedals, with the bottom fittings pointing to the left, and top fitting pointing up. Attach them to the Brake Pedals with AN3-6 Bolts, AN310-3 Nuts, and AN960-10 Washers. Attach the Master Cylinders to the Brackets with AN3-12A Bolts, AN364-1032A Ny-Shear Nuts, and AN960-10L Washers. Refer to Fig. LG-B-2. Tighten the elbow fittings and orientate as shown.

STEP 5: ADJUST BRAKE PEDALS

The Brake Pedals can be adjusted by turning the upper attach fitting on the Master Cylinder stem - in or out as necessary for desired Pedal location. Adjust so that the P/N 35007 Pedal bottom tube contacts (or just barely touches) the Rudder Pedal at full rudder deflection.




Master Cylinder Mounting Details Fig. LG-B-2


Skysiai Anciaji Corporation 1992
SSEMBLY REVISION DATE SECTION PAGE
Sept. 1, 1993 Landing Gear LG-B-2

MODEL 4-1200


Sa



Brake Line securement



Brake Line routing



Brake Line from fuselage to Gear

	. 1	
4-1200 Sub-Sect	TONE!	
4-1200 Sub-Section "B" Braking System		(
REVISION	SkyStar	
Sept. 1, 1993 Landing	SkyStar Aircraft Corporation	
Landing Gear	voration	
LG-B-	© 1992	


ROUTE BRAKE LINES

STEP 6: ROUTE BRAKE LINES

(If you are installing Dual Brakes, proceed to STEP 7.) The P/N 35001 Brake Lines can now be installed. Route them from the bottom port in the Master Cylinder, around the left end of the Rudder Pedals, along the left side of the cockpit, under the seat to the backside of the aft Gear Attach Brackets, and down the aft side of the Gear Legs to the Calipers. Refer to the "Builders Tips" Section of the manual for procedures on properly assembling the compression fittings.

IF YOU ARE NOT INSTALLING DUAL BRAKES, GO TO STEP 12.

INSTALL DUAL BRAKE



copilot Side Brakes

STEP 7: INSTALL BRAKE FITTINGS

Install the 4 P/N 39005 Brake Line Fittings in the copilot P/N 39004 Master Cylinders.

STEP 8: INSTALL TOE PEDALS

Install the P/N 35006 Toe Brake Pedals onto the copilot Rudder Pedals with the tabs forward. The P/N 36005 Collars fit onto the ends of the P/N 35006's and the 35007's. Drill a 3/32" hole through each Collar and Toe Pedal and secure the Collars with an AN380-3-3 Cotter Pin. See Fig. LG-B-3.

STEP 9: FIT MASTER CYLINDERS

The P/N 39004 Master Cylinders fit between the tabs on the Rudder and Brake Pedals on the left (pilot) side. Install them with the Brake Line Fittings aligned to the right.


STEP 10: CO-PILOT CYLINDERS

Install the P/N 39004 Master Cylinders on the right (co-pilot) side with the Fittings aligned to the left. Both sets of Master Cylinders are attached to the Brake Toe Pedals with AN3-6 Bolts and to the Rudder Pedals with AN3-10 Bolts and AN310-3 Castle Nuts with Washers on the AN3-10 bolts only. Secure the Nuts with AN380-2-2 Cotter Pins. Adjust the Brake Pedal angle to the Rudder Pedal by turning the upper Attach Fitting on each Cylinder

NOTE: You may have to relieve the tabs on the Brake Toe Pedals to fit the Master Cylinders.

	SkyStar .	Aircraft Corp	t Corporation	© 1992
ASSEMBLY	REVISION	DATE	SECTION	PAGE
Sub-Section "B" Braking System		Sept. 1, 1993 L	Landing Gear	LG-B-4

MODEL 4-1200



MODEL 4-1200

Sub-Section "B" Braking System

SkyStar REVISION

DATE Sept. 1, 1993


SECTION
Landing Gear

© 1992 PAGE

LG-B-5


Aircraft Corporation

STEP 11: INSTALL DUAL BRAKE LINES




The P/N 35001 Brake Lines can now be installed. Route a line from each pilot side Route the Lines from the outlet (lower) fittings around the left end of the Rudder Pedals and back along the left side of the cockpit. Take them under the seat to the back side of the aft Gear Attach Brackets and down the aft side of the Gear Legs to the Calipers. If you have installed the Speed Fairing Kit, run each Line down the routed slot in the aft Fairing. Be careful not to kink the Line. You may have to radius the slot in the top end of the wooden Fairing so the Brake Line will make a gentle curve into it.

Brake Line from fuselage to Gear



Brake Fluid Reservoir Installation Fig. LG-B-4

4-1200 Sub-Section "B" Braking System	MODEL ASSEMBLY	
" Braking System		
	REVISION	SkyStar
Sept. 1, 1993 Landing	DATE	SkyStar Aircraft Corporation
Landing Gear	SECTION	oration
LG-B-6	PAGE	© 1992



Brake Fluid Reservoir

STEP 12: INSTALL RESERVOIR

Install a P/N 94021 "T" Fitting in bottom of the P/N 35013 Reservoir. Install the P/N 35013 Remote Reservoir on the aft side of the upper Firewall, directly above pilot's pedals - see Fig. LG-B-4.

NOTE: Fabricate small aluminum clamps to hold the Lines secure to the floor. The 6R X 3/8" Truss Screws are provided for this purpose. Provide sufficient length on all Lines to allow full movement of Rudder Pedals without kinking the Lines.

STEP 13: CONNECTING LINES

Install Brake Lines between the Reservoir "T" and the top port in the Master Cylinders.

NOTE: The Plastic Brake Line Tubing routes down the rear edge of the Rear Gear Leg and can be secured with tie-wraps if Speed Fairings are not being used. If fabric is going to be applied to the Landing Gear it can be done at this time.

*Paint all non-painted parts at this time.

ASSEMBLY Sub-Section "B" Braking System REVISION REVISION Sept. 1, 1993 Landing Gear LG-B-7	SkyStar Aircraft Corporation © 1992
---	-------------------------------------

MODEL 4-1200

		j