
LANDING GEAR STEP Sub-Section "H"




The Step for the Landing Gear on the Speedster needs to be fitted prior to the covering of the Landing Gear Leg.

STEP 1: TRIM STEP

P/N 63900 comes as a rectangular shaped angle. Trim the corner from this angle to make a left and right hand Step. Lay out the screw holes and drill as in **Fig. LG-H-1**. Drill holes 3/16 in.

Nut Plates install on angle on Gear Leg



Fit Step to the Gear Leg

MODEL 4-1200


STEP 2: DRILL GEAR LEG

Place the 63900 Steps on the left and right Gear Legs, and after centering the Step, drill matching holes in the angle welded in the Legs for this purpose.

STEP 3: INSTALL NUT PLATES

Temporarily install the P/N 91175 Nut Plates with P/N 91119 Screws and drill through the flanges of the Nut Plates with a 3/32" (0.094) drill. Remove the Screws and fasten the Plates with P/N 91099 Driven Rivets.

	SkyStar .	SkyStar Aircraft Corporation	voration	© 1992
ASSEMBLY Sub-Section "H" Landing Gear Step	REVISION	Sept 1, 1993 Landing Gear	SECTION Landing Gear	PAGE LG-H-1



STEP 4: INSTALL P/N 62912 SHIELD

Trim the P/N 62912 Step Shield to match Gear Leg, and drill through the 63900 Step to position the holes in the Shield. Remove the Shield and the Step from the Gear Leg, as the leg must be covered and painted before final assembly.

Gear Leg with Step and Shield in place




Fig. LG-H-1

	SkyStar	SkyStar Aircraft Corporation	oration	© 1992
MODEL ASSEMBLY 4-1200 Sub-Section "H" Landing Gear Step	REVISION	Sept 1, 1993 Landing	SECTION Landing Gear	PAGE LG-H-2