PRINT AT 104%

H

BOOTLOAD HANDEBUG

Z ≤

DEBUG

SYMBOLS CLEAR

12-FEB-90 Handebug rev 1.43

							GO =>	HIDE ANDEBUG	
	60=> C	HANDEBUG					CONTINUE	PREFS	
	CONTINUE	PREFS					STEP	COLOR	
	STEP	COLOR WINDOW					STEP FLAT		
	FLAT	CART						46	
	DOWNLOAD	BOOT CART					DOWNLOAD	BOOT CART	
									ध
		LOAD/SAVE SETTINGS					UPLOAD	LOAD/SAVE SETTINGS	
	BUSMON	LOAD DEFS	SAVE TRACE				BUSMON	LOAD DEFS	SAVE TRACE
	FILL MEMORY	FOLLOW PC							т '''
	MEMORY BOOTLOAI	/ DEBUG					FILL MEMORY	FOLLOW PC	

CTRL-G - LOAD CARTRIDGE "ROM" SPACE CTRL-N - SYMBOLS IN NUMERICAL ORDER CTRL-S - VIEW SYMBOL TABLE CTRL-R - VIEW "ROM" SPACE / TOGGLE ROMO, 1 CTRL-Q - QUIT CTRL-D · VIEW DATA CTRL-C - VIEW CODE DISSASEMBLY BACKSPACE - VIEW HOWARD SPACE (TOGGLE) CTRL-A - SYMBOLS IN ALPHABETICAL ORDER CTRL-T - VIEW TRACE RAM OCBMOZYI

> CTRL-A - SYMBOLS IN ALPHABETICAL ORDER BACKSPACE - VIEW HOWARD SPACE (TOGGLE)

OTLOAD

Z ≤

NDEBUG

SYMBOLS

CLEAR

CTRL-C - VIEW CODE DISSASEMBLY

CTRL-N - SYMBOLS IN NUMERICAL ORDER CTRL-Q : QUIT CTRL-G - LOAD CARTRIDGE "ROM" SPACE CTRL-D - VIEW DATA

CTRL-S VIEW SYMBOL TABLE CTRL-R - VIEW "ROM" SPACE / TOGGLE ROMO, 1

CTRL-T - VIEW TRACE RAM

OCOMOZYI