Name + Athery Arya USN + 1B1418CSO2ON

Date = 23/09/2020

Prograin Title in LED FADING (Using Potentionneter)

Aint To demonstrate LED Fading come potention

Herrelweire Required
Archino Boxard
LED
Potentio Meter.

CODE +

int LED\_PIN =9;

Void Setup ()

{ seval begin (9600);

Pinnode (LED-PIN, OUTPUT);

y void loop ()

{ int analogyalue = analogRead (AD);

int buightness = Map (Canalog value, 0, 1023, 0,255).

Comalog write (LED\_PIN, buyhtness).

Several puint ("Analog: ").

Several puint ("Buightness: ").

Several print In (buightness).

clelay (100];

Circuit diagram.

