



IOTexp11

libraries.txt Library Manager ▼ sketch.ino #include <DHT.h>

```
#define DHTPIN A2
     #define DHTTYPE DHT22
     DHT dht(DHTPIN, DHTTYPE);
     float minTemp = 1000;
     float maxTemp = -1000;
10
     void setup() {
       Serial.begin(115200);
12
13
       dht.begin();
14
15
16
     void loop() {
       float tempC = dht.readTemperature();
17
       float tempF = dht.readTemperature(true);
18
19
       if (isnan(tempC)) {
20
         Serial.println("Error: Failed to read temperature!");
21
22
         return;
23
24
       if (tempF < minTemp) minTemp = tempF;</pre>
25
       if (tempF > maxTemp) maxTemp = tempF;
26
27
       Serial.print("Temperature: ");
28
       Serial.print(tempF);
29
       Serial.print("°F | Min: ");
30
       Serial.print(minTemp);
31
       Serial.print("°F | Max: ");
32
       Serial.print(maxTemp);
33
       Serial.println("°F");
34
```

Simulation









