

User Manual For BOM Creation Using Excel Template Sheet

Submitted to:



Bajaj Electricals Limited

Rustomjee Aspire, 7th Floor,
Bhanu Shankar Yagnik Marg,
Sion East,
Mumbai
Maharashtra – 400022, India

Submitted by:



Softcell Technologies Global Pvt. Ltd.

401, Mayfair Tower-1,
Wakdewadi, Shivajinagar,
Pune
Maharashtra – 411005, India.

Document History

Version	Date	Owner	Description
00	06-03-2024	Softcell Technologies Global Pvt. Ltd.	BOM Creation Using Excel Template Sheet

Document Author

Mr. Bhagyawan Solanke	bsolanke@softcell.com
-----------------------	--

Approved & Reviewed By

Mr. Ravichandran M A	ravichandran@softcell.com
Mr. Suresh Vasu	sureshv@softcell.com
Ms. Bhagyashree Kulkarni	bkulkarni@softcell.com

Contents

INTRODUCTION	4
Windchill URL and Navigation.....	5
Product Code Creation in Windchill	7
Using Import from Spreadsheet.....	8
Manually adding each Part	12
BOM IMPORT IN WINDCHILL	9

INTRODUCTION


This document is prepared to show the Windchill Excel Export/Import to built the EBOM structure and by utilizing the basic functionality of Windchill to modify the Bill of Material by adding and removing parts.

Windchill URL and Navigation

- Enter below URL in Web Browser and enter username and credential.


Windchill URL: - <http://belazplm-uat-ap.bel.com/Windchill/app>

Windchill Page will Open




- Navigate to Parts Library


Click on Navigate - Browse < Go to Library< CP & MR WTParts



- Click on Folders



- Create New Part



Product Code Creation in Windchill

Click on New part < Select “BEL_CP “ type, Fill At least mandatory attribute values

Then Click on Finish

New Part - Google Chrome

Not secure belazplm-uat-ap.bel.com/Windchill/ptc1/part/createPartWizard?revisionMode=crea...

New Part

1 Set Attributes

Library: CP & MR WTParts

* Type: BEL_CP

* Create as End Item: Yes

Part Attributes

* Base Code: Number: (Generated)

* Name:

* Assembly Mode:

* Source: Make

* Default Trace Code: Serial Number

* Default Unit: each

* Gathering Part: No

* Phantom Manufacturing Part: No

* Life Cycle Template: (Generated)

* Team Template: (Generated)

* Location: ☐ Autoselect Folder (/CP & MR WTParts) ☒ Select Folder /CP & MR WTParts


* Part Description:

* Segment:

* Indicates required fields.

Back Next Finish Cancel

Part get created without structure



Note: Here we have created BOM Structure Manually (Refer below Image)

Using Import from Spreadsheet.

Export Sheet Generation.

Open BOM Excel Template

	A	B	C	D	E	F	G	H	I	J
1	ImportSheetType=BOM									
2										
3										
4										
5	Action	Level	Number	Organization ID	Container	View	Quantity	Reference Designators	Line Number	Component Reference
6	Action	Level	Number	Organization ID	Container	View	Quantity	Reference Designators	Line Number	Component Reference
7		0		BEL	/wt.inf.container.OrgContainer=BEL/wt.inf.library.WTLibrary=CP & MR WTParts Design					
8	Add	1		BEL	/wt.inf.container.OrgContainer=BEL/wt.inf.library.WTLibrary=CP & MR WTParts Design		1		10	
9	Add	1		BEL	/wt.inf.container.OrgContainer=BEL/wt.inf.library.WTLibrary=CP & MR WTParts Design		2		20	
10	Add	1		BEL	/wt.inf.container.OrgContainer=BEL/wt.inf.library.WTLibrary=CP & MR WTParts Design		3		30	
11	Add	1		BEL	/wt.inf.container.OrgContainer=BEL/wt.inf.library.WTLibrary=CP & MR WTParts Design		4		40	
12	Add	1		BEL	/wt.inf.container.OrgContainer=BEL/wt.inf.library.WTLibrary=CP & MR WTParts Design		5		50	
13										


Copy only WTPart number from BOM report excel and prepare sheet.

User can provide line number and quantity value from excel sheet.

	A	B	C	D	E	F	G	H	I	J
1	ImportSheetType=BOM									
2										
3										
4										
5	Action	Level	Number	Organization ID	Container	View	Quantity	Reference Designators	Line Number	Component Reference
6	Action	Level	Number	Organization ID	Container	View	Quantity	Reference Designators	Line Number	Component Reference
7		0	CFG0000015	BEL	/wt.inf.container.OrgContainer=BEL/wt.inf.library.WTLibrary=CP & MR WTParts	Design				
8	Add	1	A0050AX3458	BEL	/wt.inf.container.OrgContainer=BEL/wt.inf.library.WTLibrary=CP & MR WTParts	Design	1		10	
9	Add	1	A0050AX3459	BEL	/wt.inf.container.OrgContainer=BEL/wt.inf.library.WTLibrary=CP & MR WTParts	Design	2		20	
10	Add	1	A0050AX3460	BEL	/wt.inf.container.OrgContainer=BEL/wt.inf.library.WTLibrary=CP & MR WTParts	Design	3		30	
11	Add	1	A0050AX3461	BEL	/wt.inf.container.OrgContainer=BEL/wt.inf.library.WTLibrary=CP & MR WTParts	Design	4		40	
12	Add	1	A0050AX3457	BEL	/wt.inf.container.OrgContainer=BEL/wt.inf.library.WTLibrary=CP & MR WTParts	Design	5		50	
13										
14										
15										

BOM IMPORT IN WINDCHILL

- Go To Library < CP & MR WTParts < Actions < Import Spreadsheet



Below Window will open

- Browse File < Import Action (ADD AND UPDATE) < Click Validate Spreadsheet
- After Successful Validation Click on Import

Import from Spreadsheet - Google Chrome

Not secure belazplm-uat-ap.bel.com/Windchill/ptc1/ixb/importer/import?ContainerOid=OR%3Awt.inf.li...

Import from Spreadsheet

1 2
Import Settings Preview

* Primary Content Source: Local File

* File Name: Template.xls **Browse...**

Attributes (2 objects)

Search in table

*	Name	Value
*	Import Action	ADD AND UPDATE
	Baseline	

Validate Spreadsheet **Resize table**

* Indicates required fields.

Next **Import** Cancel

- Part structure along with line number updated

windchill® wcadmin

All Types Search ... Quick Links

Libraries > CP & MR WTParts > A0050

Recently Accessed

Actions Concept FG Code - CFG0000015, FG_TEST_04032024, 00.3 (Design) Released

Details Structure Related Objects Changes History Where Used AML/AVL FG Code Vendor Details New Tab 1

Editing: Insert Existing, Remove, Check Out, Revise, Insert New, Edit, Check In, My Checkouts, Paste, Copy, Hide, Display, New, Add to

Filter: Current Filter, Path Filter, Saved Filters, Enter name or number, Compare, Open in

Find in Structure: All, Advanced, Latest, Design, Working

Object T...	Line Nu...	Number	Name	Quantity	Unit	Version	View
Conc		CFG0000015	FG_TEST_04032024			00.3 (Design)	Design
B 10		A0050AX3458	TEST-ASM_0403	1	each	00.3 (Design)	Design
B 20		A0050AX3459	TEST-Part01	2	each	00.2 (Design)	Design
B 30		A0050AX3460	TEST-Part_02	3	each	00.2 (Design)	Design
B 40		A0050AX3461	TEST-Part_03	4	each	00.2 (Design)	Design
B 50		A0050AX3457	TEST_04032024	5	each	00.2 (Design)	Design


Attributes	Classification	Visualization	Uses	Occurrences	Effectivity
Part	Number	Quantity	Unit	Name	Ver
A0050AX3457	5	each	TEST_04032024	00.2	
A0050AX3458	1	each	TEST-ASM_0403	00.3	
A0050AX3459	2	each	TEST-Part01	00.2	
A0050AX3460	3	each	TEST-Part_02	00.2	
A0050AX3461	4	each	TEST-Part_03	00.2	
Enter Number			Enter Name		

Manually adding each Part

Open the Part in which user wants to add BOM structure.


To add parts in BOM we have 2 options

1. Using Insert Existing option as shown below.




In this window search the part by using Number or Name search option.

Select the part and click on OK.




After this it will ask to fill some BOM related values add those and click on Ok.




2. Using the Enter Number and Enter Name option from Uses tab.

Enter some digits of number and select the part from the list which user wants to add.




After this it will ask to fill some BOM related values add those and click on Ok.




While adding the parts in BOM it will gets checked –out then after doing all the modification user need to check-in the BOM.

To check-in Go to Actions> Check-in.



Add comment if required and click on Ok.



Then the BOM structure will gets created manually as below.

Windchill interface showing the BOM structure for **BEL_CP - A0050AX3459, TEST-Part01, 00.3 (Design)**. The Structure tab is active, displaying a tree view of the BOM structure. The main table lists components with columns for Object Type, Line No., Change, Number, Name, Quantity, Unit, Version, and State.

Object Type	Line No.	Change	Number	Name	Quantity	Unit	Version	State
BEL_CP			A0050AX3459	TEST-Part01			00.3 (Design)	Design In Work
BEL_C 10			A0050A01061	CHUTNEY JA...	1	each	00.1 (Design)	Design In Work
BEL_C 20			A0010A00090	base_unit_eleg...	1	each	00.18 (Design)	Design In Work


BOM Report Export in Windchill

Open the FG or Part which has the BOM structure and Click on Actions tab.


Windchill interface showing the BOM report export process for **Concept FG Code - CFG0000013, Immorto_Popular Plus_New Shakti_15L, 00.14 (Design)**. The Structure tab is active, displaying a tree view of the BOM structure. The main table lists components with columns for Object Type, Line No., Change, Number, Name, Quantity, Unit, Version, and State.

Object Type	Line No.	Change	Number	Name	Quantity	Unit	Version	State
Concept FG Co			CFG0000013	Immorto_Popular Plus_New Sha...				
Other Parts			00003213	Polythene Bag (Water Heater)	1	each	00.3 (Design)	P
Other Parts			00003214	POLYTHENE BAG (CABLE) GR.	1	each	00.3 (Design)	P
Other Parts			00003215	RATING LABEL 15L IMMORTO	1	each	00.2 (Design)	U
Other Parts			00003216	PRODUCT BRANDING 15L IMM	1	each	00.2 (Design)	U
Other Parts			00003217	MANUAL IMMORTO	1	each	00.2 (Design)	U
Other Parts			00003218	CAUTION TAG FOR MULTIFICA	1	each	00.2 (Design)	P
Other Parts			00003219	WIRING DIAGRAM STICKER-1	1	each	00.2 (Design)	U
Other Parts			00003220	CHILD SAFETY CAUTION STIC	1	each	00.2 (Design)	U
Other Parts			00003221	WARRANTY CARD- 15L IMMOR	1	each	00.2 (Design)	P
Other Parts			00003222	BEE LABEL- 15L IMMORTO	1	each	00.2 (Design)	U
Other Parts			00003223	BOPP TAPE NEW SHAKTI 10L	1	each	00.2 (Design)	U
Other Parts			00003224	STRAP ROLL-ALL MODELS (S	1	each	00.2 (Design)	U
Other Parts			00003225	KNOB UI GRAPHICS 15L IMM	1	each	00.2 (Design)	U
Other Parts			00003226	CAUTION STICKER- ALL MODE	1	each	00.2 (Design)	U
Other Parts			00003227	ACCESSORIES STICKER- GRA	1	each	00.2 (Design)	P
Other Parts			00003228	ACCESSORY POUCH KIT SWH	1	each	00.2 (Design)	P
Other Parts			00003229	QR CODE STICKER- 15L IMM	1	each	00.2 (Design)	P
Other Parts			00003230	HO CYDRAM, ALL MODELS (S	1	each	00.2 (Design)	P

Then click on the Bajaj Multi BOM report option from Actions Menu.



Click on OK to download the BOM report.



User will get the BOM report in Bajaj format as shown below.

A B C D E F G H I J K L M N O P Q R S T U V W X Y Z AA A																						
BILL OF MATERIAL											Format No. ABS/ED/5/009											
											Format Rev. No. 2											
											Format Rev Date 29.12.2022											
Product : Consumer Product											PRD By : Edwaterheater Plm		BOM No. CJ/BOM/2223/WH/D168									
Model : Immorto_Popular Plus_ New Shakti_15L											CXD By :		BOM Rev No. BD									
Project No :											APRD By :		BOM Rev Date 16-06-2023									
Date : 2023-12-08 06:04:32.0											NPD No. : CFG0000013											
Sr.No.											Description		Qty(Nos)		Legacy Part Number		Matl Specification / Drawing		P/M/U type		Remark	
0											Immorto_Popular Plus_ New Shakti_15L		0		CFG0000013							
1											ACCESSORY POUCH KIT SWH (pouch)-		1		00003228				P			
1											WIRING DIAGRAM STICKER- IMMORTO-		1		00003219				U			
1											BATING LABEL 15L IMMORTO		1		00003215				U			
1											PANEL STICKER ON BODY-15L IMMORTO		1		00003232				U			
1											TOP EPS-IMMORTO-15L		1		P0240A03173		As per file		U			
1											IMMORTO-15L MAIN ASSEMBLY		1		A0050A01691		PLEASE SEE DRAWING		U			
2											WALL MOUNTING BRACKET-IMMORTO-		1		M0010A01692		PLEASE SEE DRAWING		U			
2											TANK ASSEMBLY-15L IMMORTO		1		A0050A01685		PLEASE SEE DRAWING		U			
3											INNER INLET PIPE-ALL IMMORTO &		1		M0020A00531		PPTF 20%		U			
3											INNER OUTLET PIPE ASSEMBLY-		1		A0050A00530		55304		U			
3											BOTTOM DOME 15L- GRACIO-		1		M0010A01669		PLEASE SEE DRAWING		P			
3											TANK HOOK (EAR)		2		M0010A00527		MS		P			
3											LOCKING FLANGE		1		M0010A00529		MS		P			
3											TOP DOME- 15L GRACIO-IMMORTO		1		M0010A01668		PLEASE SEE DRAWING		P			
3											IN-OUT OUTER PIPE-MS- ALL IMMORTO		2		M0010A01325		L-105MM, MATL-MS		U			
3											GL VERTICAL TANK FLANGE		1		M0010A00594		PLEASE SEE DRAWING		P			
3											TANK BRACKET- 15L IMMORTO		1		M0010A01686		PLEASE SEE DRAWING		U			
2											TOP COVER 15L IMMORTO		1		M0020A01682		PLEASE SEE DRAWING		U			
2											SHEET METAL BODY-15L IMMORTO		1		M0010A01681		PLEASE SEE DRAWING		U			
2											EPDM PAD - 6 HOLE		1		B0360A00916		PLEASE SEE DRAWING		P			
2											WASHER-PLAIN-MS		8		H0060A00548		MS PLAIN WASHER		P			
2											SERVICE COVER- 15L IMMORTO		1		M0020A01684		PLEASE SEE DRAWING		U			
2											TANK REST- IMMORTO		1		M0020A00521		PPTF 20%		U			
2											SCREW 6 x 13 MS		4		H0050A00142		MS ZINC COATING 6-8		P			
2											EVA FOAM NECK SEAL 10L, 15L & 25L		1		B0340A01664		PLEASE SEE DRAWING		P			
2											CAPILLARY HOLDER		1		M0010A00544		MS PART		P			
2											GLASS WOOL- IMMORTO-6L		1		B0390A00559		DIA"7", THICK"7"		P			
2											PENTACLE EPDM PIPE		2		M0070A00695		ID.=19, OD.=31, L=50,		P			

Activate windows
Go to Settings to activate Windows