

User Manual
For
Copy BOM Structure from Concept FG to
FG Part.

Submitted to:



Bajaj Electricals Limited

Rustomjee Aspire, 7th Floor,
Bhanu Shankar Yagnik Marg,
Sion East,
Mumbai
Maharashtra – 400022, India

Submitted by:



Softcell Technologies Global Pvt. Ltd.

401, Mayfair Tower-1,
Wakdewadi, Shivajinagar,
Pune
Maharashtra – 411005, India.

Document History

Version	Date	Owner	Description
00	07-03-2024	Softcell Technologies Global Pvt. Ltd.	Copy BOM Structure from Concept FG to FG Part.

Document Author

Mr. Sumit Garade	sagarade@softcell.com
------------------	--

Approved & Reviewed By


Mr. Ravichandran M A	ravichandran@softcell.com
Mr. Suresh Vasu	sureshv@softcell.com
Ms. Bhagyashree Kulkarni	bkulkarni@softcell.com

Contents


Create BOM structure In Concept FG Part:-	4
Create the same BOM structure to FG Part type:-	6

Create BOM structure In Concept FG Part:-


- To create the Concept FG code user have to click on the New Part Icon.




- Select the Type Concept FG Code and fill all required information and click on Finish.



- Concept FG Code will get created as shown below.
- To add the assembly BOM structure below FG code user has to copy the Main assembly number.




- In this case copy main assembly number.



Create the same BOM structure to FG Part type:-


- Paste the assembly number in Enter Number field in Uses tab and select the Assembly it will get added to FG code BOM structure.



This screenshot shows the Windchill interface for a Concept FG Code. The 'Uses' tab is active, displaying a table with columns: Part Group, Number, Quantity, Unit, Name, Version, Line Number, Remarks, P/MU T..., Vendor, Source, and Default. The table contains one entry: A0050AX3458, 1, each, TEST-ASM_0403 00.3 (Design), 10, P, Make, Untraced. Below the table, there are input fields for 'Enter Number' and 'Enter Name'. The 'Enter Number' field is highlighted with a red rectangle.

Part Group	Number	Quantity	Unit	Name	Version	Line Number	Remarks	P/MU T...	Vendor	Source	Default
A0050AX3458	1	each		TEST-ASM_0403	00.3 (Design)	10		P		Make	Untraced


- To check all levels user can expand the BOM structure as shown below.




This screenshot shows the same Windchill interface, but the BOM structure is expanded. The 'Identity' pane on the left shows a tree view with the following items: CFG0000015, FG_TEST_04032024, 00.2 (Design); A0050AX3458, TEST-ASM_0403, 00.3 (Design); A0050AX3459, TEST-Part01, 00.2 (Design); A0050AX3460, TEST-Part_02, 00.2 (Design); A0050AX3461, TEST-Part_03, 00.2 (Design); and A0050AX3462, TEST-Part_04, 00.2 (Design). The 'Uses' tab is still active, showing the same table as in the first screenshot.

Part Group	Number	Quantity	Unit	Name	Version	Line Number	Remarks	P/MU T...	Vendor	Source	Default
A0050AX3458	1	each		TEST-ASM_0403	00.3 (Design)	10		P		Make	Untraced


- When user creates the Final FG code then he will copy the same BOM structure from Concept FG code as shown below.
- Note- Select all the Parts and right click to get Copy option.




- After this open the FG code in which user wants to add all the BOM structure from Concept FG code and Paste into the system (right click on the FG code number to get Paste Option)
- Note- User will able to add BOM structure in FG code or in any Part Code when its state is In Work Only.




- After selecting paste option Edit usage attributes window will Pop-up and in this user need to fill the required and mandatory attribute value for BOM parts. For Ex- P/M/U Type.




- As we are editing the FG code BOM structure it will get checked-out and after all modification user need to check-in the FG code.



- To check-in go to Action > Check In.



- Add comments if required and click on Ok to check-in the FG code.



windchill

wcadmin

All Types

Search

Quick Links

Products > Consumer Product > WTParts

Recently Accessed

Actions

FG_CP - 440194, Majesty MX 100, 00.2 (Design)

In Work

Details

Structure

Related Objects

Changes

History

Where Used

AML/AVL

FG Code Vendor Details

Editing

Check Outlin

Clipboard

Viewing

New/Add To

Filter

Tools

Reports

Insert Existing

Remove

Check Out

Revise

Check In

My Checkouts

Paste

Copy

Show

Views

Hide

Display

New

Add to

Edit Filter

Current Filter

Saved Filters

Enter name or number

Compare

Open in

Reports

Export

Find in Structure

All

Advanced

Latest

Design

Working

Loaded 6 objects

Object Type

Line No.

Number

Name

Quantity

Unit

Version

View

State

FG_CP

440194

Majesty MX 100

00.2 (Design)

Design

In Work

BEL_C

A0050AX3457

TEST_04032024

1

each

00.2 (Design)

Design

In Work

BEL_C

A0050AX3458

TEST-ASM_0403

1

each

00.3 (Design)

Design

Released

BEL_C

A0050AX3459

TEST-Part01

1

each

00.2 (Design)

Design

Released

BEL_C

A0050AX3460

TEST-Part_02

1

each

00.2 (Design)

Design

Released

BEL_C

A0050AX3461

TEST-Part_03

1

each

00.2 (Design)

Design

Released

BEL_C

A0050AX3462

TEST-Part_04

1

each

00.2 (Design)

Design

Released

Attributes

Classification

Visualization

Uses

Occurrences

Effectivity

Supersedes

Documents

Part Gro.

Number

Quantity

Unit

Name

Version

Line Number

Remarks

PMU T...

A0050AX3457

1

each

TEST_04032024

00.2 (Design)

P

A0050AX3458

1

each

TEST-ASM_0403

00.3 (Design)

P

A0050AX3459

1

each

TEST-Part01

00.2 (Design)

P

A0050AX3460

1

each

TEST-Part_02

00.2 (Design)

P

A0050AX3461

1

each

TEST-Part_03

00.2 (Design)

P

A0050AX3462

1

each

TEST-Part_04

00.2 (Design)

M

Enter Number

Enter Name

Activate Windows

Go to Settings to activate Windows.

Displaying 1 - 6 of 6