Συστήματα Μικροϋπολογιστών 6ο Εξάμηνο 6η Ομάδα Ασκήσεων

Χαρδούβελης Γεώργιος-Ορέστης Κυριάκου Αθηνά

el15100 el17405 6ο Εξάμηνο 6ο Εξάμηνο

Άσκηση 1:

Το πρόγραμμα που ζητείται είναι το εξής:

```
.INCLUDE "m16def.inc" ; δηλώνουμε μικροελεγκτή
.def temp = R16 ; ονομάζομαι temp έναν καταχωρητή
.def Delay0 = r17
                    ; ορίζουμε την καθυστέρηση όταν τα led θα είναι σβηστά
.def Delay1 = r18
                   ; ορίζουμε την καθυστέρηση όταν τα led θα είναι ανάμμένα
main:
       clr temp
       out DDRD,temp ; ορίζουμε DDRD ως θύρα εισόδου.
       ser temp
       out DDRB,temp ; ορίζουμε DDRB ως θύρα εξόδου.
       out PORTD, temp ; τίθενται οι αντιστάσεις πρόσδεσης pull-up.
       ldi Delay0,50 ; αν το MSB της εισόδου είναι 0 θα έχουμε 0 (σβηστά led) για
50*(10ms)
       ldi Delay1,150 ; και θα έχουμε 1 (αναμμένα led) για 150*(50ms)
       sbic PIND, 0x07 ; αν το MSB της εισόδου είναι 1 αλλάζουμε το delay του 0, αλλιώς
όχι.
       Idi Delay0,150;
       sbic PIND, 0x07 ;Αντίστοιχα, αλλάζουμε και το delay του 1
       Idi Delay1,50;
leds_on:
       Idi temp,0xFF
       out PORTB, temp ; ανάβουμε όλα τα leds
       //rcall Delay10 ;καλούμε την Delay10 για Delay1 φορές
       dec Delay1
       brne leds on
leds_off:
       ldi temp,0x00
       out PORTB, temp ; σβήνουμε όλα τα leds
       //rcall Delay10 ;καλούμε στην Delay10 για Delay0 φορές
       dec Delay0
       brne leds off
       rjmp main ;επιστρέφουμε πάλι στην αρχή
```

Άσκηση 2:

Το ζητούμενο πρόγραμμα σε Assembly για τον μικροελεγκτή AVR είναι:

```
.include "m16def.inc"
.DEF temp=R21
.DEF F0=R16
.DEF F1=R17
.DEF F2=R18
.cseg
.org 0
       clr temp
                            ;initialize all the bits of temp to 0
       out DDRD,temp
                            ;set PORT D as output
       ser temp
                            ;initialize all the bits of temp to 1
       out DDRB, temp
                            ;set PORT B as input
       out PORTD, temp
                            ;pull-up of PORT D
again:
       clr F2
                            ;F2 initialized to zero
       in temp, PIND
                            ;input in temp
       mov F0,temp
       andi F0,0x01
                            ;F0<-A
       BREQ ONE F0
                            :F0=1 if A=1 OR BC'D'=1
       mov F0,temp
                            ;if A is not 1, check if BC'D'=1
       andi F0,0x0E
                            ;keep BCD
       cpi F0,0x02
                            ;F0=1 if B=1
       breq ONE F0
       clr F0
                            :F0=0
       rjmp L_F1
ONE F0:
       ldi F2,0x80
                            ;F2 turns 1
       ldi F0,0x20
L F1:
       mov F1,temp
                            ;F1=1 if E=G=1 or (A=C=0 and B=D=1)
       andi F1,0x30
                            ;keep only the bits corresponding to E,G
       cpi F1,0x30
       breq ONE_F1
                            ;if E or G != 1, check if A'BC'D=1
       mov F1,temp
       andi F1,0x01
                            ;F1<-A
       com F1
                            ;F1<-A'
```

```
andi R19,0x02
                           ;R19<-B
             R19
                           ;B in the LSB
      and F1,R19
                           ;F1<-A'B
      mov R19,temp
      andi R19,0x04
                           ;R19<-C
                           ;F1<-C'
      com R19
      Isr R19
      Isr R19
      and F1,R19
                           ;F1<-A'BC'
      mov R19,temp
      andi R19,0x08
                           ;R19<-D
      Isr R19
      Isr R19
      Isr R19
      and F1,R19
                           ;F1<-A'BC'D
      cpi F1,0x01
      breq ONE_F1
      clr F1
      clr F2
                           ;F2 turns 0
      rjmp END
ONE_F1:
      Idi F1,0x40
END:
      clr temp
                           ;temp initialized to 0, will hold the final result
      or temp,F0
      or temp,F1
      or temp,F2
      out PORTB, temp
      rjmp again
Το πρόγραμμα σε γλώσσα C ενσωματωμένων συστημάτων είναι:
#include <avr/io.h>
unsigned char A, B, C, D, E, G, F0, F1, F2, temp;
int main(void){
      DDRD = 0x00;
                                         //configure portD as input
```

mov R19,temp

```
PORTD = 0xFF;
                                             //Turn ON LEDs of input
       DDRB = 0xFF;
                                             //configure portB as output
       while(1)
       {
               A = PIND;
                                             //Read 8 bits of port PIND (switches), store
them in register A
               B = PIND;
                                             ///Read 8 bits of port PIND again(switches),
store them in register B
               C = PIND;
               D = PIND;
               E = PIND;
               G = PIND:
               A >>= 0;
                                             //Shift register A zero positions right, interested
bit already in the LSB position
               B >>= 1:
                                             //Shift register B one position right, to take
interested bit in the LSB position
               C >>= 2;
               D >>= 3;
               E >>= 4;
               G >>= 5;
               //All of our caclulations will take place with the LSB element of each register
               F0 = A \mid (B \& (\sim C) \& (\sim D));
               F1 = ((\sim A) \& B \& (\sim C) \& D) | (E \& G);
               F2 = F0 & F1;
               F2 &= 1;
               F1 &= 1;
               F0 &= 1;
               //Bring each register to the correct position, unite them with "or" operation and
upload the result into LEDS
               //via PortB
               F2 <<= 7:
               F1 <<= 6;
               F0 <<= 5;
               F2 = F2 | F1 | F0;
               PORTB = F2;
       };
       //We suppose display with high impudence (positive)
```

}

Άσκηση 3:

Ο κώδικας του προγράμματος που περιγράφεται στην παρούσα άσκηση είναι ο εξής:

```
.INCLUDE "m16def.inc" ; δήλωση του μικροελεγκτή
.DEF reg = R16
.DEF temp = R17
main:
  clr reg
  out DDRB,reg ; ορισμός DDRB ως θύρα εισόδου
  ser reg
  out DDRD,reg ; ορισμός DDRD ως θύρα εξόδου
  out PORTD,reg ; τίθενται οι αντιστάσεις πρόσδεσης pull-up
  out PORTD,reg ; ανάβουμε τα leds (ανάστροφη λογική)
loop:
  sbis PINB,4 ; αν δεν έχει πατηθεί ο sw4 προσπερνάνε την επομενη εντολή
  rjmp sw4
               ; αν έχει πατηθεί πηγαίνουμε στο sw4 (προτεραιότητα από sw4 προς sw0)
  sbis PINB,3 ; αν δεν έχει πατηθεί ο sw3 προσπερνάνε την επομενη εντολή
              ; αν έχει πατηθεί πηγαίνουμε στο sw3
  rjmp sw3
  sbis PINB,2 ; αν δεν έχει πατηθεί ο sw2 προσπερνάνε την επομενη εντολή
      rjmp sw2
                   ; αν έχει πατηθεί πηγαίνουμε στο sw2
      sbis PINB,1 ; αν δεν έχει πατηθεί ο sw1 προσπερνάνε την επομενη εντολή
      rjmp sw1
                   ; αν έχει πατηθεί πηγαίνουμε στο sw1
      sbis PINB,0 ; αν δεν έχει πατηθεί ο sw0 προσπερνάνε την επομενη εντολή και
γυρνάμε πίσω στο loop
      rjmp sw0
                   ; αν έχει πατηθεί πηγαίνουμε στο sw0
      rimp loop
sw4:
      ldi reg,0xFF ; σβήσιμο όλων των led (ανάστροφη λογική)
      out PORTD,reg
  sbic PINB,4
              ; μέχρι να επανέλθει ο αντίστοιχος διακόπτης συνεχίζουμε στο sw4
      rjmp loop
                   ; αλλιώς επιστρέφουμε στο loop
      rjmp sw4
sw3:
  mov temp,reg ; αποθήκευση της προηγούμενης κατάστασης για αν επιστρέψουμε σε
αυτή όταν
      ldi reg,0xFF ; επανέλθει ο διακόπτης
  CLc
             ; μηδενισμός κρατούμενου έτσι ώστε μετά το shift να ανάψει πρώτο το led
που αντιστοιχέι στο LSB
loop_sw3:
  rol reg
            ; κάνουμε shift αριστερά και εμφανίζουμε
      out PORTD,reg
      //call Delay500 ; καθυστέρηση για 0.5 sec
  sbic PINB,3 ; μέχρι να επανέλθει ο αντίστοιχος διακόπτης συνεχίζουμε στο lopp_sw3
```

```
rjmp sw3_end ; αλλιώς πηγαίνουμε στο sw3_end
      rjmp loop_sw3
sw3 end:
  mov reg,temp
  out PORTD, temp ; επαναφορά στην τελευταία κατάσταση των leds πριν πατηθεί ο
διακόπτης
  rimp loop
              ; και επιστροφή στην αρχή
sw2:
  mov temp,reg ; αποθήκευση της προηγούμενης κατάστασης για αν επιστρέψουμε σε
αυτή όταν
  Idi reg,0xFE ; επανέλθει ο διακόπτης
             ; κάνουμε το κρατούμενο 1 έτσι να λειτουργήσει σωστά το shift στη συνέχεια
loop sw2:
      out PORTD,reg ; εμφανίζουμε πρώτα και μετά κάνουμε shift
      //call Delay500 ; καθυστέρηση για 0.5 sec
      ror reg
      sbic PINB,2 ; μέχρι να επανέλθει ο αντίστοιχος διακόπτης συνεχίζουμε στο
lopp_sw2
      rjmp sw2 end ; αλλιώς πηγαίνουμε στο sw2 end
      rjmp loop sw2
sw2 end:
  mov reg,temp
  out PORTD,temp ; επαναφορά στην τελευταία κατάσταση των leds πριν πατηθεί ο
διακόπτης
  rjmp loop ; και επιστροφή στην αρχή
sw1:
      Idi reg,0x0F ; ανάβουμε τα led4-7 και σβήνουμε τα led0-3 (αρνητική λογική)
      out PORTD,reg
      sbic PINB,1
                    ; μέχρι να επανέλθει ο αντίστοιχος διακόπτης συνεχίζουμε στο sw1
                   ; αλλιώς επιστρέφουμε στο loop
      rjmp loop
      rjmp sw1
sw0:
      ldi reg,0xF0 ; ανάβουμε τα led0-3 και σβήνουμε τα led4-7 (αρνητική λογική)
      out PORTD,reg
      sbic PINB,0
                    ; μέχρι να επανέλθει ο αντίστοιχος διακόπτης συνεχίζουμε στο sw1
      rjmp loop
                   ; αλλιώς επιστρέφουμε στο loop
      rjmp sw0
```

Άσκηση 4

Το πρόγραμμα σε assembly φαίνεται εδώ:

.include "m32def.inc" ;Define microcontroller

```
.def tmp = r16
.def LEDs = r17
                                    ;Interrupt1 in PD3 <=> r17
.def delay1 = r19
.def delay2 = r20
.def delay3 = r21
       ;Set up the interrupt vector
       imp reset
                                            ;Reset Handler
       .org INT1addr
                                    ;INT1addr is the address of EXT INT1
       jmp interrupt1
                                    ;IRQ1 Handler
;note: it so happens that INTO is hooked up to the PDO pin for the mega 32
;Here is the mapping:
;INT0: PD0
;INT1: PD1
;(from pg2 of atmega32 datasheet)
reset:
       ;Initialize stack in the last position of the RAM
       Idi tmp,high(RAMEND)
                                    ;Set pointer of stack to the RAM, RAMEND value is
coming of microcontroller's model
       out SPH,tmp
       Idi tmp,low(RAMEND)
       out SPL,tmp
       ;Set DDRC to 0xFF. DDRC is data direction register C. There 8 pins, so setting 8 bits
to 1 sets, sets the 8 pins for output
       ser tmp
       out DDRC,tmp
                                            ;digits of portC became output for the LEDs
       ldi tmp, 1<<INT1
                                    ;1000\ 0000\ (INT1 = 7)
       out GIMSK,temp
                                            ;Activate external interrupt 1, since general
register mask of interrupts is
                                                   responsible for activating/disactivating
interrupts
       Idi temp, 0b00001100
                                     ;Defining interrupt 1 to be executed in a rising edge, or
"Idi temp, (1 << ISC11) | (1 << ISC10)""
       out MCUCR, temp
       sei
                                            ;Activate all interrupts masked, here just INT1
                                                   ;Global Interrupts MUST be enabled for
the microcontroller to react to the interrupt event.
```

```
;Routine to wait for exeternal interrupt (press of button 3 - PD3)
wait:
       rimp wait
;This is the handler for PushButton3
interrupt1:
       ;Push conflic registers
       push tmp
       in tmp, SREG
       push tmp
;Before starting the main operation of 1 minuted turned on LEDs, they must firstly blink for 5
secs
       ldi tmp, 5
                                            ;(tmp) = 5
blinking:
       dec tmp
       ser LEDs
       out PORTC, LEDs
       rcall Delay
       clr LEDs
       out PORTC, LEDs
       rcall Delay
       brne blinking
main operation:
       ;Turn on LEDs
       ser LEDs
       out PORTC, LEDs
       ldi tmp, 120
                                     ;(tmp) = 120
;Keep LEDs turned on for 60 sec = 1 minute, by calling DELAY routine 120 times since 1
DELAY equals to 0.5 sec time delay
;Total Delay = 120 \times 1/2 \sec = 60 \sec
interrupt1_loop:
       dec tmp
       rcall Delay
                                     ;We use rcall so that when the PC gets to a "ret"
statement it will come back to the line following rcall.
       brne interrupt1_loop
       ;After 60 secs having passed, turn off the LEDS by assigning
       clr LEDs
       out PORTC, LEDs
```

```
;Restore conflict registers
       pop tmp
       out SREG, tmp
       pop tmp
       reti
                                           ;Interrupt Return, address was loaded from
stack. Exiting the ISR, and automatically
                                                   ;re-enabling the Global Interrupt Enable
bit.
Delay:
       ldi Delay1, 3
       ldi Delay2, 138
       ldi Delay3, 90
D1:
       dec Delay3
       brne D1
       dec Delay2
       brne D1
       dec Delay1
       brne D1
       ret
Το πρόγραμμα C φαίνεται εδώ:
#include <stdio.h>
#include <stdlib.h>
#include <avr/io.h>
#include <avr/interrupt.h>
#define F_CPU 4000000UL
#include <util/delay.h>
#define DataPort
                             PORTC
                                                   //Using PortC as our Dataport
#define DataDDR
                             DDRC
unsigned char counter, leds;
/* External Interrupt 0 service routine. When a new putton is pressed
counter initialized to 120 and the interrupts starts over again
to complete 60 secs*/
void ext_int1_isr(void){
       int i:
       counter = 120;
```

```
/* This for loop blink LEDs on Dataport 5 times
       before LEDs turned on for 1 minute !!*/
       for(i = 0; i < 5; i++){
              DataPort = 0x00;
              _delay_ms(500);
                                                   //Turn on 0.5 sec
              DataPort = 0xFF;
                                                   //Turn off 0.5 sec
              _delay_ms(500);
       }
       leds = 0xFF;
                                                   //Leds are ON when interrup1 starts
       DataPort = leds;
       //Implement total delay = 120 \times 1/2 \sec = 60 \sec
       while(counter!=0){
              _delay_ms(500);
       }
       leds = 0x00;
                                                   //Leds are OFF when interrupt1 finishes
       DataPort = leds;
}
int main(void){
       DDRD = 1 << PD3;
                                                           //Set PD3 as input (using for
interrupt 1) =>Configure PortD as input
       PORTD = 1<<PD3;
                                                   //Enable PD3 pull-up resisotr. Turn on
the leds of input
       DataDDR = 0xFF;
                                                           //Configure Dataport as output
       DataPort = 0x00;
                                                   //PortC as output
       GIMSK = (1 << INT1);
                                                   //Activate external interrupt1, INT1:0N
       MCUCR = 1<<ISC11 | 1<<ISC10; //INT1 mode: activated in the a rising edge
       sei();
                                                           //Activate all interrupts masked,
here just INT1. Enable Global Interrupt
       /*Continuous operation of our program, wait for an interrupt*/
       while(1);
}
```