



Clayton Boiler Stand-By Procedure

Procedure #2

Prepared by:

Andy Gomes

Approved by:

Clive Baek

Review Date: March 2026

Original Date: January 2017

The Clayton Boiler uses the main steam pressure transmitter located on the boiler steam header while in stand-by mode. It will automatically come online if steam demand exceeds the capacity of the C.B. Boiler.

Clayton Boiler Wet Stand-By Procedure

Step	Operation	Initial when Complete	Date and Time when Complete
Note: The Auxiliary Standby (AUX) mode can only be achieved in AUTO operation.			
1	Ensure the boiler is shutdown. Press in the Red-Stop-Button .		
2	Place the boiler into AUX mode. This is done by pressing the ESC Aux button. The word AUX will display on the auxiliary section of the display.		
3	Place the boiler into automatic by pressing the Auto Manual button.		
4	Pull out the Red-Stop-Button .		
5	Press the Green-Start-Button . The feedwater pump will start pumping to fill the coil.		
6	Open the main stop valve.		
7	Make an appropriate log book entry.		

Notes:

- Clayton Industries recommends that if a boiler requires a dry shutdown lasting more than 7 days without continuous feedwater recirculation, the heating coil must be complete dry and protected with a nitrogen purge to prevent corrosion of metal surfaces.
- Although the dry shutdown procedure is detailed in the Clayton Industries documentation, it is UBC policy to have Clayton Industries on site to oversee

----- End of Procedure -----