



Procedure #3

Prepared by:
Andy Gomes

Approved by:
Clive Baek

Review Date: March 2026

Original Date: January 2017

CLAYTON BOILER WET SHUTDOWN PROCEDURE

The purpose of a wet shutdown is to maintain a filled heating coil with properly treated feedwater to prevent corrosion within the heating coil for up to a maximum of 7 days.

Become familiar with the entire procedure before commencing.

Only qualified and trained personnel are to implement this procedure. Refer to the Clayton Operating Manual for full procedures. In general, either the Clayton Boiler or C.B. Boiler will be designated as the lead boiler while the other is in stand-by with all valves set as indicated on the P&IDs.

ASSUMPTIONS:

- The C.B. Boiler is set to carry load once the Clayton is in Wet Shutdown mode.
- Any scheduled blow down operations are to be performed at least one hour prior to starting the wet shutdown procedure.
- The Red-Stop-Button will be left in the pulled-out position during the entire wet shutdown period.
- The intermittent fill auto control will cycle the feedwater pumps periodically during the wet shutdown period.

Clayton Boiler Wet Shutdown Procedure

Step	Operation	Initial when Complete	Date and Time when Complete
1	Place the running Clayton boiler into Auto mode using the Auto Manual button on the Clayton OIU.		
2	Press the Auto-Shut-Down-Button on the boiler control panel. (The boiler will begin the post-purge cycle.)		
3	Verify the C.B. Boiler is maintaining header pressure.		

Step	Operation	Initial when Complete	Date and Time when Complete
Note: After the post-purge cycle, the CLAYTON OIU may still display post-purge while the fans have shutdown. This message will continue to display until the boiler has cooled down to a pre-set temperature.			
4	Verify the feedwater pump is still running.		
Note: Feedwater will continue flowing through the boiler until the coil reaches the preset low temperature limit. The feedwater pump will then go into intermittent operation.			
5	Ensure the boiler has entered stand-by mode (intermittent operation of the feedwater pump).		
6	Close the main stop valve (chain operated valve).		
7	Partially open valve C-31 to allow condensate to flow back to the Hotwell.		
8	Partially open valve S-87 and the bypass valve for the trap upstream of the main stop valve. This will reduce water hammer taking place as the boiler cools down.		
9	Close the valves from step 8 once water hammer subsides.		
10	Make an appropriate log book entry.		
End of Procedure			