



Procedure #9

Prepared by:

Andy Gomes

Approved by:

Clive Baek

Review Date: March 2026**Original Date: January 2017**

CLEAVER BROOKS BOILER (B2) WET LAY-UP PROCEDURE

Wet Lay-up procedure should be **repeated every two weeks**, as the Sulphite level in the boiler water starts to diminish.

C.B Boiler (B2) Wet Lay-Up Procedure			
Step	Operation	Initial when Complete	Date and Time when Complete
1	Shutdown the C.B. Boiler on the control panel by turning the toggle switch to off. If the boiler is already off and cooled, please skip to step #6		
2	Close the main steam valve on the C.B. Boiler (B2) to the header.		
3	Open the vent line on the side of the C.B. Boiler (B2) by opening the gate valve slowly.		
4	Allow for all the pressure inside the C.B. Boiler (B2) to be released.		
5	Once all the C.B. Boiler (B2) pressure has been released, please close the vent line.		
6	Power on EMM60 switch (right side of the C.B. Boiler control cabinet.		
7	Open the vent line on top of the right side water column (this line feeds into the safety valve drain)		

8	Turn the feed water pump on hand and toggle it (on and off) until the C.B. Boiler (B2) is full of water.		
9	The water will start coming out of the water column vent line.		
10	Turn the feed water pump to the off position and lock out the pump.		
11	Power off and lock out EMM60 switch		
	End of Procedure.		