


Pure Performance

The Digi is a desktop dashboard that monitors Atlantium Systems.

Topology



The image shows a web browser window displaying the login page for 'digi by Atlantium'. The browser's address bar shows 'http://192.168.1.100:8080/'. The page has a white background. At the top left, the logo 'digi by Atlantium' is displayed, with 'digi' in teal and 'by Atlantium' in grey. Below the logo, the text 'Welcome !' is shown in a bold, dark blue font. The login form consists of two input fields: 'Username' with the placeholder text 'you@company.com' and 'Password'. Below the password field is a link for 'Forgot Password ?'. A checkbox labeled 'Remember Me ?' is checked. At the bottom of the form is a teal 'Log In' button. On the right side of the page is a large, square image with a teal, wavy, water-like background and a large, light grey, stylized 'd' logo in the center. The browser window has a dark blue header bar with standard window controls (minimize, maximize, close) on the right. At the bottom of the browser window, a status bar shows 'SW ver: 10.0.1.0' on the left and a small logo on the right.

Overview

The digi monitor provides real-time oversight of multiple systems, showing status (Operational, Malfunction, Disconnected), key metrics like Dose, UVT, Flow, and Power, and tools for maintenance.


Using the local network or mobile VPN through the system's IP address.



Login and Home Screen


Log in as a "Guest" user without a password to access the welcome screen.

Select one of the options.



Register Atlantium Systems

*This screen will be empty on the first login



Add a new system

+ New System

1.- Press add new system button

2.- Insert IP Address

*No need to check the TCP/IP check box

The screenshot shows the 'digi by Atlantium' web interface. A modal window titled 'Add New System' is open. The form contains the following fields and options:

- Search IP Address:** A text input field with a 'Search System' button.
- TCP/IP:** An unchecked checkbox.
- Serial Number:** A text input field.
- Customer Id:** A text input field.
- Name:** A text input field.
- Plant:** A text input field.
- Application:** A text input field.
- Model:** A text input field.
- Software Version:** A text input field.
- Lamps:** A text input field with the value '0'.
- Application Mode:** A text input field.
- Device Id String:** A text input field with the value 'Local'.
- Units Format:** A dropdown menu with 'm³/h' selected.
- Connectivity:** A section with several fields:
 - Group:** Two text input fields.
 - Host Id:** A text input field with the value '1'.
 - Port:** A text input field with the value '2221'.
 - Direct Port:** A text input field with the value '1502'.
 - Converter:** A dropdown menu with 'None' selected.
 - Username:** A text input field with the value 'username'.
 - Password:** A text input field with the value 'password'.
 - SS Card:** A text input field with the value '32'.
 - Latitude Position:** A text input field.
 - Longitude Position:** A text input field.
 - Controller Model:** A dropdown menu with 'AIO' selected.
- Automatic Backup:** A checked checkbox.
- Send Mail Notifications To Customer:** A checked checkbox.
- Buttons:** 'Save Changes' and a greyed-out button.

3.- Press Search System Button

If the IP address owner is an Atlantium System, Digi will read the system details

4.- Fill or update the system detail fields.

5.- If you have pif file for the system, import it.

6.- To allow mail notifications, select the checkbox

Select the correct Ethernet connection and port.

Set the protocol converter type

Set the corresponding port


Set the controller model



Controllers List Screen

This screen displays the register Atlantium systems.

Use the filter box to select groups.




Main System Dashboard Screen


- **Event Log:** Filter by dates, display the main system event log, monthly event summary, and ignition trend.

Status Indicators

Green: On/Operational; Gray: Off; Red: Error.



- **Tech Monitor:** Check lamp details (ID, UVIs/UVTs mA, UVT %, kW, voltage, current, age in hours, temp.



- **Trend Graph:** Plot Dose (mJ/cm²), UVT, Flow (mL/h), Power over time; spot anomalies like system errors.

- **Sys. Data:** View System data, alarms, real-time graph, and anomalies for Dose/UVT/Power/Flow/Temp, working hours (e.g., 5489 hrs).

The screenshot displays the 'digi by Atlantium' web interface. The top navigation bar includes 'Home', 'Reports', and 'Systems'. A status bar shows 'View All' (2), 'Operational' (2), 'Malfunction' (0), and 'Disconnected' (0). The main content area is titled 'System Data' and features a sidebar for the 'Home-RZB300(2L)' system, including its IP address (192.168.16.122) and a 'Dose' gauge showing 627. The main panel contains several sections: 'Customer' and 'Site' information, 'Required UV Dose' (120), 'Flow Rate' (5), 'Water Type' (Sea water), 'Water Temp' (Below 50°C), and 'Electricity' (400). Below these are input fields for 'Flow Rate', 'Minimum Flow', 'Maximum Flow', 'Flow Delay', 'Dose', 'Minimum Dose', 'Maximum Dose', 'UVT', 'Minimum UVT', 'UVT Delta', 'Power (%)', and 'Temperature'. An 'Alarms' table lists various system errors with their values. A 'Current Trend' and 'Trend Anomalies' section shows a table of data points over time.

Date	Name	Start	End	Period
12/03/2026 06:30	Power	100.00	93.00	2.00
12/03/2026 06:30	Dose	697.00	642.00	2.00

- **Programming:**

Edit settings;

The screenshot displays the Atlantium digi by Atlantium web interface. The top navigation bar includes 'Home', 'Reports', and 'Systems'. A status bar shows 'View All' with 2 Operational, 2 Malfunction, and 0 Disconnected units. The main content area is titled 'Home-RZB300(2L)' and shows a 'Dose' gauge at 627. Below the gauge, there are three metrics: UVT (96.91%), Flow (50 m³/h), and Power (93%). The 'Programming' section on the right allows editing of 'Minimum Flow' (10), 'Maximum Flow' (2000), and 'Set Power' (93). The bottom status bar indicates 'SW ver: 10.0.1.0'.

Next > Edit

Home-RZB300(2L)
192.168.16.122
3.4.0-rc1

Dose 627

UVT 96.91% Flow 50 m³/h Power 93%

Plant: Heker Yamim Eilat
Model: RZB300
Application Type: Disinfection
Application Mode:
Software Version: 3.4.0-rc1
On

Event Log Tech Monitor Trend Graph Sys. Data **Programming** Contact List

Working Hours 4376.32Hrs Connectivity: 99.3%



Programming

Minimum Flow	Maximum Flow	Set Power
10	2000	93
Send	Send	Send

SW ver: 10.0.1.0



- **Reports:** Generate compliance, health, or maintenance reports (e.g., UVT calibration, lamp audits); select time periods like "Last Week"



Trouble shooting

1. No system was found after the search process.

- Try to make a ping from the command line, if return ok

Check the SD card on the AIO controller.

deleted files or change for an empty one.

2. The Atlantium system was displayed but without data.

-Wait a few minutes, the digi system is copying all the data from the controller and can take a few minutes.

-Check the software version controller (AIO)

if its lower or than 3.3.0 (The System works through FTP)

Uncheck the checkbox in the system details screen.

-For an AIO software version up to 3.3.0, check on the controller
General tab -> Connection settings

If you use a converter, try to work on a baud rate of 9600

-If it is an AIO controller, try to close the digi and log in again.

The first connection with the AIO controller is through FTP (historical reasons)

After that, the communication changes to TCP/IP automatically.