


The Digi is a desktop dashboard that monitors Atlantium Systems.



## Overview

The digi monitor provides real-time oversight of multiple systems, showing status (Operational, Malfunction, Disconnected), key metrics like Dose, UVT, Flow, and Power, and tools for maintenance.


Using the local network or mobile VPN through the system's IP address.



## Login and Home Screen


Log in as a "Guest" user without a password to access the welcome screen.

Select one of the options.



## Register Atlantium Systems

\*This screen will be empty on the first login



## Add a new system

+ New System

1.- Press add new system button

2.- Insert IP Address

\*No need to check the TCP/IP check box

The screenshot shows the 'digi by Atlantium' web interface. The 'Add New System' modal is open, displaying a form with the following fields and options:

- Search IP Address:** A text input field with a 'Search System' button.
- TCP/IP:** An unchecked checkbox.
- Serial Number:** A text input field.
- Customer Id:** A text input field.
- Name:** A text input field.
- Plant:** A text input field.
- Application:** A text input field.
- Model:** A text input field.
- Software Version:** A text input field.
- Lamps:** A text input field with the value '0'.
- Application Mode:** A text input field.
- Device Id String:** A text input field with the value 'Local'.
- Units Format:** A dropdown menu set to 'm³/h'.
- Connectivity:**
  - Group:** A dropdown menu.
  - Host Id:** A text input field with the value '1'.
  - Port:** A text input field with the value '2221'.
  - Direct Port:** A text input field with the value '1502'.
  - Converter:** A dropdown menu set to 'None'.
  - Username:** A text input field with the value 'username'.
  - Password:** A text input field with the value 'password'.
  - Set Card:** A text input field with the value '32'.
  - Latitude Position:** A text input field.
  - Longitude Position:** A text input field.
  - Controller Model:** A dropdown menu set to 'AIO'.
- Automatic Backup:** A checked checkbox.
- Send Mail Notifications To Customer:** A checked checkbox.
- Buttons:** 'Save Changes' and 'Cancel' buttons.

3.- Press Search System Button

If the IP address owner is an Atlantium System, Digi will read the system details

4.- Fill or update the system detail fields.

5.- If you have pif file for the system, import it.

6.- To allow mail notifications, select the checkbox

Select the correct Ethernet connection and port.

Set the protocol converter type

Set the corresponding port


Set the controller model



## Controllers List Screen

This screen displays the register Atlantium systems.

Use the filter box to select groups.




## Main System Dashboard Screen


- **Event Log:** Filter by dates, display the main system event log, monthly event summary, and ignition trend.

### Status Indicators

Green: On/Operational; Gray: Off; Red: Error.



- **Tech Monitor:** Check lamp details (ID, UVIs/UVTs mA, UVT %, kW, voltage, current, age in hours, temp.



- **Trend Graph:** Plot Dose (mJ/cm<sup>2</sup>), UVT, Flow (mL/h), Power over time; spot anomalies like system errors.

- **Sys. Data:** View System data, alarms, real-time graph, and anomalies for Dose/UVT/Power/Flow/Temp, working hours (e.g., 5489 hrs).

The screenshot displays the 'digi by Atlantium' web interface. The top navigation bar includes 'Home', 'Reports', and 'Systems'. A status bar shows 'View All' (2), 'Operational' (2), 'Malfunction' (0), and 'Disconnected' (0). The main content area is titled 'System Data' and features a sidebar for the 'Home-RZB300(2L)' system with a real-time graph and a 'Next >' button. The main panel shows system details, including customer information, required UV dose, and various operational parameters like flow rate, dose, UVT, power, and temperature. An 'Alarms' section lists system errors and dose-related alerts. A 'Current Trend' and 'Trend Anomalies' table is also present.

**System Data**

**Customer:** Heker Yamim Eliot  
**Site:** Heker Yamim Eliot  
**Room:** Clean room assembly:  
**Segment:** Aquaculture  
**Subsegment:** Other  
**Application:** Disinfection

**Required UV Dose:** 120  
**UVT:** 95  
**Flow Rate:** 5  
**Water Type:** Sea water  
**Water Temp:** Below 50°C (120°F)  
**Electricity:** 400

**Flow Rate:** 50  
**Minimum Flow:** 10  
**Maximum Flow:** 2000  
**Flow Delay:** 0

**Dose:** 627  
**Minimum Dose:** 20  
**Maximum Dose:** 999

**UVT:** 96.91  
**Minimum UVT:** 50  
**UVT Delta:** 0

**Power (%)**  
 93

**Temperature**  
 25

**Maximum**  
 0

**Alarms**

| Description   | Value |
|---------------|-------|
| System error  | 0     |
| Over dose     | 0     |
| Under dose    | 0     |
| High temp. #4 | 0     |
| Over temp. #5 | 0     |

**Current Trend** **Trend Anomalies**

| Date             | Name  | Start  | End    | Period |
|------------------|-------|--------|--------|--------|
| 12/03/2026 06:30 | Power | 100.00 | 93.00  | 2.00   |
| 12/03/2026 06:30 | Dose  | 697.00 | 642.00 | 2.00   |

SW ver: 10.0.10

- **Programming:**

Edit settings;

The screenshot displays the Atlantium digi by Atlantium web interface. The top navigation bar includes links for Home, Reports, and Systems, along with a '+ New System' button. Below the navigation bar, there are status indicators for View All (2), Operational (2), Malfunction (0), and Disconnected (0). The main content area is divided into two sections. On the left, a sidebar for 'Home-RZB300(2L)' shows a circular gauge with a 'Dose' of 627 and three data points: UVT (96.91%), Flow (50 m³/h), and Power (93%). Below the gauge, a list of system details is provided: Plant (Heker Yamim Eilat), Model (RZB300), Application Type (Disinfection), Application Mode, Software Version (3.4.0-rc1), and an 'On' button. On the right, the 'Programming' section contains three input fields: Minimum Flow (10), Maximum Flow (2000), and Set Power (93), each with a 'Send' button. The bottom status bar shows 'SW ver: 10.0.1.0' and a stylized logo.



- **Reports:** Generate compliance, health, or maintenance reports (e.g., UVT calibration, lamp audits); select time periods like "Last Week"

The screenshot shows the Atlantium digi by Atlantium web interface. The top navigation bar includes 'Home', 'Reports', and 'Systems' tabs, along with a '+ New System' button. The 'Search Reports' sidebar on the left contains filters for 'Select System' (Home-RZB300), 'Compliance' (with 'Health Report' selected), 'Maintenance' (with 'Lamps' selected), and 'Select Time Period' (Last Month). A 'Generate Report' button is at the bottom of the sidebar. On the main panel, a 'Health Report' card is displayed, stating 'This report provides a comprehensive overview of the maintenance activities' and featuring a 'View Report' button. A large, faint 'A' watermark is visible in the background.

This screenshot shows the same Atlantium digi by Atlantium web interface, but with a detailed 'Your Monthly Atlantium System Health Report' displayed in the main panel. The report includes system information, calculated values, and a table of parameters.

**System Information:**

- Date: 13/03/2026 06:31
- Period: 10/02/2026 - 12/03/2026
- Operator: RZB30002L
- Model: RZB30002L
- Plant: Haker Yaron Elad
- IP address: 192.168.16.122
- Software ver: 3.4.0-rc1

**Calculated Values:**

| Parameter   | Average | Minimum | Maximum | Last value |
|-------------|---------|---------|---------|------------|
| Flow        | 432.47  | 827     | 864     | 827        |
| Power       | 83.37   | 50      | 97      | 93         |
| Flow        | 50      | 50      | 50      | 50         |
| Temperature | 25      | 25      | 25      | 25         |
| UVT         | 95.93   | 95.9    | 97      | 95.9       |
| UVIs        | 5.31    | 5.3     | 5.4     | 5.3        |
| UVIs        | 5.2     | 5.2     | 5.2     | 5.2        |
| LampUVT     | 95.93   | 95.9    | 97      | 95.9       |

The report footer indicates 'Page 1 of 2' and 'www.atlantium.com'.



## Trouble shooting

### 1. No system was found after the search process.

- Try to make a ping from the command line, if return ok

Check the SD card on the AIO controller.

deleted files or change for an empty one.

### 2. The Atlantium system was displayed but without data.

-Wait a few minutes, the digi system is copying all the data from the controller and can take a few minutes.

-Check the software version controller (AIO)

if its lower or than 3.3.0 (The System works through FTP)

Uncheck the checkbox in the system details screen.

**System Details** ×

Buscar dirección IP

192.168.16.140 Q Buscar sistema

☒ TCP/IP

| Número de serie | ID del cliente    | Nombre     |
|-----------------|-------------------|------------|
|                 | Heker Yamim Eilat | HOME RZ104 |

-For an AIO software version up to 3.3.0, check on the controller  
General tab -> Connection settings

If you use a converter, try to work on a baud rate of 9600

-If it is an AIO controller, try to close the digi and log in again.

The first connection with the AIO controller is through FTP (historical reasons)

After that, the communication changes to TCP/IP automatically.

