RUCKUS One Online Help (index.html)

Search Q

Security Settings


You can customize the security settings of the Wi-Fi network in a venue.

Complete the following steps to customize the security settings of a venue.

- 1. On the navigation bar, click Venues. The Venues page is displayed.
- 2. Select the Venue Name and click Edit. Alternatively, click Venue Name > (and then)Configure.
- 3. Select the Wi-Fi Configuration > (and then)Security tab. The Security tab is displayed.

Security Tab

1 of 3 6/10/25, 14:19



- 4. Switch the DoS Protection button to ON. By defaut, this button is set to OFF.
- 5. Specify the time in the Block a client for field, seconds after field, and repeat authentication failures within field.
- 6. Switch the Rogue AP Detection button to ON.
- 7. Specify the value for the Report SNR Threshold. The range is from 0 to 100.
- 8. Select a Rogue AP Detection Policy Profile from the drop-down or add a new Rogue AP Detection Policy Profile.
 - a. Click View Details to review the selected Rogue AP Detection Policy Profile.
 The Rogue AP Detection Policy Profile Details dialog box is displayed with the following information:
 - Priority
 - o Rule name
 - Rule Type
 - Category

2 of 3 6/10/25, 14:19

- b. Click Add Profile to add a Rogue AP Detection Policy Profile. Refer to *Creating a Rogue AP Detection Policy (GUID-15FEBB01-E40D-43AE-91D9-4D25DC2557F5.html)*.
- 9. Click Save.

800-73730-001 Rev E 29 May 2025 © 2024 CommScope, Inc. All rights reserved.

3 of 3 6/10/25, 14:19