

Equipment Maintenance SAP

Preventive maintenance and scheduling system for farm and utility equipment

Author August Wageman

Date 6/20/2025

Utility equipment maintenance system structured after SAP Plant Maintenance conventions. Includes a unique ID for each vehicle, a task list per asset, and a preventive maintenance schedule model for managing repetitive service across equipment.

Contents

1. Vehicle Description
2. Standard Operating Procedures (SOP)
3. Preventive Maintenance Schedule
4. Equipment Photos

1. Vehicle Description

Asset registry for all equipment covered under this maintenance system.

Vehicle ID	Vehicle Name	Asset Category	Model	Serial #
EQ-001	Polaris Ranger XP (PROSTAR)	UTV	Ranger Fullsize	46240
EQ-002	Kubota L3901	Heavy tractor	LA525	W0202
EQ-003	Kubota Zero-Turn Mower	Lawn mower	Z726XKW	12359

2. Standard Operating Procedures (SOP)

Step-by-step service procedures for each recurring maintenance task.

TA-001 | Polaris Ranger XP (PROSTAR)

200 Hours / 4 Months

Task: Oil change, fuel lines replaced

1. Move vehicle to a flat, level surface and set to park.
2. Disconnect the negative battery terminal before working on electrical systems.
3. Allow the engine to cool before any further servicing.
4. Dispose of used oil and filter carefully, following proper guidelines.

TA-002 | Kubota L3901

1000 Hours / 12 Months

Task: Change transmission fluid, replace hydraulic filter

1. Park the tractor on a flat, level surface, lower attachments, engage the parking brake, and shut off the engine.
2. Allow the engine to cool for 5-10 minutes until engine temp is normal.
3. Place a drain pan under the transmission and remove the drain plug.
4. Remove the current hydraulic filter and clean the mounting surface.
5. Lightly lubricate the gasket.
6. Install the new hydraulic filter.
7. Reinstall the drain plug; it should be tight to prevent leakage.
8. Refill the system with Kubota Super UDT2 until it reaches the full mark.
9. Start and warm up the engine.
10. Operate steering and hydraulic functions to circulate fluid.
11. Shut off the engine.
12. Check the fluid level and add more if needed.
13. Inspect for leaks around the drain plug and filter.

Task: Change oil, replace filter, grease pump into blade spindles

1. Park the mower on a flat, level surface, engage the parking brake, shut off the engine, and remove the key.
2. Allow the engine to cool.
3. Drain the old engine oil.
4. Replace the oil filter; lubricate the new filter gasket before installation.
5. Reinstall the drain plug.
6. Fill with SAE 10W-30 engine oil until full.
7. Start the engine.
8. Inspect for leaks.
9. Shut off the engine and recheck the oil level.
10. Use a grease gun to lubricate all blade spindle fittings until a small amount of grease exits the fitting.
11. Clean up any spills.
12. Dispose of used oil and filter properly.

3. Preventive Maintenance Schedule

Service history log for all tracked equipment.

Plan ID	Equipment Name	Task Performed	Date	Status
P-001	Polaris Ranger XP (PROSTAR)	Oil change; fuel lines replaced	5/5/2026	Completed
P-002	Kubota L3901	Change transmission fluid; replace hydraulic filter	6/10/2025	Completed
P-003	Kubota Zero-Turn Mower	Change oil; replace filter; grease pump into blade spindles	5/25/2025	Completed

4. Equipment Photos

Polaris Ranger XP (PROSTAR)



Kubota L3901



Kubota Zero-Turn Mower

