

# Finite Volume Discretisation in OpenFOAM Best Practice Guidelines

Hrvoje Jasak

h.jasak@wikki.co.uk

Wikki Ltd, United Kingdom



## **Outline**



#### Objective

- Review the best practice guidelines for the Finite Volume (FV) discretisation in OpenFOAM and compare it with commercial CFD solvers
  - Background on discretisation
  - Default settings on dominantly hex and dominantly tet meshes

#### **Topics**

- Background
- Discretisation requirements: gradient scheme; convection; diffusion
- Proposed default settings: hexahedral meshes
- Proposed default settings: tetrahedral meshes
- Summary

# **Background**



#### Best Practice Guidelines in CFD

- Commercial CFD codes offer robust set of default settings for the FVM: make the code run on a bad mesh and by inexpert users
- Priority is in producing a result: substantial improvements in solution quality and accuracy is possible
- ...but only for an expert user!
- Default settings are extremely important and change only after large validation and robustness testing campaigns

#### Default Settings in OpenFOAM

- ...are practically non-existent: the code is written by experts and defaults are changed on a whim
- Some tutorials have settings appropriate for the case, but not recommended in general
- ullet To remedy this, we need automatic test loops with 5000+ validation cases
- Improvements are in the pipeline: community effort and validation harness

## **Discretisation**



#### Finite Volume Discretisation

- Main concerns of FVM accuracy are mesh structure and quality and choice of discretisation schemes
- Mesh structure determines the choice of appropriate gradient calculation algorithm
- For transport of bounded scalars, it is essential to use bounded differencing schemes: both for convection and diffusion



### **Gradient Scheme**



#### **Gauss Gradient Scheme**

Gradient calculated using integrals over faces

$$\int_{V_P} \nabla \phi \, dV = \oint_{\partial V_P} d\mathbf{s} \, \phi = \sum_f \mathbf{s}_f \phi_f$$

• Evaluate the face value of  $\phi$  from cell centre values

$$\phi_f = f_x \phi_P + (1 - f_x) \phi_N$$

where 
$$f_x = \overline{fN}/\overline{PN}$$

- ullet Expression is second-order accurate only if  $\phi_f$  is the face centre value
- Accurate on hexahedral meshes, but looses accuracy on tetrahedra: large skewness error

## **Gradient Scheme**



Least Squares Gradient: Second Order Accuracy On All Meshes

• Consider cell centre P and a cluster of points around it N. Fit a plane:

$$e_N = \phi_N - (\phi_P + \mathbf{d}_N \bullet (\nabla \phi)_P)$$

Minimising the weighted error: second-order accuracy on all meshes

$$e_P^2 = \sum_N (w_N e_N)^2$$
 where  $w_N = \frac{1}{|\mathbf{d}_N|}$ 

yields a second-order least-square form of gradient:

$$(\nabla \phi)_P = \sum_N w_N^2 \mathbf{G}^{-1} \cdot \mathbf{d}_N (\phi_N - \phi_P)$$

• G is a  $3 \times 3$  symmetric matrix:

$$\mathbf{G} = \sum_N w_N^2 \, \mathbf{d}_N \mathbf{d}_N$$

## **Gradient Limiter**




#### Cell- and Face-Limited Gradient

 Gradient reconstruction may lead to local over- or under-shoots in reconstructed field:

$$min_N(\phi_N) \le \phi_P + \mathbf{d}_N \bullet (\nabla \phi)_P \le max_N(\phi_N)$$

- This is important for bounded variables, especially when gradients are used in further discretisation or coupling terms
- Solution: based on the gradient, calculate min and max neighbourhood value and apply gradient limiter to preserve bounds in cell centres



## **Convection Discretisation**



#### **Convection Operator**

 Convection operator splits into a sum of face integrals (integral and differential form)

$$\oint_{S} \phi(\mathbf{n} \cdot \mathbf{u}) dS = \int_{V} \nabla_{\bullet}(\phi \mathbf{u}) dV = \sum_{f} \phi_{f}(\mathbf{s}_{f} \cdot \mathbf{u}_{f}) = \sum_{f} \phi_{f} F$$

where  $\phi_f$  is the face value of  $\phi$  and

$$F = \mathbf{s}_f \bullet \mathbf{u}_f$$

is the face flux: measure of the flow through the face

 Simplest face interpolation: central differencing. Second-order accurate, but causes oscillations

$$\phi_f = f_x \phi_P + (1 - f_x) \phi_N$$

• **Upwind differencing**: taking into account the transportive property of the term: information comes from upstream. No oscillations, but smears the solution


$$\phi_f = max(F, 0) \phi_P + min(F, 0) \phi_N$$

# **Face Interpolation**



#### Face Interpolation Scheme for Convection

- In order to close the system, we need a way of evaluating  $\phi_f$  from the cell values  $\phi_P$  and  $\phi_N$ : face interpolation
- In order to preserve the iteration sequence, the convection operator for bounded (scalar) properties must preserve boundedness
- There exists a large number of schemes, trying to achieve good accuracy while preserving boundedness: e.g. TVD, and NVD families:  $\phi_f = f(\phi_P, \phi_N, F, ...)$



 Special differencing schemes for strictly bounded scalars: switching to UD when a variable violates the bound. Example: Gamma01

## **Diffusion Discretisation**




#### Diffusion Operator and Mesh Non-Orthogonality

Diffusion term is discretised using the Gauss Theorem

$$\oint_{S} \gamma(\mathbf{n} \bullet \nabla \phi) dS = \sum_{f} \int_{S_{f}} \gamma(\mathbf{n} \bullet \nabla \phi) dS = \sum_{f} \gamma_{f} \mathbf{s}_{f} \bullet (\nabla \phi)_{f}$$

• Evaluation of the face-normal gradient. If s and  $\mathbf{d}_f = \overline{PN}$  are aligned, use difference across the face. For non-orthogonal meshes, a correction term may be necessary



$$\mathbf{s}_f \bullet (\nabla \phi)_f = |\mathbf{s}_f| \frac{\phi_N - \phi_P}{|\mathbf{d}_f|} + \mathbf{k}_f \bullet (\nabla \phi)_f$$

# **Diffusion Operator**



#### Limiting Non-Orthogonal Correction in a Laplacian

- Decomposition of face gradient into "orthogonal component" and "non-orthogonal correction" depends on mesh quality: mesh non-orthogonality is measured from  $\overline{PN}$  and  $\mathbf{s}_f$
- Mathematically, a Laplacian is a perfect operator: smooth, bounded, self-adjoint.
   Its discretisation yields a symmetric matrix
- In contrast, non-orthogonal correction is explicit, unbounded and unsigned
- Limited non-orthogonal correction: explicit part clipped to be smaller than its implicit counterpart, base on the current solution

$$\lambda \frac{|\mathbf{s}_f|}{|\mathbf{d}_f|} (\phi_N - \phi_P) > \mathbf{k}_f \bullet \nabla (\phi)_f$$

#### where $\lambda$ is the limiter value

- Treatment of mesh non-orthogonality over 90°: mesh is formally invalid
  - This corresponds to a Laplacian operator with negative diffusion
  - Stabilise the calculation and remove non-orthogonal correction term
  - Note: This is a "rescue procedure": reconsider mesh and results!



# **Discretisation Settings**



#### Proposed Settings for Hexahedral Meshes

- Gradient scheme: Gauss or Gauss with limiters
- Convection scheme
  - In initial settings or unknown mesh quality, always start with Upwind. If this fails, there are problems elsewhere in case setup
  - Momentum equation: for second order, recommend linear upwind. with optional gradient limiters
  - TVD/NVD schemes for bounded scalars (eg. turbulence); optionally, use deferred correction formulation
- Diffusion scheme: settings depend on max non-orthogonality
  - Below 60 deg, no special practice: Gauss linear corrected
  - Above 70 deg, non-orthogonality limiter: Gauss linear limited 0.5
- In all cases, monitor boundedness of scalars and adjust convection and diffusion schemes to remove bounding messages



# **Discretisation Settings**



#### Proposed Settings for Tetrahedral Meshes

- On tetrahedral meshes, cell neighbourhood is minimal: a tet has only 4 neighbours
- Skewness and non-orthogonality errors are larger and with substantial effect on the solution: it is essential to re-adjust the discretisation
- Gradient scheme: least squares; in most cases without limiters
- Convection scheme
  - On simple cases, use upwinding; nature of discretisation error changes due to lack of mesh-to-flow alignment
  - For highly accurate simulations, special (reconstructed) schemes are used
- Diffusion scheme: always with non-orthogonality limiters. Control limiter based on boundedness messages on scalars



# **Summary**



#### Summary

- Discretisation settings in tutorials are a good starting point
- Variation in mesh structure (tetrahedral, hexahedral and polyhedral) means that no single choice will work for all meshes
- In complex physics, consider physical properties of variables: boundedness and conservation
- OpenFOAM is regularly set up for high accuracy rather than convergence to steady-state: The fact that a solver converges does not necessarily mean the results are correct (or physical!)
- "Special applications" like LES require additional care: energy conserving numerics, low diffusion and dispersion errors
- Guidance provided for main mesh types: hex and tet. Polyhedral meshes use hex settings
- Further complications may be introduced by moving mesh and topological changes