P-102 Permit-to-Work and Energy Isolation Guide

Seed artifact | Cross-document procedure synthesis

Permit selection

Select the permit type based on the work: hot work, confined space, electrical work, line breaking or work at height.

Hazard identification

Consider hydrocarbon release, pressure, temperature, electrical energy, stored mechanical energy and toxic exposure.

P-102 isolation boundary

For P-102 work, the source identifies M-102 electrical supply, process suction isolation, process discharge isolation, drain/vent as required and stored rotational energy.

Zero-energy verification

Verify absence of voltage, pressure confirmation, drain verification and an approved try-start where safe.

Restoration

Confirm work completion, guards installed, tools removed, locks cleared, line-up restored and operations acceptance.

