



Ignition Output JP1 Ignition Voltage IGN-V-Select IGN-V-Select LED2 LED C5 LED4 LED 0.1uF 0.1uF IGN-V-Select C8 1uF R13 2.4k U2 TC4427 TC4427 100K R11 1K 100K MC-D38 OUT_A MC-D50> 0UT_4 OUT_B) OUT_B MC-D40> IN_B 1K R4 R6 2.4k LED1 LED 100K R2 1K R12 100K R1 R16 R14 2.4k LED3 LED ↓ GND GND GND GND → N S Fuel Injector Output GND → R22 100K R24 1K R18 R20 1K Q7 STP62NS04Z 100K STP62NS04Z MC-D10> GND GND R17 R19 1K R21 R23 1K 100K 100K) Q8 STP62NS04Z STP62NS04Z MC-D11> Sheet: /Fuel-Ignition/ File: Fuel-Ignition.sch

 Title:

 Size: A4
 Date:
 Rev: 1

 KiCad E.D.A. kicad (5.1.10)-1
 Id: 3/5



