ReadMe File:

1. Enter the	value of the	desired	degrees	at which	you	would I	like the	system
to stabilize.								

- 2. Move the pendulum between minus 45 and 45 degrees.
- 3. Wait for the system to stabilize.