Group 26

User instructions:

- 1. View display screen
- 2. Adjust the light intensity on the sensor to above 20%
- 3. When the light sensor detects that the intensity of the sun's rays is strong (over 20% of the sun's intensity), An "Open shutter" message will appear on the display screen
- 4. See the yellow light flashing as an indication that the shutter should be opened.
- 5. To open the blinds, press the black button
- 6. See the green light turns on (indication for receiving the click)
- 7. Servo motor mirror works to open the shutters (rotates clockwise)
- 8. When the shutters are finished opening, a message indicating "Shutter Open" will appear on the display screen
- 9. Adjust the light intensity on the sensor to 20% or less.
- 10. When the light sensor detects that the intensity of the sun's rays is within the permissible limit (below 20% of the sun's intensity), a message will appear on the display screen "Close shutter"
- 11. See the red light flashing as an indication that the shutter needs to be closed.
- 12. To close the shutters, press the black button.
- 13. See the green light turns on (indication for receiving the click)
- 14. Servo motor mirror works to open the blinds (rotates counter-clockwise)
- 15. When the shutters are closed, a message will appear on the display screen "Shutter Closed"