

# Anti Spark Switch User Manual

Model # ASR100

This electronic switch is designed for high-power DC systems (up to 84V/100A). It prevents arcing during power on/off, protecting batteries, connectors, and downstream devices from damage and oxidation, extending their service life. This remote-controlled version features dedicated ON/OFF buttons on the remote. An onboard 2-pin terminal is provided for connecting an external switch to control power on/off (when remote control is not used).

| Indicator    | Label | Color | Normal operation                                 | Pair mode                                                                    |
|--------------|-------|-------|--------------------------------------------------|------------------------------------------------------------------------------|
| Power Status | -     | Red   | Off: Output disconnected    On: Output energized |                                                                              |
| Mode         | LED   | Green | Off: Default Mode<br>On: Vibration Mode          | 0.5s flash interval: waiting for pairing<br>2s rapid flash: paired / cleared |

**Operating Modes** (Short-press SET to toggle between modes):

- **Default Mode:** Output is off by default after power-up. Press ON to turn on, press OFF to turn off.
- **Vibration Mode:** Output is off by default after power-up. Press ON to turn on; the OFF signal is ignored while the device is vibrating – it can only be turned off when the device is stationary.

*Prevents accidental power-off – e.g., avoids drone power-loss mid-flight from unintended OFF button press.*

**Remote Pairing** (Double-click SET within 1 second):

- The MODE LED flashes every 0.5s to indicate pairing waiting mode.
- Press either the ON or OFF button on the remote within 10 seconds to complete pairing (the MODE LED flashes rapidly for 2 seconds upon success).
- If no operation is detected within 10 seconds, the unit exits pairing mode and retains the previously paired remote.

**Clear Paired Remote:**

- Long-press SET for 2 seconds to clear all paired remotes (the MODE LED flashes rapidly for 2 seconds and then automatically enters pairing waiting mode).

**Zhuhai Baoge Technology Co., Ltd.**

Website: <https://www.autorotech.com>

Sales inquiries: [Autoro.sales@hotmail.com](mailto:Autoro.sales@hotmail.com)

Technical support: [Autoro.service@hotmail.com](mailto:Autoro.service@hotmail.com)



# 防火花开关用户手册

型号: ASR100

本电子开关专为大功率直流系统设计（最高 84V/100A），可有效消除电源通断时产生的电弧（电火花），保护电池组、连接器及下游设备免受电击损伤和氧化腐蚀，显著延长电子设备的使用寿命。本产品为遥控版本，配套遥控器设有独立的 ON 和 OFF 按键，用于控制开关机。板载 2Pin 端子，可外接开关控制电源通断（当无需使用遥控器时）。

| 指示灯     | 标识  | 颜色 | 正常工作时              | 配对模式下                               |
|---------|-----|----|--------------------|-------------------------------------|
| 电源状态指示灯 | 无   | 红  | 熄灭：输出断开<br>亮起：输出接通 |                                     |
| 模式指示灯   | LED | 绿  | 熄灭：默认模式<br>亮起：振动模式 | 间隔 0.5s 闪烁：配对等待<br>快闪 2 秒：配对成功或清除完成 |

## 工作模式

短按 SET 键，可在默认模式与振动模式之间切换

- **默认模式：**上电后输出默认断开。按 ON 键接通，按 OFF 键断开。

- **振动模式：**上电后输出默认断开。按 ON 键接通；设备振动时 OFF 信号无效，需静止时按 OFF 键方可断开。

防止运行中误触断电 —— 例如避免无人机飞行时因误按 OFF 键导致坠机。

## 遥控器配对（1 秒内双击 SET 键）：

- 模式灯间隔 0.5s 闪烁，进入配对等待状态。
- 10 秒内按遥控器的 ON 或 OFF 键完成配对（配对成功模式灯快闪 2 秒）。
- 若 10 秒无操作，自动退出配对，保留原有配对信息。

## 清除已配对遥控器：

- 长按 SET 键 2 秒，清除所有配对（模式灯快闪 2 秒后自动进入配对等待）。



制造商：珠海宝格科技有限公司

商务合作：[Autoro.sales@hotmail.com](mailto:Autoro.sales@hotmail.com)

技术支持：[Autoro.service@hotmail.com](mailto:Autoro.service@hotmail.com)

公司网址：<https://www.autorotech.com>

