

**GENERAL****Operational Hours****ATS Hours / AD OPS Hours:** H24**AD ADMIN Hours:** MON-FRI 0300-1200, SAT, SUN, HOL CLSD**Airport Information****RFF:** CAT 7**Fuel:** TS-1, RT**PCN:** RWY 06/24: 38/F/B/X/T**Operation****Taxi/Parking**

Parking by Marshaller.

Stand 2-4:

- Shall be carried out under own ENG PWR.
- Stand 2 facing east, stand 3 and 4 facing west.

Stand 5-10:

- Parking on stands shall be carried out under own ENG PWR, facing to the RWY; taxiing out of stands under own ENG PWR.

Stand 11-13:

- Parking on stands under own ENG PWR, facing to the Terminal; taxiing out of stands by towing only.

Stand 14, 15:

- Into stands shall be carried out under own ENG PWR after follow-me.
- Taxiing out by towing.
- Equipped by aerobridges.

Stand 16, 17:

- Into stands shall be carried out by towing, taxiing out under own ENG PWR.

**Warnings**

Birds in vicinity of AD.

**ARRIVAL****Communication****COM Failure:** See CRAR Russian Federation.**DEPARTURE****Take-off Minima**

RWY	06/24	
All ACFT	ft - m/km	0 - 400R/400V

**Communication****COM Failure:** See CRAR Russian Federation.**De-Icing**

AVBL.


## HMA-USHH

HMA-IISH

## HMA-USHH


2-10


1050 ✓



<b>ATIS</b>	126.400
<b>Khantym RAD</b>	120.400
<b>Khantym TWR</b>	118.100 RAD by ATC
<b>Khantym GND</b>	119.000 Start-up and Towing

## Landing RWY system:







Effective 04-JAN-2018

28-DEC-2017

## Russian Federation Khanty-Mansiysk

HMA-USHH

4-20


## SIDs RWY 06 (PROCs G)

SID

SID

## Khanty-Mansiysk Russian Federation

## SIDs RWY 06 (PROCs G)





Effective 04-JAN-2018

28-DEC-2017

## Russian Federation Khanty-Mansiysk

HMA-USHH


4-40


## SIDs RWY 24 (PROCs H)


SID

## Khanty-Mansiysk Russian Federation


## SIDs RWY 24 (PROCs H)











**6-50 STARs RWY 24 (PROCs D West)**


**6-50 STARs RWY 24 (PROCs D West)**

11. **What is the primary purpose of the `get` method in the `HttpURLConnection` class?**

## STARs RWY 24 (PROCs D West)

## STARs RWY 24 (PROCs D West)

11. **What is the primary purpose of the `get` method in the `HttpURLConnection` class?**



Effective 04-JAN-2018

28-DEC-2017

HMA-USHH

Russian Federation Khanty-Mansiysk


STAR

STAR

Khanty-Mansiysk Russian Federation

6-60 STARs RWY 24 (PROCs J)

STARs RWY 24 (PROCs J)




Changes: new

## HMA-USHH

7-10

## ILS 06 / NDB + NDB 06




Changes: Note

## HMA-USHH

7-20


ILS X 06



## HMA-USHH

7-30


ILS 24 / NDB + NDB 24



HMA-USHH

7-40

ILS X 24






## HMA-USHH

7-60


# VOR Y 06



## HMA-USHH

7-70


**VOR X 06**



HMA-USHH

7-80

VOR Z 24




Changes: new

## HMA-USHH

7-90

VOR Y 24



Changes: new

## HMA-USHH

7-100

**VOR X 24**

