

HEAD POWER IN / W13 + W14


J1
J8-1_HEAD_POWER_MF3




HEAD LINK / W24 (D-092 order)




LINK GND -> GND_SIG: 0R, ferrite fallback




W42 POWER FFC: 7+7 HEAD, 2+2 C2, 2+2 DISPLAY



W43 SIGNAL FFC: NO POWER, 10-22 ISOLATED



YAW SERVO / W15 + W17 RAIL





BENCH PADS





D-093 / D-100: 6.0 V head 7+7; J8-7 signal-only; GND_SIG

Makad

Sheet: /
File: pcb-08-yaw-junction.kicad_sch

Title: PCB-08 yaw junction

Size: A3	Date: 2026-11-09	**Rev: A**
KiCad E.D.A. 10.99.0-5923-gde08734017		Id: 1/1