

HEAD POWER IN / W13 + W14

J1
J8-1_HEAD_POWER_MF3




W42 POWER FFC: 7+7 HEAD, 2+2 C2, 2+2 DISPLAY



J3
J8-6_W42_POWER_FFC

W43 SIGNAL FFC: NO POWER, 10–22 ISOLATED



J4
J8-7_W43_SIGNAL_FFC

YAW SERVO / W15 + W17 RAIL




J5
J8-8_YAW_SERVO_5267



J6
W17_YAW_RAIL_PADS

HEAD LINK / W24 (D–092 order)



J2
J8-4_HEAD_LINK_W24

LINK GND –> GND_SIG: 0R, ferrite fallback



BENCH PADS





D–093 / D–100: 6.0 V head 7+7; J8–7 signal–only; GND_SIG

Makad

Sheet: /
File: pcb–08–yaw–junction.kicad_sch

Title: PCB–08 yaw junction

Size: A3	Date: 2026–11–09	**Rev: A**
KiCad E.D.A. 10.99.0–5923–gde08734017		Id: 1/1