

		Saudia Aerospace Engineering Industries P.O. Box 167 CC 808 Jeddah 21231		W/O 29156055 Copy		Barcode  WO29156055R4		Registration HZ-ASP 321	
Type S SCHED	Origin EOD DOL. ENGINEERING ORDER DETAIL	ATA 46 INFORMATION SYSTEMS	Position N/A	Zone N/A	Area N/A				
Workpackage									
Workpackage No. / Sequence No. ASP/H-26 C7-CHK / SEQ 490 C07-CHK + WIFI			Planning-Date Start - Planned-Date End 04.Sep.26, 22:00 - 06.Oct.26, 22:00 Flight-No.			Maintenance Provider SAUDIA AEROSPACE ENGINEERING IND. AMO-001			
Classifications/Statistics/Requests									
Line/Heavy: HEAVY MAINTENANCE									
Type	Reference			Description					
DO	A320-46-1156/SB (RV.11)								
DO	A320-46-1156/SB (RV.12)								
DO	EOC-320-31-00006-R00/EOC (RV.00)								
DO	EOC-321-31-00003-R00/EOC (RV.00)								
DO	EOD-321-46-00005-R00/EOD (RV.00)								
DO	UP-2022-SVA0656-CO2/MOD (RV.00)								
Description Step 1									
A.GENERAL									
Task set A320-A-46-XX-1156-01000-93AA-A (A320-A-46-XX-1156-01ZZZ-93AZ-A) Modification									
WARNING: MAKE SURE THAT YOU OBEY ALL THE WARNINGS AND ALL THE CAUTIONS INCLUDED IN THE REFERENCED PROCEDURES.									
CAUTION: ALWAYS OBEY THE PRECAUTIONS THAT FOLLOW TO KEEP ELECTRICAL WIRING IN A SATISFACTORY CONDITION (ELECTRICALLY AND MECHANICALLY SERVICEABLE). WHEN YOU DO A MAINTENANCE WORK, REPAIRS OR MODIFICATIONS, ALWAYS KEEP ELECTRICAL WIRING, COMPONENTS AND THE WORK AREA AS CLEAN AS POSSIBLE. TO DO THIS:									
- PUT PROTECTION, SUCH AS PLASTIC SHEETING, CLOTHS, ETC., AS NECESSARY ON WIRING AND COMPONENTS.									
- REGULARLY REMOVE ALL SHAVINGS, UNWANTED MATERIAL AND OTHER CONTAMINATION.									
THESE PRECAUTIONS WILL DECREASE THE RISK OF CONTAMINATION AND DAMAGE TO THE ELECTRICAL WIRING INSTALLATION.									
IF THERE IS CONTAMINATION, REFER TO Ref. ESPM 20-55-00.									
NOTE: Section 3. includes procedures given in other documents or in other sections of this Service Bulletin.									
- You must obey the given procedure when the words "in accordance with" are used.									
- You can use an accepted alternative procedure only when the words "refer to" are									

used and you have a procedure that is accepted by the related local authority.

NOTE: To add flexibility to your maintenance operations you can select to ignore steps or add steps from paragraphs 3.B., 3.D., and 3.F. of section 3. as long as:

- you can do paragraphs 3.C. and 3.E.,
- and the technical intent of the Service Bulletin is met within the set parameters,
- and you can put the aircraft back into a serviceable condition.

NOTE: In section 3., the names of the manuals are given with their related acronyms. Refer to the paragraph "1.J., References" for the definition of acronyms.

NOTE: This Service Bulletin contains the instructions for the on-aircraft maintenance necessary to ensure the continued airworthiness of the aircraft.
For any deviations from the instructions, contact AIRBUS for further instructions and approval.

NOTE: The management of the removed parts that are identified with "discard" is the responsibility of the operator and must be done in accordance with the applicable local

=====

=====

Summary of the EOD:

- 1- This EO is extracted from SB A320-46-1156 , REV 12
- 2- Applicable Aircraft HZ-ASA to HZ-ASW & HZ-AS51 to HZ-AS84 ,conf 01 , REV 12
- 3- Man Hours Required : **17 hrs**
- 4- Material Required :

- 1-Part kit 461156A01R00
- 2-Part kit 461156A02R04
- 3-Part kit 461156A03R02

5-Referenced tools:

Referenced tools for task set A320-A-46-XX-1156-01000-93AA-A Modification
To accomplish this Service Bulletin it is necessary to use the tools listed in the subsequent referenced tasks:
Ref. AMM Task 52-30-00-860-005
Ref. AMM Task 52-30-00-860-009
Ref. ESPM 20-52-21

6- Consumables

REFERENCE CML	DESCRIPTION
	Primer Polyurethane Paint

 السعودية Saudia 	Saudia Aerospace Engineering Industri P.O. Box 167 CC 808 Jeddah 21231	W/O 29156055 Copy	Barcode  WO29156055R4	Registration HZ-ASP 321
---	--	--------------------------------	--	--------------------------------------

04EAC2	- - CorrosionInhibiting Structure
04JME4	Top Coat Polyurethane - - Grey InternalStructure
05BAB1	Threadlocking Adhesive - - Low strengthLow viscosity
06AAC1	Polysulfide Sealant - General Purpose Interfay
14QDB1	Wire - Locking Dia: 0.5 mm (0.020 inch)CRES Nickel Alloy

7- Equipment

PN: 822-3594-100 , ANTENNA , Quantity : 1 per Aircraft

8- Re-identified parts :

check SB

9- CONCURRENT REQUIREMENTS

SB A320-46-1126

SB A320-46-1134

Description Step 2

Wael Yazqi (11011720), 18.Aug.2025

B. PREPARATION

(1) TASK A320-A-46-XX-1156-01001-540A-A (A320-A-46-XX-1156-01ZZZ-540Z-A)

JOB SET-UP

Referenced Information

Manuals/Drawings	References/Sheets
AMM	Task 12-34-24-869-002 Task 25-54-11-000-001 Task 25-54-12-000-002 Task 52-30-00-860-001 Task 52-30-00-860-003 Task 52-30-00-860-005

Procedure

NOTE: For the basic aircraft configuration, refer to AMM Chapter “Introduction - Aircraft Status for Maintenance” in the Manual Front Matter section.

- (a) Make sure that the aircraft is electrically grounded, refer to Ref. AMM Task 12-34-24-869-002.
- (b) Put an access platform in position below the avionics compartment door, Door 812 and the FWD cargo-compartment door, Door 825.
- (c) Open avionics compartment door 812, refer to Ref. AMM Task 52-41-00-010-002.
- (d) Open the FWD cargo-compartment door, Door 825, refer to Ref. AMM Task 52-30-00-860-001 or Ref. AMM Task 52-30-00-860-003 or Ref. AMM Task 52-30-00-860-005.
- (e) Remove the partition panels (Panel 131CW, Panel 131DW and Panel 132EW) from the FWD cargo compartment, at Frame 24A for access, refer to Ref. AMM Task 25-54-11-000-001.
- (f) Remove the ceiling panels (Panel 131AC, Panel 131HC, Panel 131KC and Panel 131MC) from the FWD cargo compartment for access, refer to Ref. AMM Task 25-54-12-000-002.

C. PROCEDURE (1)

**(1) TASK A320-A-46-XX-1156-04001-720A-A
(A320-A-46-XX-1156-04ZZZ-720Z-A) INSTALL THE
BRACKETS, THE EQUIPMENT AND ROUTE 21T IN THE
AVIONICS COMPARTMENT**

Follow attached instructions from Page 48 ((1) TASK A320-A-46-XX-1156-04001-720A-A) to Page 66 ,from SB A320-46-1156 Rev 12

Description Step 4	Wael Yazqi (11011720), 18.Aug.2025
--------------------	------------------------------------

C. PROCEDURE (2)

**(2) Task A320-A-46-XX-1156-02001-920A-A
(A320-A-46-XX-1156-02ZZZ-920Z-A) Install the Brackets
and Modify Route 21T in the FWD Cargo Compartment**

Follow attached instructions from Page 85 to Page 99 ,from SB A320-46-1156 Rev 12,

Description Step 5	Wael Yazqi (11011720), 18.Aug.2025
--------------------	------------------------------------

C. PROCEDURE (3)

**(3) TASK A320-A-46-XX-1156-01001-720A-A
(A320-A-46-XX-1156-01ZZZ-720Z-A)
INSTALL THE TUBE ASSY BETWEEN THE AVIONICS
COMPARTMENT AND THE FWD CARGO
COMPARTMENT**

Follow attached instructions from Page 100 to Page 103 ,from A320-46-1156 Rev 12,

Description Step 6	Wael Yazqi (11011720), 18.Aug.2025
--------------------	------------------------------------

C. PROCEDURE (4)

**(4) Task A320-A-46-XX-1156-02001-720A-A
(A320-A-46-XX-1156-02ZZZ-720Z-A)
Install the COAX Cables on Route 21T between the
Avionics Compartment and the FWD Cargo
Compartment**

Follow attached instructions from Page 104 to Page 110 ,from A320-46-1156 Rev 12,

C. PROCEDURE (5)

**(5) Task A320-A-46-XX-1156-03001-720A-A
(A320-A-46-XX-1156-03ZZZ-720Z-A)
Install the COAX Cables in Aft Electronics Rack 80VU**

Follow attached instructions from Page 111 to Page 118 ,from A320-46-1156 Rev 12,

E. TEST

**(1) Task A320-A-46-XX-1156-01001-300A-A
(A320-A-46-XX-1156-01ZZZ-300Z-A)
Test**

Referenced Information

Manuals/Drawings	References/Sheets
AMM	Task 25-54-11-400-001
	Task 25-54-12-400-002
ESPM	20-52-23

Procedure

NOTE: This Service Bulletin requires the accomplishment of tests which are given in:

- Ref. Task A320-A-46-XX-1156-01ZZZ-740Z-A

The manhours for the tests are included in the referenced Service Bulletin subtasks.

(a) Remove the safety clips and tags and close the C/Bs as specified after the installation of the partition panels (Panel 131CW, Panel 131DW and Panel 132EW) in the FWD cargo compartment, at Frame 24A, (if necessary), refer to Ref. AMM Task 25-54-11-400-001.

(b) Remove the safety clips and tags and close the C/Bs as specified after the installation of the ceiling panels (Panel 131AC, Panel 131HC, Panel 131KC and Panel 131MC) in the FWD cargo compartment, (if necessary), refer to Ref. AMM Task 25-54-12-400-002.

(c) Do the tests for the COAX cables, refer to Ref. ESPM 20-52-23.

Description Step 9

Wael Yazqi (11011720), 18.Aug.2025

F. CLOSE-UP

**(1) Task A320-A-46-XX-1156-01001-740A-A
(A320-A-46-XX-1156-01ZZZ-740Z-A)
Close-up**

Referenced Information

Manuals/Drawings	References/Sheets
AMM	Task25-54-11-400-001
	Task25-54-12-400-002
	Task52-30-00-860-002
	Task52-30-00-860-004
	Task52-30-00-860-009
	Task52-41-00-410-002

Procedure

- (a) Make sure that the work area is clean and clear of tools and other items.
- (b) Install the partition panels (Panel 131CW, Panel 131DW and Panel 132EW) in the FWD cargo compartment, at Frame 24A, refer to Ref. AMM Task 25-54-11-400-001.
- (c) Install the ceiling panels (Panel 131AC, Panel 131HC, Panel 131KC and Panel 131MC) in the FWD cargo compartment, refer to Ref. AMM Task 25-54-12-400-002.
- (d) Close the FWD cargo- compartment door, Door 825, refer to Ref. AMM Task 52-30-00-860-002 or Ref. AMM Task 52-30-00-860-004 or Ref. AMM Task 52-30-00-860-009.
- (e) Close avionics compartment door 812, refer to Ref. AMM Task 52-41-00-410-002.

- (f) Remove the access platform(s).
- (g) Put the aircraft back to its initial configuration.

Copyright of Saudia Technic - Regeneration is not allowed without prior approval by Saudia Technic.

COPY