

How to Back up MQM Database

Part I

Why do we need to back and restore ?

In course of time due to downloading and uploading lots of data the MQM DB increases in size .


This can affect the operation of the DB in means of speed .

In order to keep the DB in a small size we recommend that you make a backup and restore of the DB from time to time.


Part II - Backup

How to backup :

1. Open the IB console
2. logon to your server
3. right click on the "backup" and select backup - see picture:




4. select your db to backup - see picture




5. Fill in the name you wish to give for the backup file in both places:


1. the alias field
2. the file name if you don't give a full path (like c:\Interbase backup\mqmbbackup.gbk)
then the backup file shall be created in:([c:\program files\borland\bin](#))
- see picture



6. press OK and then you get this - see picture




7. Now you should have a backup file - see picture




Part III - Restore:

And now to restore:


8. right click on the "backup" and select restore - see picture



9. The form should have already the correct details - see picture



10. Change to overwrite : true (to overwrite the current DB) - see picture



11. Press OK .

12. Close the form - press cancel

13. That's it now you should be after restore with a much smaller DB file.