Assignment No: 12

Code:

```
#define fsrpin A0
#define buzzer 9
int fsrreading;
void setup() {
    Serial.begin(9600);
}

void loop() {
    fsrreading = analogRead(fsrpin);
    Serial.println(fsrreading);
    if(fsrreading>200){
        buzzerAlert();
    }
}

void buzzerAlert() {
    // Activate the buzzer for a specific duration tone(9, 220, 100);
    delay(200);
}
```

Output:

