

Chapter 4: Transport Regimes

Sediment transport begins when the bed shear stress exceeds the critical value for the grain size present. Below that threshold the bed is immobile and no net transport occurs at any depth.

Suspension becomes dominant once the shear velocity approaches the settling velocity of the particle. The transition is gradual and depends on turbulence intensity near the bed as well as size.