settings: settings passive PCB; instance 1/34; local references in manifest



release: release passive PCB; instance 2/34; local references in manifest



meter_input: meter_input passive PCB; instance 3/34; local references in manifest

ring: ring passive PCB; instance 9/34; local references in manifest

quantize: vertical_top passive PCB; instance 10/34; local references in manifest



Three directly wired common−anode display digits; manufacturer pin numbers







10k pots; terminal2 wiper; verify clockwise direction physically





















Momentary contacts:1–2 and3–4 internally common; press bridges pairs; wire1 and3 only



























































Source-bound main-board header pins; boundary symbols are not additional physical connectors