








## GRAFCET


SH201 - STEP N°020 SHUTTLE IS WAITING




SECTION 200 IN PRODUCTION  
SECT200\_PROD

LI202 SAFE POSITION  
LI202\_POS1\_SAFE


AUTHORIZATION TO UNLOAD  
UNLOADING\_AUTHORIZATION









5




6





7




8
























31








SH201\_AUTOR\_BR111







SH201\_SAFE\_CV109

35

Position Process  
Value

| LES      |                                            |
|----------|--------------------------------------------|
| Source A | SH201_FB_R.FP.Pos_PV<br>19.9994            |
| Source B | SH201_FB_W.PARAM.POSITION_2_SAFE<br>1500.0 |

SECTION 200 IN  
MANUAL MODE  
SECT200\_MANU

SECTION 200 IN  
AUTOMATIC MODE  
SECT200\_AUTO

STEP NUMBER  
SH201

| EQU      |                       |
|----------|-----------------------|
| Source A | SH201_SEQUENCE<br>110 |
| Source B | 20                    |

STEP NUMBER  
SH201

| EQU      |                       |
|----------|-----------------------|
| Source A | SH201_SEQUENCE<br>110 |
| Source B | 30                    |

STEP NUMBER  
SH201

| EQU      |                       |
|----------|-----------------------|
| Source A | SH201_SEQUENCE<br>110 |
| Source B | 40                    |

STEP NUMBER  
SH201


| EQU      |                       |
|----------|-----------------------|
| Source A | SH201_SEQUENCE<br>110 |
| Source B | 90                    |

STEP NUMBER  
SH201

| EQU      |                       |
|----------|-----------------------|
| Source A | SH201_SEQUENCE<br>110 |
| Source B | 100                   |

STEP NUMBER  
SH201

| EQU      |                       |
|----------|-----------------------|
| Source A | SH201_SEQUENCE<br>110 |
| Source B | 110                   |



SH201\_SAFE\_EXIT\_DOOR

36

Position Process  
Value

| LES      |                                            |
|----------|--------------------------------------------|
| Source A | SH201_FB_R.FP.Pos_PV<br>19.9994            |
| Source B | SH201_FB_W.PARAM.POSITION_2_SAFE<br>1500.0 |

SECTION 200 IN  
MANUAL MODE  
SECT200\_MANU

SECTION 200 IN  
AUTOMATIC MODE  
SECT200\_AUTO

STEP NUMBER  
SH201

| EQU      |                       |
|----------|-----------------------|
| Source A | SH201_SEQUENCE<br>110 |
| Source B | 20                    |

STEP NUMBER  
SH201

| EQU      |                       |
|----------|-----------------------|
| Source A | SH201_SEQUENCE<br>110 |
| Source B | 30                    |

STEP NUMBER  
SH201

| EQU      |                       |
|----------|-----------------------|
| Source A | SH201_SEQUENCE<br>110 |
| Source B | 40                    |

STEP NUMBER  
SH201


| EQU      |                       |
|----------|-----------------------|
| Source A | SH201_SEQUENCE<br>110 |
| Source B | 90                    |

STEP NUMBER  
SH201

| EQU      |                       |
|----------|-----------------------|
| Source A | SH201_SEQUENCE<br>110 |
| Source B | 100                   |

STEP NUMBER  
SH201

| EQU      |                       |
|----------|-----------------------|
| Source A | SH201_SEQUENCE<br>110 |
| Source B | 110                   |



SH201 SAFE POSITION  
FOR EXIT DOOR  
SH201\_SAFE\_EXIT\_DOOR

SH201\_INIT\_IN\_PROGRESS

SH201 INITIALIZATION  
IN PROGRESS  
SH201\_INIT\_IN\_PROGRESS

STEP NUMBER  
SH201

|                         |
|-------------------------|
| EQU                     |
| Source A SH201_SEQUENCE |
| 110                     |
| Source B                |
| 500                     |

37

SH201 IN SAFE POSITION

SECTION 200 IN  
AUTOMATIC MODE  
SECT200\_AUTOSTEP NUMBER  
SH201

| EQU      |                    |
|----------|--------------------|
| Source A | SH201_SEQUENCE 110 |
| Source B | 20                 |

STEP NUMBER  
SH201

| EQU      |                    |
|----------|--------------------|
| Source A | SH201_SEQUENCE 110 |
| Source B | 30                 |

STEP NUMBER  
SH201

| EQU      |                    |
|----------|--------------------|
| Source A | SH201_SEQUENCE 110 |
| Source B | 40                 |

STEP NUMBER  
SH201

| EQU      |                    |
|----------|--------------------|
| Source A | SH201_SEQUENCE 110 |
| Source B | 100                |

STEP NUMBER  
SH201

| EQU      |                    |
|----------|--------------------|
| Source A | SH201_SEQUENCE 110 |
| Source B | 110                |

STEP NUMBER  
SH201

| EQU      |                    |
|----------|--------------------|
| Source A | SH201_SEQUENCE 110 |
| Source B | 150                |

Position Process  
Value


| LES      |                                         |
|----------|-----------------------------------------|
| Source A | SH201_FB_R.FP.Pos_PV 19.9994            |
| Source B | SH201_FB_W.PARAM.POSITION_2_SAFE 1500.0 |


Speed Process Value

| LES      |                                    |
|----------|------------------------------------|
| Source A | SH201_FB_R.FP.Speed_PV 0.064847946 |
| Source B | -0.1                               |


SECTION 200 IN  
MANUAL MODE  
SECT200\_MANUPosition Process  
Value


| LES      |                              |
|----------|------------------------------|
| Source A | SH201_FB_R.FP.Pos_PV 19.9994 |
| Source B | 100                          |











48

SECTION 200 IN  
AUTOMATIC MODE  
SECT200\_AUTO

STEP NUMBER  
SH201

MAIN CHAIN STOPPED  
CV109\_STOP\_SH201

| EQU      |                    |
|----------|--------------------|
| Source A | SH201_SEQUENCE 110 |
| Source B | 40                 |

CV109 TRACKING DATA  
RING NUMBER (LETTER  
IN ASCII CODE)

| EQU      |                                 |
|----------|---------------------------------|
| Source A | TRACK_CV109[21].RING_NUMBER_L 0 |
| Source B | 0                               |

CV109 TRACKING DATA  
RING NUMBER (NUMBER  
VALUE)

| EQU      |                          |
|----------|--------------------------|
| Source A | TRACK_CV109[21].RING_NUM |
| Source B |                          |

CV109 TRACKING DATA  
GLASS PRESENT ON THE  
RING

TRACK\_CV109[20].GLASS\_LOADED

SH201 SEND  
AUTHORIZATION TO  
BR111 TO TAKE THE  
CART

SH201\_AUTOR\_BR111

GLASS NOT UNLOADED  
BY LI110

LI110\_GLASS\_NOT\_UNLOAD

ZONE 6 IN SAFE STATE  
F\_ZONE6\_SAFE

Exit Pos. 2nd Corner  
Detect PH4  
R23\_DI04.0

LI110 READY TO SEND  
LI110\_RTS\_SH201

STEP NUMBER  
SH201

| EQU      |                    |
|----------|--------------------|
| Source A | SH201_SEQUENCE 110 |
| Source B | 50                 |

STEP NUMBER  
SH201

| EQU      |                    |
|----------|--------------------|
| Source A | SH201_SEQUENCE 110 |
| Source B | 60                 |

STEP NUMBER  
SH201

| EQU      |                    |
|----------|--------------------|
| Source A | SH201_SEQUENCE 110 |
| Source B | 70                 |

STEP NUMBER  
SH201

| EQU      |                    |
|----------|--------------------|
| Source A | SH201_SEQUENCE 110 |
| Source B | 80                 |

STEP NUMBER  
SH201

| EQU |  |
|-----|--|
|-----|--|

Speed Process Value

| IES |  |
|-----|--|
|-----|--|

IMAND OPEN EXIT DOOR



COMMAND OPEN EXIT  
DOOR  
EXIT\_DOOR\_OPEN\_CD  
○

