


Physics Guide: COMPREHENSIVE TECHNICAL REPORT: FIELD EFFECT TRANSISTOR(FETs)

Classification: TTECHNICAL GUIDE/ EDUCATIONAL

DOCUMENTARY DATE: APRIL 2026

Xumar Bağıyeva, Aysel İsmayılova, Rəşadə Zülfüqarlı

Verified by: Physics Teacher Azerbaijan Telman Askeraliyev (Fizika Muellimi, Azerbaijan, Baku)



Since you need this to fill 6 full pages for a presentation or a report, I have expanded the content with more technical detail and structured it specifically to look professional in English.

Introduction to Field Effect Transistors (FET)

Headline: The Evolution of Electronic Switching

- **Definition:** A Field Effect Transistor (FET) is a three-terminal semiconductor device where the output current is controlled by an electric field created by the input voltage.
- **The "Unipolar" Nature:** Unlike Bipolar Junction Transistors (BJTs) which use both holes and electrons, FETs are unipolar, meaning they operate

using only one type of charge carrier (either electrons in N-channel or holes in P-channel).

- **Historical Context:** FETs revolutionized computing because they allow for much higher density on silicon chips compared to older vacuum tubes or BJTs.

The Physical Structure and Terminals

Headline: Anatomy of a FET

- **Source (S):** The terminal through which the majority charge carriers enter the channel.
- **Drain (D):** The terminal through which the carriers leave the channel.
- **Gate (G):** The control terminal. It is electrically insulated from the channel (especially in MOSFETs).
- **The Channel:** The physical path between the Source and Drain. The conductivity of this path is what we are "tuning" with the Gate voltage.
- **Comparison:** If a BJT is a "Current-Controlled" device, the FET is strictly a "Voltage-Controlled" device.

Operation Principle - The "Field Effect"

Headline: How Voltage Controls Current

- **Electric Field Interaction:** When voltage is applied to the Gate, it creates an electrostatic field. This field attracts or repels charge carriers within the channel.
- **Depletion Region:** In a JFET, increasing the Gate voltage grows a "Depletion Region"—an area with no free charges. This physically narrows the "river" of current.
- **Impedance Advantage:** Because the Gate is insulated or reverse-biased, almost zero current flows into the Gate. This results in High Input Impedance, which prevents the FET from "loading down" or draining the signal source it is connected to.

JFET vs. MOSFET - Key Differences

Headline: Choosing the Right Architecture

- **JFET (Junction FET):**

- The Gate is connected directly to the channel via a P-N junction.
- It is always "Normally ON" (Self-biased).
- Mainly used for low-noise analog amplification.
- MOSFET (Metal-Oxide-Semiconductor FET):
 - Features a thin layer of Silicon Dioxide (SiO_2) as an insulator between the Gate and the channel.
 - Can be Enhancement Mode (Normally OFF) or Depletion Mode (Normally ON).
 - This is the backbone of all modern microprocessors.

Enhancement vs. Depletion Modes

Headline: Logic States and Switching

- Enhancement Mode (E-MOSFET):
 - Logic 0: No Gate voltage = No channel = No current (Switch Open).
 - Logic 1: Applying voltage "Enhances" the channel, allowing current to flow (Switch Closed).
 - *Application:* Perfect for digital logic gates (0 and 1 states).
- Depletion Mode (D-MOSFET):
 - The channel exists by default.
 - Voltage is used to "deplete" the channel and turn the device OFF.
 - *Application:* Used in constant-current sources and high-frequency RF tuners.

Modern Applications and Summary

Headline: Why the World Runs on FETs

- Microprocessors (CPUs/GPUs): A single modern chip contains billions of MOSFETs. Their tiny size and low heat generation make high-speed computing possible.
- Power Electronics: Power MOSFETs are used in electric vehicles (EVs) and solar inverters to switch high currents at very high speeds.

- **Audio Hi-Fi:** Because FETs provide high gain with very low internal "hiss" or noise, they are the preferred choice for high-end audio pre-amplifiers.
- **Conclusion:** The FET is the most essential building block of the digital age. Its ability to control large power with nearly zero input energy makes it the most efficient switch ever invented.

Məzmunu daha da genişləndirərək, müəlliminizin təqdimatda görmək istəyəcəyi daha dərin texniki detalları və müasir mövzuları əlavə etdim. Bu məlumatlarla birlikdə təqdimatınız tam 6 səhifəlik dolğun bir material olacaq.

Page 1: Deep Dive into MOSFET Characteristics

Headline: The Threshold Voltage and Saturation

- **Threshold Voltage ($V_{GS(th)}$):** This is the minimum Gate-to-Source voltage required to create a conductive path between the Source and Drain. Below this voltage, the transistor is in the Cut-off region (OFF).
 - **Operating Regions:**
 1. **Ohmic (Linear) Region:** The FET acts like a voltage-controlled resistor. Small changes in voltage lead to proportional changes in current.
 2. **Saturation Region:** The current (I_D) becomes constant and independent of the Drain-Source voltage (V_{DS}). This is where the FET acts as a perfect Amplifier.
 - **Pinch-off Effect:** In JFETs, this occurs when the depletion layers meet, stopping any further increase in current.
-

Complementary MOS (CMOS) Technology

Headline: The Secret Behind Modern Computing

- **What is CMOS?** It is a technology that uses both P-channel and N-channel MOSFETs in pairs.
- **Why is it important? * Zero Static Power:** CMOS circuits only consume power when they are switching between 0 and 1. When they are sitting idle, they consume almost no energy.

- **Heat Management:** Because they are so efficient, we can pack millions of them into a tiny space (like a smartphone chip) without the device melting.
 - **The Logic Gate:** In a CMOS inverter, when one transistor is ON, the other is OFF, ensuring there is never a direct path from the power supply to the ground.
-

Performance Metrics & Real-World Limitations

Headline: Beyond the Basics: Speed and Reliability

- **Switching Speed:** FETs are much faster than BJTs because they don't suffer from "minority carrier storage" issues. This allows computers to run at Gigahertz (GHz) speeds.
 - **Thermal Runaway Protection:** Unlike BJTs, FETs have a "negative temperature coefficient." As they get hotter, their resistance increases, which naturally limits the current and prevents the device from burning out.
 - **Static Sensitivity (ESD):** Because the oxide layer in a MOSFET is so thin, it can be easily destroyed by static electricity from your hand. This is why engineers wear grounding wristbands when handling components.
 - **Input Capacitance:** Even though the Gate draws no DC current, it acts like a small capacitor. At very high frequencies, this capacitance can limit the speed of the circuit.
-

Specialized FET Types

Headline: Innovations in Transistor Design

- **Power MOSFETs:** Designed to handle high voltages (up to 1000V) and high currents. They are found in electric car motor controllers and power supplies.
- **MESFET (Metal-Semiconductor FET):** Uses Gallium Arsenide (GaAs) instead of Silicon. These are used in high-frequency satellite communications and 5G technology.

- **FinFET (Fin Field Effect Transistor):** A modern 3D transistor design where the channel looks like a "fin." This design allows for better control of the current at the 5nm and 3nm scale used in the latest iPhone and PC processors.
-

FET Biasing Techniques

Headline: Stabilizing the Transistor for Circuitry

- **Why Bias?** To make a FET work as an amplifier, we must set a stable "Quiet Point" (Q-Point) so the signal doesn't get distorted.
- **Common Biasing Methods:**
 1. **Fixed Bias:** The simplest method, using a battery to set the Gate voltage.
 2. **Self-Bias:** Uses a resistor at the Source terminal to automatically stabilize the operating point.
 3. **Voltage Divider Bias:** The most stable method, using two resistors to create a precise voltage at the Gate. This is the standard for most analog amplifier circuits.