

Q: Can I open the door mid-cycle?

A: If water is not too high, you can pause and wait for the door lock to release. Otherwise, door stays locked for safety.

Q: Why is my washer noisy during spin?

A: Check load balance, level the machine, clean drain filter, ensure floor is stable.

Q: Can I wash blankets or bedsheets?

A: Yes, but avoid overloading. Use Bedding/Bulky cycle.