

STANDARD OPERATING PROCEDURE - Version 2.4

Title: C-101 Startup and Shutdown Procedure

Equipment Tag: C-101 (Main Air Compressor)

Author: Tech Ops Team

1. Startup:

- Ensure all intake valves are clear.
- Verify oil levels in the main lubrication reservoir.
- Initiate the slow-roll sequence for 5 minutes before engaging the main drive.

2. Shutdown (Normal):

- Gradually reduce load over 15 minutes.
- Engage the cooling loop for 30 minutes post-shutdown.

3. Emergency Trip Response:

- If a pressure trip occurs, DO NOT attempt immediate restart.
- Follow the Lockout/Tagout (LOTO) procedure per OSHA standard 1910.147.
- A supervisor must inspect the unit before the trip can be reset.