



# X S'S Ink LLC i3x assembly guide

Quantity	Item Fasteners	Check Initial1			
	Nuts:			Bolts: M3×8 Grub	
	M4 Hex			M3X10 Socket	
	M5 Hex			M3×16 Socket	
	M8 Hex			M3×20 Socket	
	M8 Nyloc			M3×30 Socket	
	M8 Acorn			M4×25 Socket	
	#6-32 Hex			M4×40 Socket	
	#6-32 Wing			M8×30 Socket	
			M8×5	0 Hex	
	Washers: M3 Washer			#6-32 x 1 Flat	
	M8 washer			#6-32 x 2 Flat	
	Rods				
8mm threaded	l:				
	5~435mm				
	5~365mm				
	0~330mm				
	0~210mm ~18mm				
12 13	-1011111				
5mm threaded 2X 240	l: 0~250mm				
8mm smooth:	0. 405				
	0~405mm 5~375mm				
	5~325mm				




@ Copyright 2013 X S's Ink LLC, All Rights Reserved http://www.xssink.com/

# **Bed part 2**




@ Copyright 2013 X S's Ink LLC, All Rights Reserved http://www.xssink.com/

# **Bed Full**




© Copyright 2013 X S's Ink LLC, All Rights Reserved http://www.xssink.com/


#### ExtruderHinge




# **Extruder Hinge 2**




## **Extruder HotEnd Clamp**



#### **Extruder Motor**




#### **Extruder hubbed-bolt**





Mother board and fan mount


part 1




@ Copyright 2013 X S's Ink LLC, All Rights Reserved http://www.xssink.com/










#### back part 2




## back part 3









#### **Backsplash Support**






@ Copyright 2013 X S's Ink LLC, All Rights Reserved http://www.xssink.com/

XCarraige part 2





@ Copyright 2013 X S's Ink LLC, All Rights Reserved http://www.xssink.com/


#### X carraige part 3













belt tightening





If your motherboard is the Ramps 1.4 version here are the online instructions  $http://reprap.org/wiki/RAMPS\_1.4$ 

