#### FRA222 Microcontroller Interface


07 -0

QEI

## Rotary Encoder

Device that converts the angular position or motion of a shaft to analog or digital output signals.






Magnetic

### Rotary Encoder




## - Incremental

- Absolute



## **Absolute Rotary Encoder**


- Maintains position information when power is removed from the encoder.
- The position of the encoder is available immediately on applying power




## **Absolute Rotary Encoder**

#### **Output Type**

Parallel Out







**Gray Code** 

## **Absolute Rotary Encoder**

#### **Output Type**


Serial / Communication






## Incremental Rotary Encoder


- **NOT** Maintains position information when power is removed from the encoder.
- The position of the encoder is relative form start point / Home set point




# **Incremental Rotary Encoder**



Read By Circuit Read By Software Read By Interrupt Read By QEI



### QEI - quadrature encoder interface



#### QEI - quadrature encoder interface

