
Lesson 4 Interrupt


Lecturer: Harvard Tseng

Simply view at exception entry & exit




Level Trigger

 Peripheral interrupt request will store in status register(TIMx) or pending register(EXTI).




Pulse Trigger

 Pending status register will hold the request until the interrupt is being served.



If do not clear interrupt request

Will re-enter interrupt handler again and again.



SYSCFG

System configuration controller

Main purposes

- Enabling/disabling I2C Fast Mode Plus on some IO ports
- Remapping some DMA trigger sources to different DMA channels
- Remapping the memory located at the beginning of the code area
- Managing the external interrupt line connection to the GPIOs

• ...

Register

10.1.2 SYSCFG external interrupt configuration register 1 (SYSCFG_EXTICR1)

Address offset: 0x08

Reset value: 0x0000

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
Res.	Res.	Res.	Res.												
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
EXTI3[3:0]				EXTI2[3:0]				EXTI1[3:0]				EXTI0[3:0]			
rw	rw	rw	rw												

Bits 31:16 Reserved, must be kept at reset value.

Bits 15:0 **EXTIx[3:0]**: EXTI x configuration bits (x = 0 to 3)

These bits are written by software to select the source input for the EXTIx external interrupt.

x000: PA[x] pin x001: PB[x] pin x010: PC[x] pin x011: PD[x] pin x100: PE[x] pin


x101: PF[x] pin

other configurations: reserved

EXTI

Extended interrupts and events controller

External interrupt/event GPIO mapping



Register

- EXTI_IMR Interrupt mask register to mask interrupt request or not.
- EXTI_RTSR Rising trigger selection register
- EXTI_FTSR Falling trigger selection register
- EXTI_PR Pending register is set when the selected edge event arrives on the external interrupt line.

EXTI interrupt selection


- Eg. PAO as interrupt source.
- RCC->APB2ENR |= RCC_APB2ENR_SYSCFGEN; // Enable SYSCFG clock
- SYSCFG->EXTICR[0] |= SYSCFG_EXTICR1_EXTIO &
 SYSCFG_EXTICR1_EXTIO_PA; // Select the source input for EXTIO
- EXTI_IMR |= EXTI_IMR_IM0; // Set mask bit(EXTI_Line0)
- EXTI_RTSR |= EXTI_RTSR_RTO; // Active when rising edge occur
- NVIC_EnableIRQ(EXTIO_1_IRQn); // Enable NVIC IRQ channel

Timer

Register

- TIMx_CCRy capture/compare register if counter matches CCR value, will generate interrupt.
- TIMx_SR status register record CCR interrupt information.
- TIMx_DIER DMA/Interrupt enable register enable DMA/Interrupt request.

Generate square wave



TIM2_SR=~TIM_DIER_CC1IE <

Timer CCR interrupt configuration

- TIM2_DIER |= TIM_DIER_CC1IE; // Capture/Compare 1 interrupt enable
- TIM2_CCR1 = 100; // Give a match value to compare
- NVIC_EnableIRQ(TIM2_IRQn); // Enable NVIC IRQ channel

Peripheral Interrupt Handler

- Every interrupt handle's name is already well defined in startup_<device>.s.
- Implement handler function under main() or in independent source file.

```
int main(void){
    ...
}
void TIM2_IRQHandler(void){
    ...
}
```

Exercise

- If button pressed, increase frequency by 1. When frequency is bigger than 10, set to 1.
- Use ISR to handle actions when button pressed or timer match compare value.