The World's top 10 Chemicals

1) Sulfuric Acid, Hasoy 90 billion lbs/yr

Manufacture: Sulfur or H2S is burned in air to form SO2. Very exothermic.
SO2 is dried & reacted with air over

an intercooled - multipass V20s catalyst reactor. This makes 50s. The 50s is absorbed in H2504 in a packed tower. This is exothermic. This H2504 is then diluted - some recycled to absorber - some sent to product. The 50s is absorbed in H2504 (~98%) as opposed to pure H20 because it has a lower vapor pressure.

Uses: Alkylation units, Fertilizer, metal processing

2) Nitrogen, N2

52 billion lbs/yr

Manufacture: Distillation of liquid air (Lincle process)

Tb,02 = -183°C; T3,N2 = -195.8°C (a) P=1 atm note: The notified

Corpresser coder 600-70000; Mat my Distillation Linke cycle used in

Linke cycle used in

Linke cycle used in

Linke cycle used in

Note of the color of the color of the color of the color of the cycle used in

Pressure Swing adsorption on a zeolite. At high

Pressure Swing adsorption on a zeolite. At high

Other lever P-absorbed gas desorbs.

Membrane Separation - size exclusion
Magnetic methods - Oz is Stronly paramagnetic
Uses: Enhanced oil Recovery, freezing neat, Electronics,
inert atmospheres.

3) Oxygen, 02

37 billion lbsyr

Manufacture: See N2; Also Electrolytic decomp. of H2O

Uses: many chemical process - oxidation, Electronics, medical use

4) Ethylene, C2H4

36 billion 16s/gr

Manufacture: catalytic cracking of hydrocarbons, or thermal pyrulysis: Endothermic rxn.

Thermal pyrulysis at later & 1300-1600°F of potruleum fractions (largely Co's I gives from 6-40 Wo Ethylene Recovery in low pressure distillation columns—for removal of heavy HC's. low temp, high P. columns for CHy, Hy removal & Co's Cy's

Uses: Polyners - polyethylene, polyvinyl chloride, polystyren polyethylene terephthalate (2 Liter roke bottles); antifreeze

5) Ammonia, NH3

34 billion lbs/yr

Manufacture: Hober process: He from thermal retorning of Natural year Ul steam. No from air after De removed in furnace.

Noter gas shift (xxx comes in here

No the ix a ratio of 1:3 is sent at 550°C, 200-350 atm

over doubly promoted iron catalyst. recirculation, & bleeding of inerts is required. Need either refrigeration or scrubbing to collect NHz.

Exothermic 1xxx

Uses: Fertilizer, explosives, refrigeration, paper pulping

CADH)

6) Line, CaO 32 billion lbs/gr

Manufacture: Calcination (turning in the absence of O2) of limestone. Ca CO3 > CaO + CO2 (a) CaO + H20 = Ca (OH)2 exothermic linestone must be crushed & calcined at 1700-2450°F the CO2 must be removed quickly as exa (a) is reversible rotary Kilns are used. 6-124t in diameter x 60-400ft long

Uses: Metallurgy, soap, waste water treatment

71 Sodium Hydroxide, NaOH 24 billion lbs/yr

Manufacture: produced by electrolysis of Nacl solins

Uses: Chemical production, rayon, socp, pulp & paper

8) Chlorine, Cl2 23 billion lbs/yr

Manufacture: Also made by electrolysis of Nacl

Made in diaphraym cells. Cla made on anode, Ha

(9 North made at cathode.

With graphite anodes some CO2 is produced. (1/2 with water rapor (inevitably released in production) is very corresive. It must be dried with the soy, then it is liquetied (100 psi, - 100c) & stored.

Uses: Viny chloride, pulpt paper bleaching, Water traitment, chlorinated ethones, bromane production from sea water.

a) Phosphoric Acid, H3PO4

 $\left(\begin{array}{c} - \\ - \end{array} \right)$

23 billion lbs/gr

Manufacture: liquid elemental Phosphorous is burned at ~1000°F to form P2O5, this is phydrated in a spring tower & mists best absorp are collected in an electrostatic ppt. - this method produces occurs in "clean" phosphoric acid for uses other than fertilizer- a solin of when the H3D04 doesn't have to be particularly pure, 1304-as the wet process is used:

Phosphote rock t H2SO4 — Casoyisi t H3PO4 Partial puritial position - renoval of F, Ca, Fe, A1, Soy - is performed by evaporative concentration.

Uses: Fertilizer, dicalcium phosphate (Animal faud preparation)

10) Propylene, CH2=CH-CH3 20 billion lbs/yr

Manufacture: produced as side product in manufacture.
of gasoline, ore Ethylene.

Uses: Alkiylation with isobutane to raise octane levels in gas.
Polypropylene

In your free time investigate production of HCI, HNO3, benzene, P-Xylene, Acetic Acid, The water gas Shift rxn.