

2 BCN3DR ASSEMBLY GUIDE AXIS



2 BCN3DR ASSEMBLY GUIDE AXIS






BOM ID	Description	Qty
1	Carriage	1
4	DIN912 M3x12	4
2	DIN934 M3	4
3	LM8 Linear bearing	2

BOM ID

Description

DIN 912 M3x20









Enroscar el tornillo en el propio plástico, hasta llegar al final de la pieza y asomar por el orificio, como se muestra en la figura.


















BOM ID	Description	Qty
2	BCNozzle	1
3	DIN912 M3x8	3
1	Platform	1





BOM ID	Description	Qty
1	25mm fan	1
2	Cooler fan support	1
3	DIN912 M3x18	2
4	DIN934 M3	2





BOM ID	Description	ğ
1	Pneufit	1
2	Pneufit nut	1







BOM ID	Description	Qty
3	DIN912 M3x20	1
2	DIN934 M3	2
1	Rod Bar	1



BOM ID

DIN934 M3






BOM ID	Description	Qty
2	DIN912 M3x20	1
1	DIN934 M3	1








































Tensarlas correas y lubricar los belt pulleys

