Part File Validation

Purpose: To validate and update part and sheetmetal file properties

Functions:

- → The tool will detect active .par or .psm files automatically.
- → The tool will fetch properties from the open part and display them under current part details.
- → The tool will highlight mismatch properties with respect to standard BEC Material Data excel.
- → Users can select new properties and apply them to active parts or sheet metal files.

Constraint:

- The tool will work on one part at a time.
- → The tool will only work on .psm and .part files.

Part File Validation

User Interface Guide:

- 1. Open the desired part in Solid Edge and Activate the tool by clicking on it.
- Assign BEC Material excel path to fetch standard data, skip this step if already assigned.
- Click get BEC material data to fetch data from BEC material excel.
- 4. Users can filter new part detail by Material wise or by part type wise.
- 5. If the tool highlights any mismatch in current part details, the user can assign correct information under new part details Click
- 6. Apply button to assign new properties to part.
- 7. Click the refresh button to reset the tool.
- 8. Close the tool to use other tools if needed

