Assembly Validation



Purpose: To validate and update multiple parts from the assembly

Functions:

- → The tool will extract properties from the presently opened assembly file and display them in the "Current details" section.
- → Any variations in properties when compared to the standard BEC Material Data Excel will be brought to attention by the tool.
- → Users are provided with the choice to select new properties and apply them to their active parts or sheet metal files.

Constraint:

- → The tool will work only with assembly files.
- The tool will read only top-level parts.

Assembly Validation



User Interface Guide:

- Open the desired assembly in Solid Edge launch the Automation tool and access the Assembly validation tool by clicking on it.
- Click "Get BEC Material Data" to read BEC Material Data and fetch assembly parts
- 3. Click on part to get current properties under current details
- Users can search by part properties using the search option.
- Select material from the dropdown to assign new material user can also assign a gage table from the dropdown for sheet metal
- Click Apply button to assign new properties to part
- Click the refresh button to reset the tool.
- 8. Close the tool to use other tools if needed

