I. Description:

This device works at the international frequency band 2.400-2.483MHz with one handheld communicates to only one receiver. Effective communication distance can reach 50-70 meters in the clear open air.

II. Decode Capability:

Code11, Code39, Code93, Code32, Code128, Coda Bar, UPC-A, UPC-E

EAN-8, EAN-13, JAN.EAN/UPC Add-on2/5 MSI/Plessey, Telepen and China Postal Code

Interleaved 2 of 5, Industrial 2 of 5, Matrix 2 of 5, more for Request

III. Features:

- 1. New hi-tech product, RF section uses America TI company 2.4G wireless communication IC to ensure it working efficiency, stability and integrity.
- 2. Effective communication distance is 70-95 meters.
- 3. 250K wireless transmission rate, high speed to microseconds delay transmission.
- 4. Unique frequency hopping technology enables superior anti-jamming ability. Will not be disturbed by other 2.4GHz device.
- 5. Each scanner can be named with an individual ID to avoid interference with others when working in a network.
- 6. Auto data detection to ensure transmission accuracy.
- 7. Easy inventory with memory of 500-10000 codes, as convenient as working on a portable USB disk.

- 8. Auto sleep mode, low power consumption as common battery leakage current under natural condition.
- 9. Battery low voltage protection; the scanner emits a long beep when started under battery voltage lower than 3.5V.

IV. Specification:

Performance	
Optical Source	650nm laser
Communication Channel	2.4G
Communication Distance	70-95m (max.)
Reading precision	0.10-0.825mm
Reading Width	60mm at 30mm; 90mm at 100mm;
Reading Distance	10-420mm
Reading Speed	78 scans/sec.
Physical	
Dimension	80x60x160mm
Material	ABS
Weight	240g
Electrical	
Receiver Power Supply	DC 5V
Reader Power Supply	700mA Li-ion Battery
Working Current	75mA

V. Operation Instructions:

- 1. Connect the USB receiver to the host (e.g.: PC/other device)
- 2. Pull the trigger to start the scanner. It works on two beeps.

VI. Notes:

- 1. The charging port on the scanner is for battery charging only. Do not connect it with data cables.
- 2. The LED light at the scanner top is on (red or green) under charging and off when charging is finished.
- 3. During working, the scanner will auto shut down in case of not in use for 20 second.
- 4. The receiver was paired to the reader at factory. Do not pair again unless necessary. When self pairing is needed, please first read the code **CHSET**, then read the ten's digit and the units digit from the **Setting Conference** (Before setting, please reset the receiver until the light turns long red, and finish resetting it before the light off.)

VII. Beeps instruction

■read code succeed: one short beep

■self pairing failed: five short beeps

■read & trans succeed: two short beeps

■Trans failed: three short beeps

■low voltage alarm: one long beep

VIII. Package Including:

- 1 x Wireless Barcode Scanner
- 1 x Receiver
- 1 x Charging Cable
- 1 x Instruction