Common Settings

1. Sleep time(Default 20s)

Sleep time
SET(%%ALLTIMSET)

20s(%%ALLTIM00)　　30s(%%ALLTIM01)　　60s(%%ALLTIM02)　　2m(%%ALLTIM03)

5m(%%ALLTIM04)　　10m(%%ALLTIM05)　　20m(%%ALLTIM06)　　No sleep
(%%ALL*TIDIS)

2. Shutdown, Restore factory settings, Read version information

Shutdown
(%%POWEROFF)

Read Version
(%%Version)

Read Hardware
(%%HDVersion)

Restore factory
settings(%%Restore
)

3. Bluetooth work mode (Default HID Mode)

HID Mode
(%%BT_HID)

SPP Mode(%%BT_SPP)

4. Work Mode (Default normal mode)

Normal Mode (%%ALLPT-SET)

Take stock Mode SET
(%%ALLMEM-SET)

Keep the data in memory
(%%ALLAEM-SET)

Upload data (%%ALLMEM-
SC)

Total of
records(%%ALLMEM-ZS)

Clear records(%%ALLMEM-
QC)

Advanced settings

1. Channel Setting (2.4G(01-20)433M(01-30))

Make a pair (%%EZPair)

2. Buzzer hint 1："Scanned barcode" Tweet（Default OFF）

ON (%%BZOpen1)

OFF (%%BZClose1)

3. Buzzer hint 2 :"RF Uploaded successfully" Tweet（Default OFF）

ON(%%BZOpen2)

OFF(%%BZClose2)

4. Display battery power（Only for Bluetooth Scanner）

Display battery power
(%%Batt)