Clouds, Parasites, Super Parasites, SuperCell, Microcell.... and now... CIRRUS

ALL THE MODES: A COMPILATION & REWRITE/REEDIT OF ALL THE INFO OUT THERE FOR THE FIRMWARE CURRENTLY IN TANGIBLE WAVES 'CIRRUS' MODULE. word wrangled by Matt Wand (Rocky Smalls), all due credit to Emilie & all the additional firmware coders and documenters contributions sorted and compiled here.

In its tumultuous teenage years, Clouds tried to be everything, including a delay/pitch-shifter, a spectral processor, a projectionist and a cab driver in Rouen. as an adult cloud CIRRUS not only holds down those jobs but also indulges in Clairvoyancy, Zeppelin Hanger management and Carbon neutral Rain Dancing!

CHANGING MODE: hold down TIME button for over 1 second the LEDs will flash, short press TIME button whilst flashing will move between modes thus:

```
Mode 1 [●○○○]: Granular Clouds

Mode 2 [○●○○]: Pitch Shift / Time Stretch

Mode 3 [○○●○]: Looping Delay

Mode 4 [○○○●]: Spectral Processor

Mode 5 [○●●●]: Oliverb

Mode 6 [●○●●]: Resonestor

Mode 7 [●●○●]: Beat Repeat

Mode 8 [●●●○]: Spectral Clouds
```

leave on desired mode for a second and it will settle in.

Audio quality = time button, quick press

```
1- 32khz, 16bit, stereo, 1 second (of audio buffer)
```

```
2- 32khz, 16bit, mono, 2 seconds
```

3- 16khz, 8bit μ -law, stereo, 4 seconds

4- 16khz, $8bit \mu$ -law, mono, 8 seconds

Note that Clouds' 8-bit is a lovely flavour of 8-bit: μ -law companding. It sounds like a Cassette, or a Fairlight - less hiss, more distortion.

GRANULAR MODE Mode 1 $[\bullet \circ \circ \circ]$ Home sweet home. The Cumulo Nimbus original mode.

Clouds continuously records the incoming audio into a short amount of sample memory. While recording time can reach up to 8s by reducing the audio quality setting, you ought to feel very guilty every time you think of this as "tape" - think of it as a space, a room. Using this recorded audio data, the module synthesizes a sonic texture by playing back short (overlapping) segments of audio (also known as "grains") extracted from it.

Clouds allows you to control: From which part of the buffer the grains are taken.

synthesis than keeping a playback pointer moving through a SD-card sample!

How long the grains are. At which speed/pitch the grains are replayed.

How much overlap there is between the grains (density).

Whether the distribution of grains in time is constant or random.

Which envelope curve is applied to the grains - giving the impression of a "rough" or "smooth" texture. In addition, to create textures with a "blurry" feel, a diffuser (network of all-pass filters - like a reverb without tail) can be applied.

The module plays grains continuously, at a rate determined by the DENSITY and SIZE settings. A trigger input is also present, to explicitly instruct the module to start the playback of a new grain. The maximum number of concurrent grains is quite large - between 40 and 60. This specificity brings Clouds closer to the roots of granular synthesis, and allows the synthesis of varied textures even from basic waveforms - there's indeed many more dimensions to granular

It is possible, at any time, to HOLD (ie: Freeze) the audio buffer from which the grains are taken - In this case, the incoming audio is no longer recorded. Somehow, Clouds is the exact opposite of a sampler: by default, the module always samples the audio it receives, except when it is in the frozen state.

FRONT PANEL CONTROLS:

```
INPUT gain from -18dB to +6dB. applies for ALL modes.
```

HOLD This latching button stops the recording of incoming audio. Granularization is now performed on the last few seconds of audio kept in memory in the module. long press HOLD will reverse playback of the buffer.

POSITION Selects from which part of the recording buffer the audio grains are played. Turn the knob clockwise to travel back(?) forward in time.

```
SIZE controls size of grains, Left = smallest, Right = largest
```

PITCH (transposition). At 12 o'clock, the buffer is played at its original frequency.

generation rate & style of the grains. At 12 o'clock, no grains are generated. Turn clockwise and grains will be sown randomly, counter-clockwise and they will be played at a constant rate. The further you turn, the higher the overlap between grains. BEWARE THE DEADZONE! in this mode between aprox 10 o'clock & 2 o'clock no grains seem to be sown, possibly a Cirrus iteration problem, ie: that 12 o'clock area is TOO LARGE or TOO EXPONENTIAL maybe? but grains can be triggered via cv into the Trig input in this zone, so it has it's uses.

SHAPE Morphs through various shapes of grain envelopes: square (boxcar), triangle, and then Hann window. Past 2 o'clock it activates a diffuser which smears transients.

amount of signal sent back into pitch processing CAREFUL :), adds decay to the buffer clearing when not HELD. at full can take nearly a minute to fade out if PITCH is near 12 o'clock.

MIX dry/wet balance.

PAN Stereo spread of grains.

Amount and size of reverb applied to outgoing signal. REVERB

Inputs and outputs - All CV inputs are calibrated for a range of +/- 5V (?? check with robert) Voltages outside of this range are tolerated, but will be clamped.

- 1. HOLD gate input. When the input gate signal is high, stops the recording of incoming audio, just as latching the HOLD button would do.
- 2. TRIGGER input. Generates a single grain. By moving the grain DENSITY to the 12 o'clock Deadzone and sending a trigger to this input, Clouds can be controlled like a micro-sample player. An LFO or clock divider (or even a pressure plate) can thus be used to sow grains at the rate of your choice.
- 3. 4. Grain POSITION and SIZE CV inputs.
- 5. Grain transposition (PITCH) CV input, with V/Oct response.
- 6. MIX CV input. This CV input can control dry/wet balance,
- 7. 8. Stereo audio input. When no patch cable is inserted in the right channel input, this input will receive the signal from the left channel. (check?)
- 9. 10. Grain DENSITY and SHAPE CV inputs.
- 11. 12. Stereo audio output.

There are a few things worth knowing about the settings:

All settings are automatically saved, and will be restored the next time the module is powered on. Strange things happen when HOLD is enabled. Because feedback/layering can no longer occur in the recording buffer (hey, it's frozen...), we route the output signal through delays and all-pass filters, and let the feedback build-up occur in this extra recording space - giving the sound a very reverb-like nature.

NOTE: the PAN knob, in most modes PAN is actually stereo "spread" you won't hear any panning moving it left to right, CCW: it will 'mono-ize' the output, turning CW: it will open up the stereo for the grains to appear randomly across the stereo field.

In the Mono quality modes in eg: Oliverb which is mono in only , PAN crossfades between the left and the right input. Remember that the left input is normalized into the right input, so

with nothing patched in In L, this will have no effect. (check?)

PITCH-SHIFTER/TIME-STRETCHER Mode 2 [○●○○]

This mode is quite similar to the granular mode, except that it uses two overlapping grains synchronized with the most salient period of the sound. The grains are carefully spliced so that they mesh well with each other (a technique similar to the "deglitching" of early pitch-shifters). Modulating POSITION when recording is HELD will "scrub" through the audio buffer. Clouds' uses classic time-domain methods which are not suitable for polyphonic or percussive material (unless this percussive material is breakbeats and you liked Akai samplers. Then :)

HOLD Loops the buffer, long press should reverse the audio held in the buffer?

DENSITY creates a granular diffusion effect based on all-pass filters.

SHAPE acts as a low-pass/high-pass filter.

SIZE controls the size of the overlapping windows used for pitch-shifting and time-stretching - from an extremely grainy "drilling" sound to smooth bits of loops.

seems to be decay of the buffer ie: if not on HOLD CCW means when input muted buffer clears immediately, CW buffer runs out gradually (8 secs?)

dry/wet balance. MIX

PAN Stereo spread.

REVERB Amount and size of reverb applied to outgoing signal.

LOOPING DELAY Mode 3 [○○●○]

The looping delay mode continuously plays back audio from the buffer without any kind of granularization.

HOLD When HOLD is activated, the content of the audio buffer is looped (stutter effect).

POSITION controls the distance between the playback head and the recording head (in other words, the delay time). Modulating POSITION will create effects similar to vinyl scratching or manual manipulation of tape.

POSITION controls the loop start

SIZE controls the loop duration.

DENSITY creates a granular diffusion effect based on all-pass filters.

SHAPE from 12 o'clock leftwards: low-pass filter, from 12 to the right: high-pass filter.

FEEDBACK adds decay to the buffer when not HELD. single bursts of input audio will decay like an echo/release envelope.

MIX dry/wet balance.

PAN Stereo spread of grains.

REVERB Amount and size of reverb applied to outgoing signal.

TRIG input/cv When HOLD is enabled, sending a trigger on the TRIG input creates a clock-synchronized stuttering loop. Otherwise, the period of the trigger pulses sets the delay time — provided this delay is shorter than the recording buffer size.

SPECTRAL CUMULUS Mode 4 [○○○●]

In this mode, the incoming signal is converted into "frames" of spectral data, that are stored, transformed, recombined, and resynthesized as a time-domain signal.

HOLD freezes the audio buffer. see POSITION -

POSITION selects into which buffer the audio is poured (when HOLD is not active), or from which buffer the audio is synthesised (when HOLD is active). For example, set POSITION to its minimum value. Press HOLD. You get a first texture. Set POSITION to its maximum value. UN HOLD. Wait for something else to happen in the incoming audio. Press HOLD again. By moving POSITION you interpolate between the two textures which had been captured at the press of HOLD. Depending on the quality settings there are 2 to 7 buffers laid out over the course of the POSITION knob. What the module does is crossfade between a "wavetable" of FFT slices.

SIZE changes the coefficients of a polynomial that determines how frequencies are mapped between the analysis and synthesis buffers. It's like a 1-knob GRM Warp. Over the course of the knob it'll do spectral shifting, but also spectral reversal.

PITCH controls the transposition (pitch-shifting).

DENSITY determines how results from the analyzer are passed to the resynthesizer. Below 12 o'clock, there's some increasing probability that a given FFT bin won't get updated, causing a kind of partial freeze. After 12 o'clock, adjacent analysis frames are increasingly merged together (like a low-pass filter in the amplitude each frequency bin). At extreme settings, random phase modulation is applied to smooth things - giving you different flavours of spectral muddling/reverb.

SHAPE does two things: below 12 o'clock, it increasingly quantizes the amplitudes of the spectral components, like a very low-bitrate audio file. After 12 o'clock, it increasingly weakens the strongest partials and amplifies the weakest ones. This has the effect of making the spectrum more noise-like.

FEEDBACK sends signal back round through the pitch processor? (check?)

MIX dry/wet balance.

PAN Stereo spread of grains.

REVERB Amount and size of reverb applied to outgoing signal.

Sending a trigger to the TRIG input creates various frequency-domain glitches typical of corrupted (encoded) audio files. It works as a kind of build-up/feedback effect - the shorter the pulse, the smaller the effect. With a continuous gate, it'll really start to rot...

OLIVERB: Mode 5 [0•••]

This mode is mono-in, stereo-out. (?? check)

HOLD (Freeze) The hold button sets reverb to (near) infinite decay, and mutes the input. This works best with no pitch shifting and a large size.

POSITION (Pre-delay) The Position knob controls the time it take for the reverb to kick in after a sound has gone in (from 0 to about half a second). When a clock is fed to the Trig input, this knob becomes a clock divider/multiplier for the pre-delay: at 12 o'clock, the pre-delay takes the value of the clock length; clockwise, this clock is divided, and counter-clockwise it is multiplied following the rates: 1/16, 3/32, 1/8, 3/16, 1/4, 3/8, 1/2, 3/4, 1, 3/2, 2/1, 3/1, 4/1, 6/1, 8/1, 12/1 (borrowed from the Echophon). Note that the clock division is limited to the largest division not exceeding the maximum delay; beyond this point, the Position knob will have no effect. Changing predelay in real time is smooth and does not affect pitch (it uses the internal time stretcher).

SIZE (Reverb Size) The Size knob controls the lengths of all the delays internal to the reverb, i.e. the size of the emulated room. It varies from a small resonator to a huge hall.

DENSITY (Decay) The Density knob controls the amount of sound fed back into the reverb loop, i.e. the decay time of the reverb tail. Beyond 3 o'clock, this signal is actually amplified and the reverb enters self-oscillation.

SHAPE LP/HP filter

PITCH (Pitch shift) Each time the sound is fed back into the reverb, it can be pitch shifted. The Pitch knob controls, from -1 to +1 octaves how it is pitch shifted. At 12 o'clock, no pitch shifting is applied; fully clockwise, we get the classic shimmer effect; lots of oddities can be found in between. To hear the effect of the pitch shifter, some sound has to fed back by increasing Decay. Note that Size has an impact on how well the sound is pitch-shifted: the larger the room size, the more accurate the pitch shift. Dampening The Texture knob controls the dampening of the reverb. From fully CCW to 12 o'clock, a low-pass filter is applied, simultaing the absorption of the room. From 12 o'clock to fully CW, a high-pass filter is applied for unusual, crystalline effects.

 ${\tt MIX}$ (Dry/Wet) The first function of the Mix knob is dry/wet crossfading, as in the other modes.

PAN (Diffusion) The second Blend mode (called "stereo spread") controls how much the sound is "smoothed" by the diffusers each time it goes through the loop. Fully clockwise, you get the more dense, continuous sound; fully counter-clockwise, you clearly hear the sound being repeated like in a multi-tap delay.

REVERB (modulation amount) Each delay in the reverb can be individually modulated by 9 smoothed random LFOs. The Reverb knob controls the amount of modulation applied by the LFOs to the delay time. Small modulations result in subtle chorus and ghost tones, large modulations in random pitch shifts.

FEEDBACK (Modulation speed) The feedback knob controls the speed of the 9 random LFOs. It ranges from $\sim 1/100\,\mathrm{Hz}$ to $\sim 100\,\mathrm{Hz}$. It has no effect if modulation amount is null.

TRIG input/cv syncs the pre-delay

RESONESTOR Mode 6 [●○●●]

It is a dual-voice, four-parts resonator (or comb filter) effect with built-in capability for polyphonic Karplus-Strong plucked string synthesis, and more.

Each input feeds one of the two voices/resonators, which decay is controlled by the Density knob. Remember that In L is normalized to In R, so with nothing patched in In R, the In L signal is fed to both voices. The pitch of the resonator is controlled by the Pitch knob and the V/Oct input, so you can "play" the resonator like an oscillator. In fact, each voice consists of four "parts" (four resonators), which can be set to different pitches to form chords. The Size knob sets the chord, borrowed from Braids: unison, detuned, fifth etc. The resonators can sound very metallic; the SHAPE knob helps attenuating the high/low frequencies each time sound passes through the resonator. At 12 o'clock, no filtering is applied; CCW is a low-pass filter; CW is a band-pass filter. This way, a short sound impulse passing through the resonator will have a long decay with less and less high (and possibly low) frequency.

This technique, sending a short noise burst to "excite" a resonator, is the so-called Karplus-Strong algorithm to synthesize the sound of plucked strings instruments like guitars. Here, no need for additional modules: sending a trigger to the Trig input will send a short burst of noise to one of the voices. The Position knob controls the timbre and duration of this burst, roughly modelling the position on which the string is struck.

Up to now, we only discussed one voice. Actually, each time a Trig is received, the module switches the active voice; therefore, you can get duophony. At any time, the knobs (pitch, chord, feedback, damping) control only the parameters of the resonators of the active voice; the other voice keeps the last parameters it was on. If you are satisfied with the sound of

the current voice and want to keep it running (maybe as a drone, using the other voice for melody), press Freeze: it will instantly switch voice, and prevent Trig from automatically switching voice.

DENSITY (Decay) Decay time of the current voice. Beyond approx. 3 o'clock, decay is infinite and the sound sustains forever (you can use it as a traditional oscillator).

PITCH Base pitch of the current voice. At 12 o'clock, the pitch is A3 (220Hz).

SIZE (Chord) Chord selection for the current voice. Morphs gradually between Unison, Fat, Superfat, Fat power, Fat octave, Octaves, Power, Major, Major7, Minor7, Minor, Sus2, Sus4, Minor9, Major9, Minor11, Major11, and Major11.

SHAPE (Dampening) Controls filtering in the feedback loop of the resonator. At 12 o'clock, no filtering is applied; CCW, a low-pass filter is applied with a increasingly low cutoff frequency; CW, a band-pass filter at the frequency of the resonator is applied with an increasingly high resonance.

POSITION Controls the timbre and duration of the noise burst. CCW, it will be longer and more dampened; CW, it will be shorter and more high pitched. At both ends of the knob, the burst will be inaudible (too damped or too short), which you can use to "mute" a voice.

HOLD Switch the current voice, and inhibits further voice switch by the Trig CV.

MIX. (controls Distortion) Randomly distorts the timbre of the voices by modulating each comb filter by low pass-filtered noise. Fully CCW, the modulation amount is maximum but the noise is filtered out entirely, so there is no effect. Fully CW, the noise is unfiltered, but the modulation amount is null, so there is no effect. In between, you get interesting effects, from subtle swaying to harsh distortion.

PAN. (Stereo output) Assigns each part and voice to an output (Out L or Out R). Fully CCW, each voice goes to a different output. At 12 o'clock, both voices are equally mixed in both output. Fully CW, parts of both voices are distributed on both output for a wide stereo effect.

FEEDBACK (Harmonics)Simulates striking the harmonics on a string. Fully CCW, it has no effect. Fully CW, the second harmonic will ring; at 12 o'clock, the third, at 10 the fourth etc. Scatter (fourth function of Blend knob and CV) Controls the random delay times before the sound (input or burst) hits each resonator of the current voice. Used for K-S synthesis with a chord, this will give the impression that strings are struck sloppily. The delay times are randomized at each voice switch.

REVERB SCATTER

TRIG (Burst) Trig button OR CV input will switch the current voice (if Freeze is not active) and send a short burst of noise in its resonator.

BEAT REPEAT Mode 7 [●●○●]

Note: This mode requires a clock signal plugged into the Trigger input. Without a clock signal, it holds the most recent slice (or outputs silence if no clock signal has been previously provided)

The Kammerl Beat-Repeat mode analyzes the incoming clock signal to enable real-time slicing of the audio input. It manages multiple slices in real-time which can be individually selected. Each slice can be played back with different loop, pitch and distortion settings.

 ${\tt HOLD}$ Enables slice processing / beat-repeating. If not enabled, slice processing is randomly enabled based on the Mix knob setting for Slice Probability.

POSITION (Loop Start) Defines the beginning of the loop interval relative to the total slice duration. To support in-sync beat repetitions, it is quantized as follows: [0-1/64] free/unquantized, 1/64, 1/32, 1/16, 1/8, 1/4, 1/3, 1/2, 1.

SIZE (Loop Size)Defines the size of the loop interval relative to the total slice duration as well as the loop mode (regular/alternating). To support in-sync beat repetitions, it is quantized as follows: Regular from the left to 12 o'clock: [0-1/64] free/unquantized, 1/64, 1/32, 1/16, 1/8, 1/4, 1/3, 1/2 Alternating from 12 o'clock to the right: 1/2, 1/3, 1/4, 1/8, 1/16, 1/32, 1/64, [1/64-0] free/unquantized

PITCH (playback speed) The Kammerl Beat-Repeat mode does not time-correct the pitch changes (so somewhat like a tape or record running at different speeds). This allows for interesting groove effects, since audio is delayed towards the end of the slice but reset at the slice beginning. To the very left, the knob defines a zero pitch, to the very right, the original playback speed. (check these params) The pitch modulation is determined by the FEEDBACK knob.

DENSITY (Loop Size Modulation) Enables a decreasing loop size towards the slice end. This enables a ping-pong bouncing ball effect: Tak tak tak taktak tatatattttttt

SHAPE (slice mode) this parameter selects individual iteration patterns to jump between slices during playback, it incorporates the Shape CV slice selection by using it as an offset. the patterns are as follows Clockwise from 0 (disabled)

0 - Disabled - Only Texture CV selects slices. 1 - Repeats current slice due to synced playback index. 2 - Skips every second slice. 3 - Skips two slices. 5 - Skips four slices. 6 - Skips five slices. 7 - Skips six slices. 8 - Random - Randomly selects slices

note: Shape CV Selects one of the eight most recently recorded slices. 0V corresponds to the most recent slice (real-time / no delay!). Note that slices are continously created from audio input, independent from HOLD or slice probability mode.

MIX (Slice Probability) Defines the probability of disabling bypass and processing an incoming slice. Note that activating the HOLD button overwrites this setting.

PAN (Clock Divider)Selects a clock divider: 1, 1/2, 1/4, 1/8 which changes the slice lengths accordingly.

FEEDBACK (Pitch Mode) Selects one of four pitch modulation modes (from left to right): (left position) Fixed pitch - no modulation. (9 o'clock) Fixed pitch - reverse playback. (12 o'clock) Linearly decreasing pitch starting from the original pitch to the selected target pitch (Pitch Knob). (3 o'clock) Linearly increasing pitch starting from the the selected target pitch (Pitch Knob) to the original pitch. (full right position) Simulated vinyl scratching - sinusoidal pitch modulation - the Pitch Knob defines the intensity.

REVERB (Feedback, counterintuitively! :]) Controls the contribution to Cloud's feedback path. Combined with lower pitch playback, this leads to "trevor horn" style lazer gun effects on drums :)

SPECTRAL CLOUDS Mode 8 [• • • 0]

The Spectral Clouds mode creates cloud-like frequency spectras. It is a high-resolution multiband filter with randomly modulated frequency bands. The logarithmic divisions of the frequency spectrum result in a continuously morphing but musical sounding filter. This mode is inspired by this FFT Randomizer project.

HOLD freezes the buffer.

PITCH Frequency(?) amount(?) of Pitch shifting applied to the Spectral Clouds output.

POSITION (Frequency band probability) Defines the probability of a frequency band to become enabled. To the left all frequency bands are disabled. Check out the sweet spot (?) where only a few frequency bands are active.

SIZE (Frequency band division)Controls the number of filter bands and their corresponding frequency width. To the left, the frequency spectrum is split into 4 filter bands and to the right into 128 filter bands. All frequency band divisions are applied in logarithmic scale to sound musical.

DENSITY (Filter Smoothing) Defines the smoothing intensity on the frequency band division as well as the filter band attenuation changes during "trigger input" events. To the left, filter changes are applied immediately; to the right, the current filter configurations is held.

SHAPE $\,$ (Filter texture) Defines the degree of phase randomization in the frequency domain. This affects mostly waveforms with transients.

MIX (Dry/wet balance) Balance between input signal and Spectral Clouds output. Note that a warm distortion effect as well as Cloud's reverb is applied post dry / wet.

PAN (random filter change probability) Defines the chance of simulated "Trigger input" events. To the left, simulated trigger events are disabled and random filter reconfigurations only happen during high trigger input gates.

FEEDBACK (warm distortion) Adds a warm sounding distortion effect (applied post dry/wet).

REVERB (exactly what it says) Controls the contribution to Cloud's reverb (applied post dry/wet).

TRIG input/cv Randomizes the set of active frequency bands and defines their random attenuation intensity. Note that these trigger events can also be simulated with the POSITION knob (Frequency band probability).

GENERAL NOTE: the post-processing reverb COMES after dry/wet MIX, so that it also affects the dry signal (so you can use Clouds as a simple reverb plus its main function)

V1 - 13th sept 2021 - m.w.